

INSTALLATION, OPERATION AND TROUBLESHOOTING

MM9110 - MICROCOMMANDER USER MANUAL

www.barcos.com.uy
Alejandro Bologna
+59899524273

MARINE PROPULSION SYSTEMS



Released by After Sales dept.

Data subject to change without notice. We decline all responsibility for the use of non-original components or accessories which have not been tested and submitted for approval.

ZF reserves all rights regarding the shown technical information including the right to file industrial property right applications and the industrial property rights resulting from these in Germany and abroad.

© ZF Friedrichshafen AG, 2014.

Table of Contents

SW15623.0P

MicroCommander User Manual	1
Table of Contents	3
Preface	15
Revision List	19
1 Introduction	21
1.1 Basic Theory of Operation.....	21
1.2 System Features.....	21
2 Operation	23
2.1 DC Power On.....	23
2.2 Taking Command	23
2.3 Basic Operation.....	24
2.4 Start Interlock.....	24
2.5 Station Transfer.....	25
2.6 Proportional Pause.....	25
2.7 Warm-up Mode (Throttle Only Mode).....	26
2.8 High/Low Idle	27
2.9 One Lever Mode	28
2.10 Engine Synchronization.....	30
2.11 Control Systems' Configurability.....	32
2.12 Audible Tones	34
2.13 Push Button Set Up	35
2.14 Visual System Diagnostics, Set Up And Status Indication.....	35
2.15 Pluggable Connections	35
2.16 Optional Features.....	36
3 Plan The Installation	37
3.1 System Requirements	37
3.2 Wire Harnesses	38
3.3 Electric Cables	39
3.4 Tachometer Sensors (optional).....	41
3.5 Installer Supplied Tools And Parts	41
3.6 DC Power Source	42
4 Installation	45
4.1 Processor	45

4.2	Control Head(s)	45
4.3	Wire Harness Installation	45
4.4	Hard-Wired Cable	48
4.5	Engine Stop Switches	55
4.6	Push-Pull Cable Connections	55
5	Set Up Procedures	59
5.1	Processor Components Used In Set Up	59
5.2	Activating Set Up Mode	62
5.3	Storing Values To Memory	62
5.4	Function Codes and Values	62
5.5	System Programming and Adjustments	64
6	Dock Trials	75
6.1	Control Heads (Engines Stopped)	75
6.2	Start Interlock (Engines Stopped)	75
6.3	Basic Throttle Settings (Engines Stopped)	76
6.4	Servo Throttle Settings (Engines Stopped)	77
6.5	Servo Checks (Engines Running)	78
6.6	Engine Stop Switches (Engines Running)	79
6.7	Control Head Command Checks (Engines Running)	79
6.8	(E5) Throttle Pause Following Shift (Engines Running)	79
7	Sea Trials	81
7.1	Full Speed Setting	81
7.2	Proportional (Reversal) Pause - C2	81
7.3	Proportional (Reversal) Pause Time - C3	82
7.4	Synchronization Test	84
	F-226 9000 Series Sea Trial Report	85
8	Control Options	91
8.1	External Alarm Capability	91
8.2	Clutch Pressure Interlock	92
8.3	Station Expander (SE)	93
8.4	9001 Actuator Trolling Valve Control	94
9	Periodic Checks And Maintenance	95
9.1	Control Heads	95
9.2	Processor	95
9.3	Power	95
10	Troubleshooting	97
10.1	Control System Examples	97

10.2	Typical System Main Components.....	97
10.3	Questions	98
10.4	Problem Resolution.....	100
10.5	Diagnostic Menu	101
10.6	Audible Tones	104
10.7	Station Transfer.....	110
10.8	Error Codes	115
10.9	Problem Causes And Solutions	118
10.10	Problems Without Error Codes	128
10.11	Synchronization Troubleshooting	131
10.12	Wire Harnesses.....	135
10.13	Processor Pigtails.....	143
11	Appendix A - System Components and Specifications.....	147
	MMC-280 400 Series Control Head Variations.....	149
	MMC-329 MC2000 Series Standard Control Head Variations	155
	MMC-307 700 Series Standard Control Head Variations.....	159
	MMC-279 400 Series Weather Mount Enclosure.....	165
	Deutsch Connector Assembly	167
	S-214 Automatic Power Selector Model: 13505	169
	Drawing 11488 DC Power Source Kit.....	171
	MMC-287 Grounding (Bonding)	181
	MMC-288 References and Parts Source	183
	SER-161 Engine Tach Sender Req.....	185
	MMC-289 Morse Clutch and Throttle Kit	187
	MMC-290 Universal Mounting Kit	189
	MMC-345 43C Cable Conversion Kit.....	191
12	Appendix B - Sales and Service Information.....	193
	MMC-123 Factory Authorized Sales & Service - North America.....	195
	MMC-165 Warranty	201
	MMC-163 Warranty Registration	203
	MMC-151 Factory Authorized Service Centers - North America	205
	MMC-172 Factory Authorized Sales & Service Centers - International.....	217
	ENG-127 9000 Series Micro/ClearCommand Servo Throttle - Servo Clutch Qualitative Failure Analysis, Design Verification Test Procedure and Periodic Safety Test.....	225
13	Appendix C - System Drawings.....	229
	Drawing 12271 MicroCommander - Mechanical Throttle / Shift	231
	Drawing 12379 MicroCommander - Mechanical Throttle / Shift	237
14	Reference Manual MM13927 Field Service Test Unit.....	243

List of Figures

Figure 2-1: Station taking Command.....	23
Figure 2-2: Control Head Detents.....	24
Figure 2-3: Remote Stations Before Transfer of Command.....	25
Figure 2-4: Remote Station Transfer after Transfer of Command	25
Figure 2-5: Control Head Warm-Up Mode	26
Figure 2-6: Control Head Normal Operating Mode	26
Figure 2-7: High/Low Idle Mode Selection.....	27
Figure 2-8: (Step A) One Lever Operation Mode.....	29
Figure 2-9: (Step B) One Lever Operation Mode.....	29
Figure 2-10: Processor Connections View	35
Figure 3-1: Processor Dimensions	37
Figure 4-1: Harness Plug Keying.....	46
Figure 4-2: Start Interlock Connections.....	46
Figure 4-3: Twin Screw Serial Harness Connections.....	47
Figure 4-4: Liquid Tight (Watertight) Connector Installation.....	48
Figure 4-5: Processor Enclosure Cable Holes	49
Figure 4-6: Processor Circuit Board Termination Points	49
Figure 4-7: Seven-Conductor Control Head Cable Shield Wire and Heat-Shrink	51
Figure 4-8: Clamp Views.....	51
Figure 4-9: Terminal Strip Cable Connections.....	51
Figure 4-10: Two-Conductor Start Interlock Cable.....	52
Figure 4-11: Two-Conductor Power Cable.....	53
Figure 4-12: Four-Conductor Serial Communication Cable	53
Figure 4-13: AC Type Tachometer Cable	54
Figure 4-14: Open Collector Tachometer Cable.....	55
Figure 4-15: Processor Cable Clamp Rotation	56
Figure 4-16: Processor Push-Pull Cable Interior Connections	56
Figure 4-17: Throttle Push-Pull Idle Orientation to Selector Lever	56
Figure 4-18: Shift Push-Pull Cable Neutral Connection	57
Figure 5-1: Typical Processor Cover	59
Figure 5-2: Processor Shield Push Button and Display LED Locations	60

Figure 5-3: Display LED at Normal Operation	60
Figure 5-4: Decimal Point indicators.....	60
Figure 5-5: Push Buttons	61
Figure 5-6: Display Error Menu Example	61
Figure 5-7: Display Four (4) Digit Value	62
Figure 5-8: Display LED Function A0	65
Figure 5-9: Display LED Function A1	66
Figure 5-10: Display LED Function A2	66
Figure 5-11: Display LED Function A4	67
Figure 5-12: Throttle Push-Pull Cable Orientation.....	68
Figure 5-13: Display LED E0 - Servo	68
Figure 5-14: Display LED E7.....	69
Figure 5-15: Display LED C0.....	69
Figure 5-16: Display LED C1.....	70
Figure 5-17: Display LED C4.....	71
Figure 5-18: Clutch Push-Pull Cable Orientation.....	71
Figure 5-19: Display LED C5 - Servo	72
Figure 5-20: Clutch Push-Pull Cable Ahead Position	72
Figure 5-21: Display LED C6 -Servo.....	72
Figure 5-22: Clutch Push-Pull Cable Astern Position	73
Figure 5-23: Display LED C7 - Servo	73
Figure 6-1: Display LED E1	76
Figure 6-2: Display LED E4.....	76
Figure 6-3: Display LED E6.....	77
Figure 5-4: Throttle Push-Pull Cable Full Throttle Position	77
Figure 6-5: Display LED E3 - Servo	77
Figure 6-6: Display LED E2 - Servo	78
Figure 7-1: Display LED Function C2	82
Figure 7-2: Display LED Function C2	83
Figure 8-1: External Alarm Harness Example.....	91
Figure 8-2: External Alarm Hard-Wired Example	91
Figure 8-3: With Processor Harness	93
Figure 8-4: With Processor Hard-Wired.....	93

Figure 10-1: Display Function Code	102
Figure 10-2: Display Troubleshooting Function	102
Figure 10-3: Display Function Blinking	102
Figure 10-4: Example Display of Applied Battery Voltage	102
Figure 10-5: Example Display of Tach Sensor Frequency	103
Figure 10-6: Example Display Control Head Lever Current Positions	103
Figure 10-7: Example Display Control Head Transfer Button Status View	103
Figure 10-8: Example Display Software Revision Level View	104
Figure 10-9: Display Examples of Remote Stations	106
Figure 10-10: Display Examples of Remote Stations A/D Value	106
Figure 10-11: Display Station A/D's No Station Transfer Button Depressed	112
Figure 10-12: Example Display Station A/D's Transfer Button Depressed for Stations 1 - 4	112
Figure 10-13: Display Station A/D/s Transfer Button Depressed for Station 5	112
Figure MMC-280-1: Part Numbering Configurations	149
Figure MMC-280-2: Detents Available	149
Figure MMC-280-3: Dimensions	150
Figure MMC-280-4: Terminal Connections	151
Figure MMC-280-5: AFT Facing Control Head	151
Figure MMC-329-1: Part Numbering Configurations Detents Available	155
Figure MMC-329-2: Dimensions	156
Figure MMC-329-3: Terminal Connections	157
Figure MMC-329-4: AFT Facing Control Head	157
Figure MMC-307-1: Part Numbering Configurations	159
Figure MMC-307-2: Detents Available	159
Figure MMC-307-3: Dimensions	159
Figure MMC-307-4: Dual Control Head Connections	161
Figure MMC-307-5: Aft Facing Control Head	161
Figure MM13927-1: .Service Field Test Unit (Break-out Box)	247
Figure MM13927-2: CruiseCommand Connector Locations	247
Figure MM13927-3: Example of CLEARCommand Pigtail Locations	248
Figure MM13927-4: Throttle Connection (DC Voltage)	249
Figure MM13927-5: Throttle Connection (Current mA)	250
Figure MM13927-6: Throttle Connection (PWM with DC Voltmeter)	250

LIST OF FIGURES

Figure MM13927-7: Throttle connection (PWM with Duty Cycle Meter)	251
Figure MM13927-8: Throttle Connection (Frequency Hz)	252
Figure MM13927-9: Clutch Connections Neutral Solenoid.....	252
Figure MM13927-10: Clutch Connections Ahead Solenoid	253
Figure MM13927-11: Clutch Connections Astern Solenoid.....	254
Figure MM13927-12: Troll Connections Troll On/Off Solenoid.....	254
Figure MM13927-13: Troll Connections (Proportional Solenoid)	255
Figure MM13927-14: 2-Speed Connections	256

List of Tables

Table 2-1: Processor Pigtail List.....	36
Table 4-1: Circuit Board Hard wire Termination Table.....	50
Table 4-2: Connections for Remote Stations.....	51
Table 4-3: Processor Circuit Board Connections for Serial Communication Cable	54
Table 4-4: Processor Circuit Board Connections for Tachometer.....	55
Table 5-1: Processor Function Codes	63
Table 5-2: Throttle Servo Function Codes.....	63
Table 5-3: Solenoid Clutch Function Codes	63
Table 5-4: Trolling Valve Function Codes.....	64
Table 5-5: Solenoid Clutch Function Codes	64
Table 5-6: Throttle Functions Performed during Dock Trials.....	67
Table 5-7: Basic Clutch Functions Performed during Sea Trials.....	69
Table F-226-1: Vessel Information	85
Table F-226-2: Processor Information.....	85
Table F-226-3: Power Supply	86
Table F-226-4: Dock Trials	86
Table F-226-5: Record at Dock.....	86
Table F-226-6: Sea Trials	87
Table F-226-7: Record during Sea Trial	87
Table F-226-8: Processor Parameters Record.....	87
Table 8-1: Key for Figure 8-1: and Figure 8-2: Designators	91
Table 8-2: Figure 8-3: and Figure 8-4: Designator	93
Table 10-1: Examples of Components (Internal/External)	101
Table 10-2: Control Head Lever A/D Counts	111
Table 10-3: Basic Error Codes	115
Table 10-4: Servo 1 Error Codes.....	117
Table 10-5: Servo 2 Error Codes.....	117
Table 10-6: Basic Control System Problem Causes and Solutions.....	118
Table 10-7: Servo 1 Clutch Problem Causes and Solutions	126
Table 10-8: Servo 2 Throttle Problem Causes and Solutions	127
Table 10-9: Basic Control System Problems Without Error Codes (Symptom: A).....	128
Table 10-10: Basic Control System Problems Without Error Codes (Symptom: B).....	128

LIST OF TABLES

Table 10-11: Basic Control System Problems Without Error Codes (Symptom: C).....	128
Table 10-12: Basic Control System Problems Without Error Codes (Symptom: D)	129
Table 10-13: Basic Control System Problems Without Error Codes (Symptom: E).....	129
Table 10-14: Servo Clutch Problems Without Error Codes (Symptom: A).....	130
Table 10-15: Servo Clutch Problems Without Error Codes (Symptom: B).....	130
Table 10-16: Servo Clutch Problems Without Error Codes (Symptom: C).....	130
Table 10-17: Equal Throttle Synchronization (Symptom: A)	131
Table 10-18: Servo Clutch Troubleshooting (Symptom: A).....	131
Table 10-19: Servo Clutch Troubleshooting (Symptom: B).....	132
Table 10-20: Servo Clutch Troubleshooting (Symptom: C).....	132
Table 10-21: Servo Clutch Troubleshooting (Symptom: D)	132
Table 10-22: Active Synchronization (Symptom: A)	133
Table 10-23: Active Synchronization (Symptom: B)	133
Table 10-24: Servo Throttle Troubleshooting (Symptom: A).....	134
Table 10-25: Servo Clutch Troubleshooting (Symptom: A).....	134
Table 10-26: Wire Harness - Serial Communication (p/n 13316-XX)	135
Table 10-27: Wire Harness - Serial Communication Multi-Screw (p/n 15544-XX).....	136
Table 10-28: Wire Harness - Serial Communication / CANtrak (p/n 70422-XX)	137
Table 10-29: Wire Harness - Tachometer Sensor Harness Pin-Out (p/n 13239-XX)	137
Table 10-30: Wire Harness- Clutch, Ahead, Astern, Troll Command, Troll On-Off (p/n 70390-XX)	138
Table 10-31: Wire Harness- Clutch, Ahead, Astern, ZFF Transmission (p/n 70673-XX)	139
Table 10-32: Power, Start Interlock Harness Pin-Out (p/n 13756-XX)	139
Table 10-33: Wire Harness - Power, SI & Clutch Pressure Switch (p/n 13552-XX).....	140
Table 10-34: Wire Harness - Power, SI, Clutch Pressure Switch & Alarm (p/n 13631-XX).....	140
Table 10-35: Wire Harness- Power Use W/existing St Intlk Only (p/n 15023-XX)	141
Table 10-36: Wire Harness - Control Head One Connector (p/n 13557-XX).....	141
Table 10-37: Wire Harness - Control Head Two Connectors (p/n 14261-XX).....	142
Table 10-38: Power, Start Interlock, Clutch Oil Pressure Switch, and Alarm Pigtail Pin-Out (p/n 15710-XX)	143
Table 10-39: Wire Harness - Serial Com, Processor Lead (p/n 15705-XX)	144
Table 10-40: Wire Harness - Control Head, Processor Lead (p/n 15706-XX)	144
Table 10-41: Wire Harness - Throttle, Processor Lead (p/n 15703-XX)	145
Table 10-42: Wire Harness - Solenoid Clutches, Processor Lead (p/n 15701-XX)	145
Table 10-43: Wire Harness - Mag Pickup, Processor Lead (p/n 15704-XX).....	146

MMC-280 Revision List	149
MMC-329 Revision List	155
ENG-127-1: Revision List.....	225

Preface



IMPORTANT: Keep this manual in a safe place for future reference. It contains essential information about the installation and operation of the ZF Marine Electronics control system for your vessel.

MicroCommander Processor List

The processors for the systems listed below have software which includes several featured options. Information about these options is contained in this manual, along with all standard instructions for 9000 series Processors. All vessels with MicroCommander Processors will not necessarily use all the featured options. Decide on their utility based upon your application.

Below is an example of the 9000 Series Part Numbering system. This is just a guide, there are more options available than shown below.

9000 Series Part Numbering / Identification Guide													
			Part Number										
			90010	91000	91102	91202	91212	92000	92102	92112	92212	95232	96232
Engine / Throttle	None	0	X										
	Mechanical	1		X	X	X	X						
	Electrical	2						X	X	X	X		
	Premium Mechanical	5										X	
	Premium Electrical	6											X
Gear / Clutch	None	0	X	X				X					
	Mechanical	1			X				X	X			
	Solenoid	2				X	X				X	X	X
	Mechanical Gear / Solenoid 2 Speed	3											
	Solenoid Gear / Solenoid 2 Speed	4											
Troll	None	0		X	X	X		X	X				
	Mechanical	1	X				X			X			
	Solenoid	2											
	Autotroll	3										X	X
	Mechanical Governed Troll	5											
	Solenoid Governed Troll	6											





For example a 91102 is a MicroCommander Processor with Mechanical Engine, Mechanical Clutch, No Troll and 2 stations. Each number in the part number signifies a different quality of the processor that fits your needs. The last number in each Processor part number is the number of stations that are being used.

Available Options for the Processors Covered in this Manual




- Dynamic Positioning Interface
- Station 4 / Joystick Interface
- CANtrak Display
- Engine Room/Remote Switch (Station 1 only)
- Station 2 Lockout
- Speed Boost – Loaded w/Software
- Fixed Neutral Delay – Loaded w/Software

Conventional Symbols Used in the Manual

Throughout this manual special attention should be paid to the following symbols.

	WARNING: Personal Injury may result if this message is disregarded.
	CAUTION: Damage to equipment may occur if this message is disregarded.
	IMPORTANT: Contains essential Information about a topic.
	NOTE: Contains noteworthy information that may help to clarify a topic.

Important Information

	WARNING: Personal Injury could occur if the following steps are not followed exactly.
	CAUTION: On Control Systems with more than one Processor, ZF Marine Electronics highly recommends that ALL UNITS utilize the same software revision for each Processor.
	CAUTION: Electro-static discharge can damage this equipment. Personnel working on this equipment must be grounded to the chassis with an Anti-static Wrist Strap.



CAUTION: Disconnect the Power from the Processor whenever welding is being done on the vessel. Failure to do so can cause permanent damage to the Processor.



CAUTION: This equipment is designed to work with other ZF Marine Electronics designed equipment. DO NOT operate this equipment with any other manufacturers equipment unless approved so in writing by ZF Marine Electronics Engineering Department.

Optional Features Information



WARNING: If the Dynamic Positioning (DP) Interface option is being used, it is the operator’s responsibility to operate the vessel per the DP system manufacturer’s requirements. Please call your ZF Marine Electronics representative for any questions with any installation/operational questions prior to Sea Trials.



WARNING: If the DP/JS Interface option is being used, it is the operator’s responsibility to operate the vessel per the DP system manufacturer’s requirements. Please call your ZF Marine Electronics representative for any questions with any installation/operational questions prior to Sea Trials.



CAUTION: The DP pigtail **MUST NOT** be used to connect any other device such as a remote station Control Head. Failure to meet this requirement will nullify the Processor warranty, cause an unsafe operating condition and/or damage the Processor.



CAUTION: If the DP option is being utilized with a multi-screw application, **ALL Processors MUST HAVE** the DP pigtail connected to the DP System. Failure to comply with this requirement could cause an unsafe operating condition with possible severe personal injury and/or property damage.



CAUTION: If the DP option with Troll is being utilized with a multi-screw application, the Dynamic Positioning System is responsible for any transmission damage that may occur due to Trolling with one screw and operating with the clutch fully engaged on another screw (i.e., “dragging” a screw through the water).



CAUTION: Misapplication of the Speed Boost feature can damage the transmission or other equipment. Before using Speed Boost, the transmission representative must be consulted about its use, and any limitations on clutch engagement as a function of engine speed. The person(s) implementing Speed Boost have the responsibility for ensuring it is properly adjusted and for any damage that might occur.

How to Use the Manual

This manual is written describing all possible options available for this processor. Your vessel may not require all of these options. Refer only to the sections that apply to your vessel. If you wish to use one of the available options listed, please contact a technician from ZF Marine Electronics' Sales & Service Organization (SSO). For more information on an SSO in your area, please refer the the Sales and Service information appendix.



NOTE: ZF Marine Electronics is not liable for any damage incurred if these notices are not followed exactly.

Revision List

Rev	Date	Revision Description
A	11/03	Preface-1 added last paragraph regarding hard-wiring per ELR 1099. Figure 4-3: Twin Screw Serial Harness Connections revised per ELR 1099 to 5 amperes. Figure 8-1: External Alarm Harness Example and Figure 8-2: External Alarm Hard-Wired Example revised per ELR 1099 to 0.5 amperes. CAUTION revised to 0.5 amperes and 100 volts.
B	04/04	Revised to new modular style.
C	02/05	Revised Company Name to "ZF Marine Electronics, LLC" Updated all forms to current levels. Corrected Cross-Referencing. Added Language cross-referencing.
D	08/06	Revising to current modular and formatting. Removed Battery Maintenance. Added Engine Stop Switch Warning to Operation Section Corrected Push-Pull Cable Instruction Revised Control Head Pigtail Connections Updated Appendix A Forms
D.1	04/08	Reviewed and Replaced all external documents with current revision level
D.2	01/09	Reviewed and Replaced all external documents with current revision level
D.3	04/09	Reviewed and Replaced all external documents with current revision level
D.4	09/09	Reviewed and Replaced all external documents with current revision level
D.5	03/11	Updated Software number, Revised preface per ELR00113, updated all external documents with current revision level
D.6	04/12	Revised per ELR00157 and ELR00174

1 Introduction

This manual is written to document every possible system option. Your system may not include every available option for single or multi-screw reverse reduction gear applications. Only those sections that apply to your specific installation are relevant to your vessel.

If additional options described within this manual are desired, contact your dealer for availability/compatibility with your system.

1.1 Basic Theory of Operation

The MicroCommander Marine Propulsion Control System (hereafter referred to as MicroCommander or System) is designed for pleasure and light commercial marine vessels that require remote control of mechanically actuated engines and reverse reduction gears.

The System is electronic and requires a 12 or 24 VDC power supply, one Processor per engine/gear and one Control Head per remote station.

The MicroCommander commands the vessel's throttle and shift using a single Control Head lever.

The Processor is typically mounted in the engine room area and is connected mechanically to the vessel's main engine throttle and transmission with standard 33C type push-pull cables.

One wire harness/electric cable per Control Head lever connects the remote station(s) to the Processor(s). Only one remote station will have command at a given time and the Station-in-Command is indicated by a red light located on the Control Head. Station transfer is accomplished by pressing the Control Head mounted transfer button.

1.1.1 9110X Processor (Throttle - Servo, Shift - Servo, X = Number of Remote Station Pigtails)

The System is designed for pleasure and light commercial marine vessels that require remote control of:

- servo engine governors
- servo activated clutches

1.2 System Features

1.2.1 Standard Features

Further information regarding the following features can be found in section 2: Operation.

- Sequencing of Clutch and Engine Speed.
- Station-in-Command indication.
- Up to five Remote Stations.
- Command of up to five screws.
- Single Control Head lever command of speed and direction.
- Start Interlock.
- Push Button Station Transfer.
- Proportional (Reversal) Pause on through Neutral Shifts.
- Warm-up Mode.
- High/Low Idle Selection.
- One Lever Mode.
- Engine Synchronization.

Further information regarding the following features can be found in section 5: Set Up Procedures.

- Easily configured to a vessel's control requirements.
- Push Button Set Up.
- Pluggable Connections.

Further information regarding the following feature can be found in section 10.5: Diagnostic Menu.

- Visual system diagnostics, set up, and status indication.

Further information regarding the following feature can be found in section 10.6: Audible Tones.

- Audible system diagnostics and status indications.

1.2.2 Optional Processor Features

Further information regarding each optional feature can be found in section 2.16: Optional Features.

- System failure external alarm contact.
- Clutch pressure interlock.
- Multiple Screw Installations.
- Station Expander (SE).
- 9001 Trolling Valve Control

2 Operation

2.1 DC Power On

When DC power is turned ON to the Processor:

- A short steady tone, followed by an intermittent tone, will sound at all Remote Stations indicating that no station has command.
- The Start Interlock relay contact will remain open, preventing engine start.
- Throttle:
Servo: The throttle servo will drive to Idle.
- Shift:
Servo: The Shift servo will drive to Neutral.

2.2 Taking Command

The Processor has zero (0) to five (5) Remote Station Pigtail connectors available for pluggable Remote Station Control Head connection. If more Remote Stations are required, refer to section 8.3: Station Expander (SE).

To take command at any one of the Remote Stations:

- Ensure all Control Head's lever(s) at the Station are in the Neutral detent (vertical position).




Figure 2-1: Station taking Command

- Depress the transfer button for 1/2 second.

The Slow Repetitive tone will stop at all Stations, and the red LED indicator light will turn ON at the Control Head of the Station that had assumed command of the Control System.



NOTE: If Start Interlock is used: Once a Station is in command the Start Interlock relay contact will close, allowing the engine to start.



NOTE: Only one Station can have command at a time.

The Operator is now in control of the vessel's propulsion system.



WARNING: An Engine STOP Switch **MUST** be installed at every remote operating station. Refer to CFR 46, Section 62.35-5 (US Coast Guard) and ABYC P-24.5.8.

2.3 Basic Operation

2.3.1 Normal Operating Mode

- A The Control Head has three detents; Ahead, Astern and Neutral.
- B With the Control Head lever positioned in the Neutral (vertical) detent, the Processor will command Neutral and the throttle at Idle revolutions per minute (RPM).
- C Movement of the Control Head's lever 15 degrees to the Ahead or Astern detent will command Ahead or Astern clutch engagement, while the engine RPM remains at Idle.




Figure 2-2: Control Head Detents

- D Further movement of the Control Head lever through the next 65 degrees, will increase the engine RPM in proportion to the Control Head's lever position.

2.4 Start Interlock

The engine start signal is blocked unless all of the following are true:

- DC power has been turned ON to the Control System.
- A Remote Station is in command.
- The Control System is commanding Neutral.

2.5 Station Transfer



WARNING: Personal Injury could occur if the following steps are not followed exactly.

Command can be transferred as follows:

- A The Station-in-Command's lever(s) may be left in any position.
- B Place the Control Head's lever(s) of the receiving Station in the Neutral/Idle detent position (refer to Figure 2-3: Remote Stations Before Transfer of Command)




Figure 2-3: Remote Stations Before Transfer of Command

Figure 2-4: Remote Station Transfer after Transfer of Command

- C At the Station taking command (Receiving Station), depress and hold the transfer button for 1/2 second (refer to Figure 2-4: Remote Station Transfer after Transfer of Command).
 - The red LED indicator light at the receiving Station's Control Head will illuminate, indicating that the Station has taken command.
 - The red LED indicator light will go OFF at the transferring Station's Control Head, indicating that the Station no longer is in command.
- D The commanded positions of the Throttle and Clutch will remain unchanged for one second after the red LED lights. This allows the operator time to move the Control Head's lever(s) to a position approximately matching the last Station, which will allow the vessel to maintain present speed and direction.

2.6 Proportional Pause

The proportional pause provides a means of safely reversing the vessel's direction. A variable pause is introduced into the clutch command signal to allow time for the engine RPM's to drop to Idle and for the vessel's speed through the water to slow. This pause is set during section 7: Sea Trials.

2.7 Warm-up Mode (Throttle Only Mode)



WARNING: Personal Injury could occur if the following steps are not followed exactly.

This feature allows the operator to increase the engine's RPM, while the Clutch remains in Neutral. Warm-Up Mode is operational only when the Control Head lever is moved in the Ahead direction.

The system is placed into Warm-Up Mode as follows:

- A At the Station-in-Command, ensure that the Control Head's lever is in the Neutral detent position (refer to the following Figure).
- B Depress and hold the transfer button.
- C After one second, move the Control Head's lever to the Ahead detent, while continuing to hold the transfer button.




Figure 2-5: Control Head Warm-Up Mode

- D Now release the transfer button.
 - The red LED indicator light will blink slowly, indicating Warm-Up Mode is activated and the Clutch has remained at Neutral.
- E The operator now can start the engine, if required, and increase the RPM through the entire throttle range by moving the Control Head's lever forward through the next 65 degrees.
- F When the Control Head's lever is returned to the Neutral detent, the red LED will discontinue blinking and remain lit steady. After one second in Neutral, the Processor will automatically reset to normal operation with full control of the clutches and engine.




Figure 2-6: Control Head Normal Operating Mode

- G The next movement of the Control Head's lever will engage the Ahead or Astern clutch (Normal Operation).

2.8 High/Low Idle

The Control System provides the input to the engine, so that it may run at the standard Idle speed (typically adjusted at the governor or carburetor), or it can provide a second elevated Idle speed.

2.8.1 Low Idle

- The factory default setting is for Low Idle Only.
- When the System is initially powered-up, it will always command Low Idle, even when High Idle is selected.

2.8.2 High Idle

- If High Idle is desired, it may be programmed during Dock Trials.
- High Idle is programmable up to a maximum setting of 20% of Full Throttle.
- High Idle is automatically selected when in Warm-Up Mode.
- Selecting Between High and Low Idle



WARNING: Personal Injury could occur if the following steps are not followed exactly.

Refer to the following Figure when selecting between Low and High Idle (or vice versa) at the Station-in-Command.

- A The Control Head's lever(s) may be in the Neutral, Ahead or Astern detents when making a selection.




Figure 2-7: High/Low Idle Mode Selection

- B Depress and hold the transfer button for 1/2 second and then release.
- If the System was in Low Idle it will toggle to High Idle, and vice versa.
- C To return to the previous Idle setting, depress and hold the transfer button again for 1/2 second and then release.



NOTE: In Multiple Screw applications: Always program all the Processors for the same amount of High Idle. All Processors will be in High or Low Idle at the same time.

2.9 One Lever Mode



NOTE: This mode is not available for Single Screw Applications



NOTE: One Lever Operation may be used in Troll Mode or in Non-Troll Mode.



NOTE: The Green LED will always be lit while in One Lever Operation, no matter which position the Master Control Head lever is in.

The system supports a mode of operation referred to as One Lever Mode.

One Lever Mode allows the operator to control two (2) to five (5) engines and transmissions with a single Control Head lever. Any of the Control Head levers at any Remote Station can be designated by the operator as the **Master lever**.

The designation can be changed by the operator at any time. Most of the features (synchronization, troll, etc.) available in normal operation are available while operating in One Lever Mode.

- The Processor defaults to One Lever Mode disabled.
- One Lever Mode can be disabled or enabled as discussed in section 5: Set Up Procedures.
- When One Lever Mode is enabled, the operation must be turned ON and OFF as described below.



WARNING: Personal Injury could occur if the following steps are not followed exactly.

2.9.1 Turning ON One Lever Operation




Figure 2-8: (Step A) One Lever Operation Mode




Figure 2-9: (Step B) One Lever Operation Mode

- A At the Station-in-Command, move all the Control Head levers to the Ahead detent.
- B Depress and **Hold** the transfer button **while** moving one of the Control Head levers forward, out of the Ahead detent. **Do Not Release the Transfer Button** until the green LED turns ON, indicating One Lever Operation is now active.
- The Control Head lever which the operator chose to move out of the Ahead detent, becomes the **Master lever**.
 - The Control Head lever which was left in the Ahead detent is now inactive.



NOTE: The Control Head lever(s) designated by the operator to be inactive in One Lever Operation, may be left in the Ahead detent or moved fully forward. Moving the lever fully forward is recommended, because it moves it out of the way and prevents accidental bumps while operating.

2.9.2 Turning OFF One Lever Operation



WARNING: It is strongly recommended that the Master lever be returned to the Neutral/Idle position prior to turning OFF One Lever Operation. Do not attempt to transfer command from one Remote Station to another while in One Lever Operation. Always turn One Lever Operation OFF prior to transferring. Failure to observe these recommendations may result in a sudden change in the vessel's direction.

- A Place the **Master lever** into the Neutral detent.
- B Place all inactive Control Head levers into the Neutral detent.
- Whenever an inactive lever(s) is moved to the Neutral detent, One Lever Operation is turned OFF and all levers are active.
 - In applications with three or more screws, the green LED will turn OFF when any inactive Control Head lever is returned to the Neutral detent. For each inactive lever that is NOT at Neutral detent, its red LED will be blinking.

2.10 Engine Synchronization

This Feature is not available for Single Screw Applications.



NOTE: The Control System offers two (2) types of synchronization, Active or Equal Throttle.

Synchronization is automatic and only operates when the Ahead clutch is engaged, consequently it can be left ON full time.

When synchronization has been selected during set up, the Control System will always power-up with synchronization ON.

In order for synchronization to become active (work toward synchronizing the engines' RPM's) the Synchronization Criteria listed below must be met.

2.10.1 Criteria

Synchronization Criteria is met when all of the following are true:

- Both Control Heads must be commanding 5% or greater of the throttle range.
- The Control Head levers must be within 10% of one another (+/- approximately 6 degrees).
- Both Control Head levers are commanding Ahead clutch engagement.



NOTE: The use of Value 03 for Function Code E7 should be avoided in the 9000 Series Processors with mechanical throttle control.

SYMPTOM:

- When selected, Value 03 (Active Synchronization, no Synch if Tach signal lost) for Function Code E7 (Synchronization) may give the operator the appearance that synchronization is not functioning. This is due to the fact that the Control Head's green Synch indication LED does not light until both engine RPM's are within the "Active Synch Deadband". "Active Synch Deadband" is the maximum allowable difference in engine RPM where the Processors consider the system synchronized adequately. Once the allowable difference is obtained, the control system does not attempt to match the RPM's any closer.
- When in this Mode of Operation, there is no indication to the operator that the Control Head levers are matched close enough to start the synchronization process. Additionally, the green indication LED does not blink while working toward synchronization.

CAUSE:

- Function Code E7, Value 03, is operating as designed. Due to the imprecise positioning of mechanical push-pull cables, the ability to position the cables within the "Active Synch Deadband" is severely impaired.

SOLUTION:

All Processors with mechanical throttle control, where synchronization is desired, must set the Value of Function Code E7 to Value 01 (Active Synchronization reverts to Equal Throttle Synchronization if Tach Signal is lost)

2.10.2 Types

The following types of synchronization use the same criteria, indications, and are turned ON and OFF as described in following Sections.

2.10.2.1 Equal Throttle Servo Synchronization (default)

Equal Throttle synchronization simply positions the throttle push-pull cables to the same distance when the criteria has been met. With Equal Throttle Synchronization the Processors do not receive tachometer signals representative of the engines RPM's.



CAUTION: The Control System will remain synchronized as long as the Control Head's levers are in close proximity to one another. If a lever is moved to a point where the 10% throttle window is exceeded, a 10% increase or decrease in engine RPM would occur with one engine, resulting in a sudden change in the vessel's direction.



NOTE: In order for Equal Throttle Synchronization to work properly in Systems with mechanical Throttles, the bends in the push-pull cables must be kept to a minimum. There can be no back-lash in the linkage or cables. Both Governors or Carburetors must provide equal engine RPM with equal movement of their selector levers. If these conditions cannot be met, Active Synchronization is recommended.

2.10.2.2 Active

Active Synchronization must be enabled during Set Up and a Tachometer Sensor Wire Harness must be used.

The Processors each receive a tachometer signal representing engine RPM from their respective engines. These signals are compared with one another over a serial communication line. If the Synchronization Criteria is met, the throttle command signal of the engine(s) running at the higher RPM is lowered, until the RPM's of all engines match.

2.10.3 Indications

The green LED located on the Control Head indicates the status of synchronization.

- When the green LED is lit **steady**, the engines are synchronized.
- When the green LED is **not lit**, the engines are not synchronized and the Control System is not attempting to do so.
- In Active Synchronization the green LED **blinks** every time there is a change in the commanded throttle.

2.10.4 Turning OFF/ON when Criteria is Met

2.10.4.1 Turning OFF:

When the Criteria is met, synchronization is automatic and does not need to be turned ON. If the operator elects to turn OFF synchronization, follow the steps below:

- Ensure that the Control Head's levers are positioned to a point where Synchronization Criteria are met.
- At the Station-in-Command, press and hold the transfer button until the green LED **blinks twice** and then goes out (approximately 2 seconds).
- Synchronization is now OFF.

2.10.4.2 Turning ON:

Synchronization is automatic and does not need to be turned ON, unless previously turned OFF, as described in the previous Section.

- Ensure that the Control Head's levers are positioned to a point where Synchronization Criteria are met.
- At the Station-in-Command, press and hold the transfer button until the green LED **lights** (approximately 2 seconds).
 - The green LED will blink as the system is working toward synchronization.

- The green LED will become solid when the engines are synchronized.

2.10.5 Turning ON/OFF when Criteria is Not Met

The actual synchronizing of the engines occurs when the Control Head levers are within the 10% (approximately 6 degrees) window of one another. However, synchronization can be turned ON or OFF when the Control Head levers are apart more than the 10%.

At the Station-in-Command, press and hold the transfer button for at least two seconds:

- If synchronization is being turned ON, the green LED will light after two seconds and stay lighted as long as the transfer button is depressed. When transfer button is released the LED will go out.
- If synchronization is being turned OFF, after two seconds, the green LED will blink twice and then stay off.

2.11 Control Systems' Configurability

The Processor is designed in a way which allows it to be easily configured by the installer to meet the varying needs of a wide variety of vessels. Below you will find a list and a brief description of the groups of these functions.

2.11.1 Processor Functions

A0 Processor Identification - Assigns each Processor in multi screw applications a unique identifying number. **This function must be the second function set during Multi Screw Set Up.**

A1 Number of Engines - Lets the Processor know how many other Processors need to be communicated with. **This function must be the FIRST FUNCTION SET during Multi Screw Set Up.**

A2 One Lever Operation - Allows the installer to disable or enable One Lever Mode capability.

A3 Station Expander - Allows the Processor to communicate with the Station Expander (SE), which provides additional Remote Stations. **Contact the factory if this feature is required.**

A4 Neutral Indication Tone - When enabled, produces a short 200 Hz tone to indicate Neutral.

Detailed information on each Function is found in section 5: Set Up Procedures.

2.11.2 Throttle Functions

2.11.2.1 Basic Throttle Functions

E1 Throttle in Neutral - Adjusts the Throttle when in Neutral, independent of the throttle output when the clutch is engaged.

E5 Throttle Pause following Shift - Allows the adjustment of time between clutch engagement command and when throttle begins to increase above Idle.

E6 High Idle - Programs a second/elevated Idle RPM.

E7 Synchronization - Allows the installer to select synchronization and select the type of synchronization.

2.11.2.2 Servo Throttle Functions

This section along with section 2.11.2.1: Basic Throttle Functions allows the adjustment of the Servo Throttle:

E0 Throttle Servo Direction - Selects whether the Throttle Servo pushes or pulls to increase speed.

E2 Throttle Minimum - Once set mechanically at the Idle stop, this Function Code allows the position of the push-pull cable to be adjusted electrically in order to eliminate "dead lever". Dead lever in this case can be described as a movement of the Control Head lever without a change in the engine's RPM.

E3 Throttle Maximum - Adjusts the position or amount of travel of the push-pull cable at Full Throttle.

E4 Throttle Maximum Astern - Limits the amount of the Astern Throttle Servo movement.

2.11.3 Clutch Functions

2.11.3.1 Basic Clutch Functions

The following functions are available for all types of clutches.

C0 Clutch Pressure Interlock - Selects the Clutch Oil Pressure Interlock option. The interlock prevents a throttle signal above Idle from being applied unless adequate clutch pressure is available.

C1 Clutch Interlock Delay - Determines when the Clutch Oil Pressure Interlock becomes active.

C2 Proportional (Reversal) Pause - Selects between an In-Gear, Neutral, or Fixed Neutral delay.

C3 Proportional (Reversal) Pause Time - Selects the maximum delay time during a full speed reversal.

C4 Proportional (Reversal) Pause Ratio - Determines if the Ahead and Astern reversal times are the same or if Astern is 1/2 of Ahead time.

Detail information on each function is found in section 5: Set Up Procedures.

2.11.3.2 Servo Clutch Functions

This section along with the section 2.11.2.1: Basic Throttle Functions allows the adjustment of Clutch servo related items:

C5 Clutch Servo Direction - Determines if the servo pushes or pulls for Ahead and Astern.

C6 Clutch Ahead - Adjusts the amount of clutch servo travel in Ahead.

C7 Clutch Astern - Adjusts the amount of clutch servo travel in Astern.

2.11.4 Troll Functions (Optional)

Refer to the 9001 Troll Actuator Manual (p/n MM9001) for detailed information on the Troll Functions and their operation.

2.11.5 Troubleshooting Functions

2.11.5.1 Basic Troubleshooting Functions

H0 Diagnostics - Allows the installer/technician to look at various inputs to the Processor.

H1 Return to Factory Defaults - Returns all settings to the factory default values.

Detail information on each function is found in section 10.5: Diagnostic Menu.

2.12 Audible Tones

Detailed information on the following tones are in section 10.6: Audible Tones.

2.12.1 Basic Processor Tones

The Processor can produce numerous tones which inform the operator of the status of the system or if any faults were to occur. These tones are emitted from all Remote Stations regardless of whether they are in command or not.

2.12.1.1 Slow Repetitive Tone

This tone is normal when DC power is first applied to the System. This tone indicates that system initialization has occurred, no Remote Station has command, the operator can accept command at any Remote Station.

2.12.1.2 One Long, Three Short Tones

This tone indicates that the command signal from the Station-in- Command has gone out of the acceptable range.

2.12.1.3 Steady Tone

This tone indicates that the software program within the Processor has quit running, due to low voltage or component failure.

2.12.1.4 Five (5) Second Steady Tone

This tone indicates that there has been a loss of Serial Communication.

2.12.1.5 Three (3) Second Steady Tone

This tone is heard if there is a stuck transfer button, or when entering Back-up Mode, or if a Troll Solenoid error occurs. (Back-up Mode and Troll Solenoid is not available for all Processors.)

2.12.1.6 Five Seconds On, Five Seconds Off - High Repetitive Rate Tone

This tone indicates a loss of communication with the Station Expander.

2.12.2 Throttle (Servo 2) Tones

The following Tones are in addition to the Basic Processor Tones. Detailed information on each tone is in section 10.6: Audible Tones.

2.12.2.1 One Long - Two Short Tones

This tone indicates that the feedback potentiometer signal from Servo 2 (Throttle) has gone out of range.

2.12.2.2 One Long, Two Short - High Repetitive Tone

This tone indicates that Servo 2 (Throttle) cannot reach the commanded position. This tone is also referred to as Servo 2 Jam Tone.

2.12.3 Clutch (Servo 1) Tones

2.12.3.1 One Long - One Short Tone

This tone indicates that the feedback potentiometer signal from Servo 1 (Clutch) has gone out of range.

2.12.3.2 One Long, One Short -High Repetitive Rate Tone

This tone indicates that Servo 1 (Clutch) cannot reach the commanded position. This tone is also referred to as Servo 1 Jam Tone.

2.12.4 9001 Trolling Actuator Tones (Servo 3)

Detailed information is found in the MM9001 Troll Actuator Manual.

2.12.4.1 One Long, Four Short Tones

This tone indicates that there is a feedback error in the Trolling Actuator.

2.12.4.2 One Long, Four Short - High Repetitive Rate Tone

This tone indicates that Trolling Actuator Servo cannot reach the commanded position

2.13 Push Button Set Up

There are four (4) push buttons mounted to the Processor's circuit board. These push buttons allow the installer/technician access to all of the Functions required for programming and troubleshooting the control system.

A full description of their usage is provided in section 5: Set Up Procedures.

2.14 Visual System Diagnostics, Set Up And Status Indication

There are four (4), seven (7) segment LED's (hereafter referred to as the Display LED) mounted to the Processor's circuit board. The Display LED is visible through a transparent window in the Processor's cover. The information displayed is used in conjunction with the push buttons to program the Processor. The Display LED also displays Error Codes in the event that an anomaly is detected.


For a full description of the Display LED, its capability and usage, refer to section 5: Set Up Procedures.

2.15 Pluggable Connections

2.15.1 Processor Pigtails

The Processors come from the factory with enclosure mounted pigtail connectors for easy, mistake-free installations.

Refer to Figure 2-10: Processor Connections View for pigtail/servo locations:



DWG: 15588.1_ART

Figure 2-10: Processor Connections View

Table 2-1: Processor Pigtail List

FIGURE ID	QTY	DESCRIPTION
A	1	Pigtail connector is provided for serial communication between multiple Processors.
C	1	Pigtail connector is provided for the Tachometer Sensor input used in multi screw Active Synchronization.
D	0 - 5	Pigtail connector provides the connections for Remote Station Control Heads..
E	0	No Pigtail - SERVO 1 entry point.
F	0	No Pigtail - SERVO 2 entry point.
G	1	Pigtail connector provides the connections for DC Power, Start Interlock, (optional) Clutch Oil Pressure Interlock and (optional) External Alarm contact.

2.16 Optional Features

2.16.1 External Alarm Capability

- This optional feature is designed to provide a status signal to an external visual or audible alarm circuit.
- The status signal is in the form of an OPEN or CLOSED relay contact. When the contact is CLOSED, the Processor is functioning normally. When the contact OPENS, this indicates the software program has quit running due to a component failure or loss of DC power.
- A full explanation is provided in section 8: Control Options.

2.16.2 Clutch Pressure Interlock

- The purpose of the Clutch Pressure Interlock is to prevent high engine RPM when the Clutch is not fully engaged.
- A full explanation is provided in section 8: Control Options.

2.16.3 Multiple Screw Installations

This Manual, as written, is intended for Single and Twin Screw applications only.

The Processor has the capability of controlling Triple, Quad and Quint Screw vessels.

If this option is going to be used, please contact a ZF Marine Electronics Representative for further information.

2.16.4 Station Expander (SE)

- The SE is a separate Processor housed in an enclosure that allows the connection of up to five additional Remote Control Stations.
- The SE communicates with the Processor over the serial communication line.
- A full explanation of the installation, operation and adjustment of the SE is provided in the Installation Manual provided with the SE.

If this option is going to be used, please contact a ZF Marine Electronics Representative for further information.

2.16.5 9001 Mechanically Actuated Trolling Valve Control

- The purpose of a Trolling Valve is to lower the Clutch pressure, which allows the Clutch Plate to slip.
- A full explanation is provided in the Installation Manual provided with the 9001 Trolling Actuator.

3 Plan The Installation



NOTE: ZF Marine Electronics recommends that the system be installed in accordance with ABYC, E-11 and P24.

3.1 System Requirements

The first step when installing a System is to carefully plan the installation. This includes finding proper mounting locations for the Processor(s) and Control Heads. The decision must be made on where power is going to be sourced and how the power will be routed to the Processor(s).




Figure 3-1: Processor Dimensions

Once the locations have been decided, lengths of electrical wiring, harnesses and push-pull cables must be determined.

- Grounding (Bonding) is required for maximum electromagnetic compatibility (EMC) performance. Refer to MMC-287 Grounding (Bonding).
- SERVO PROCESSORS: Locate the Processor such that the push-pull cables have the shortest, most direct path to the selector lever. The push-pull cable length should not exceed 20 feet (6,0m), the bend radius should not be less than 10 inches (254mm) and the total degrees of bends must be less than 270 degrees.

Only when the locations and lengths of wiring/harnesses have been determined, should you start the actual installation. The following sections describe the requirements for installing the components and selecting mounting locations.

3.1.1 Processor(s)

Processors required per engine:

- Single Screw: One (1) Processor
- Twin Screw: Two (2) Processors

Mounting Hardware is installer supplied.

Installation/Troubleshooting Manual is included with the Processor.

The following items must be taken into account when selecting the location for the Processor(s):

- The Processor is spray proof, but not water proof. Therefore, an area must be selected that typically stays dry.
- The engine room is the preferred location for mounting the Processor. If the engine room is too small, locate in any area where it is easily accessible, as long as all of the criteria listed are met.
- Bulkhead mounting is the preferred method due to ease of access for wiring and adjustments. However, the Processor can be mounted in any attitude as long as the Display LED window and push buttons are accessible.
- Locate the Processor(s) away from sources of high heat, such as engine exhaust manifolds or turbochargers. Allow 4 feet (1,2m) of clearance or more.
- Do not mount the Processor on the engine, transmission, or in any location that will subject it to excessive vibration.
- Do not mount the Processor to the transom when the vessel is equipped with a surface piercing drive system (due to vibration concerns).
- Do not mount the Processor(s) in close proximity to gas engine ignition systems, alternators, generators or any equipment producing strong magnetic fields. Allow 4 feet (1,2m) clearance or more.



CAUTION: Strong magnetic fields can influence the Processor's electronic circuits and void your warranty.

3.1.2 Control Head(s)

Refer to section 11: Appendix A - System Components and Specifications for information on the various Control Heads available and their dimensions.

- Control Heads are available with pluggable pigtails or may be hard-wired (no pigtails).
- Retrofit applications may require an Adapter Pad to cover the old Control Head cutout. A variety of Adapters and Cover Pads are available. If an Adapter/Cover Pad is required, please contact a ZF Marine Electronics Representative for further information.
- Ensure that the clearance is sufficient for the Control Head's lever to reach full Ahead and full Astern.
- The 400 and MC2000 Series Control Heads are spray proof from the top, but must be protected from the weather on the underside.
- When a 400 or MC2000 Series Control Head must be mounted in a location where the underside may be exposed to the weather, consider using a Weather Mount Enclosure. Refer to the MMC-279 400 Series Weather Mount Enclosure for specific information.
- The 700 Series Control Heads are fully water proof.

3.2 Wire Harnesses

For further information regarding Wire Harness requirements, contact a ZF Marine Electronics Representative. The following lists the various Harnesses that plug into the Processor:

3.2.1 Control Head Harnesses

- One Control Head Harness is required for every Control Head lever at every Remote Station.
- The Control Head Harnesses are available in various lengths.
- Harnesses are available with plugs on both ends or a plug on the Processor end only.

- The Harness from the Port side of a Control Head is always routed to the Port Processor.
- The Harness from the Starboard side of a Control Head is always routed to the Starboard Processor.

3.2.2 Power, Start Interlock, (optional) Clutch Pressure, (optional) Alarm Harness

- One Harness required per Processor Power, Start Interlock, Clutch Pressure Switch, Alarm Pigtail.
- The Harness is plugged at the Processor Pigtail end only.
- In addition to the required DC power and Start Interlock, the Harness has options for Clutch Oil Pressure Switch and External Alarm Circuit that are available.
- All of the cables in the Harness are the same length, therefore, order a length that will reach all of the previously mentioned items, if required.
- The Harness is available in lengths up to 30 feet (9,14m) for 12 VDC systems, and up to 60 feet (18,2m) for 24 VDC systems.

3.2.3 Serial Communication Harness

The Serial Communication Harness is only required in:

- Multi Screw applications

The Harness interconnects the Processors to each other. A plug is attached at both ends of the Serial Harness.

Twin Screw:

One (1) Serial Harness (part no. 13316-X)

3.2.4 Additional Harnesses

Not all of the following harnesses may be required for your application. For further information regarding Wire Harness requirements, contact a ZF Marine Electronics Representative. The following lists the additional Harnesses available that plug into the Processor:

3.2.4.1 Tach Sensor Harness

One Harness per Processor is required. The Harness is plugged on one end only. There are two types of Tach Sensor Harnesses available:

1. An AC Coupled Sensor Harness, which is designed for inputs from items such as Mechanical Senders, Magnetic Pickup Sensors, the Alternator AC Stator Terminal or the negative Coil Terminal.
2. A Harness designed for Active Sensors with an Open Collector output, such as Hall Effect Sensors.

This Harness is only required when Active Synchronization is required.

Determine the source of the tachometer signal, which can be provided by a mechanical tachometer sender, magnetic pickup, alternator's pre-rectified output, the negative side of the coil (gasoline engine) or an engine's electronically produced signal. Refer to SER-161 Engine Tach Sender Req.

3.3 Electric Cables

For further information regarding Electric Cable requirements, contact a ZF Marine Electronics Representative. The installation may use Harnesses, Electric Cables, or a combination of both. Electric cable may be ordered from ZF Marine Electronics, or the cable **MUST** meet the following specifications. The following lists the various equivalent electric cables:

3.3.1 Control Head Cable Requirements

- Seven-conductor with shield, twisted.
- Color Code – black, brown, red, orange, green, blue, and violet.
- 18 AWG (nearest metric equivalent - #1).
- 300V, 105 degrees C, UL VW1, stranded tinned copper wire.
- Maximum outside diameter: 0.390 inch (9,9mm)

3.3.2 Power, Start Interlock, (optional) Clutch Pressure, (optional) Alarm Cable Requirements

3.3.2.1 Power Cable

- Two-conductor, black and red with violet stripe, twisted.
- 14 AWG (#2,5 metric) or 12 AWG (#4 metric) may be used to crimp directly to the Processor terminals. Refer to S-214 Automatic Power Selector Model: 13505 for cable length and additional wire size requirements.
- 300V, 105 degrees C, UL VW1, stranded tinned copper wire.
- Maximum outside diameter: 0.390 inch (9,9mm).

3.3.2.2 Start Interlock Cable

- Two-conductor, both yellow with red stripe, twisted.
- 16 AWG (#1,5 metric).
- 300V, 105 degrees C, UL VW1, stranded tinned copper wire.
- Maximum outside diameter: 0.390 inch (9,9mm).

3.3.2.3 (optional) Clutch Pressure Interlock Cable

- Two-conductor, both light blue.
- 16 AWG (#1,5 metric).
- 300V, 105 degrees C, UL VW1, stranded tinned copper wire.
- Maximum outside diameter: 0.390 inch (9,9mm).

3.3.2.4 (optional) External Alarm Circuit Cable

- Two-conductor, red and black, twisted.
- 16 AWG (#1,5 metric).
- 300V, 105 degrees C, UL VW1, stranded tinned copper wire.
- Maximum outside diameter: 0.390 inch (9,9mm).

3.3.3 Serial Communication

It is strongly recommended that only ZF Marine Electronics factory manufactured Harnesses are installed.

3.3.4 (optional) Tach Sensor Cable Requirements

The cable selected depends on what type of Sensor is being used:

3.3.4.1 AC Tach Input

- Two-conductor, twisted, shielded.
- 20 AWG (#0,5 metric)
- 300 V, 165 C, UL VW1, stranded tinned copper
- Maximum outside diameter: 0.390 inches (9,9mm)

3.3.4.2 Open Collector (Active)

- Three-conductor, twisted, shielded
- 20 AWG (#0,5 metric)
- 300 V, 165 C, UL VW1, stranded tinned copper
- Maximum outside diameter: 0.390 inches (9,9mm)

3.4 Tachometer Sensors (optional)

There are two types of Tachometer Sensors available through ZF Marine Electronics, Mechanical (p/n 8902) and Magnetic Pickup (p/n 8912). Both types provide two separate outputs, one for the tachometer(s) and the second output provides the Processor's tachometer signal requirement. If a sensor other than one supplied by ZF Marine Electronics is used, it must meet the criteria provided below for each type:

3.4.1 AC Coupled Sensors

- The signal must have a minimum amplitude of +/- 1.5 V (3.0 V P-P).
- The signal's maximum amplitude must not exceed +/- 100 V (200 V P-P).
- The frequency of the signal must be no lower than 30 Hz at Idle.
- The signal's frequency may not exceed 8 KHz at Full Throttle.

3.4.2 Alternator

- The pre-rectified stator AC terminal may be used as the tach source.
- The signal is inputted to the AC Coupled Sensor input.
- The signal must meet the same criteria as any AC Coupled Sensor Signal (refer to section 3.4.1: AC Coupled Sensors).

3.4.3 Point side of the Coil

- When the signal is sourced from the coil or an electronically produced tach signal (used on some gasoline engines) the signal is connected to the AC Coupled Sensor input.
- The signal must meet the same criteria as any AC Coupled Sensor Signal (refer to section 3.4.1: AC Coupled Sensors).

3.4.4 Active Sensors (Open Collector Output)

- The sink current ability of the Sensor may be no lower than 2 mA.
- The operational current may not exceed 50 mA.
- The Sensor must have a maximum saturation voltage of 0.8 V.
- An operational voltage requirement of 9- 10 VDC.
- A minimum frequency of 5 Hz at Idle.
- A maximum frequency of 8 KHz at Full Throttle.

3.5 Installer Supplied Tools And Parts

3.5.1 Required Tools

- Anti-static wrist strap (included with Processor).
- Screwdriver – medium Phillips, #2.
- Wire cutter, stripper & crimper (Thomas & Betts model WT-2000 or equivalent).
- 7/16 inch Nut Driver or Socket with ratchet & medium extension.
- 5/16 inch Wrench – open end.

- Screwdriver – small straight slot.
- Saw with blade suitable for Console Top Panel.
- Drill Motor with 9/32 inch and 7/32 inch drill bits.

3.5.2 Optional Tools

- Calibrated Digital Multimeter (Fluke 80 Series or equivalent).
- Service Field Test Unit (P/N 13927, available through ZF Marine Electronics)
- Field Test Control Head - Dual (P/N 14000)

3.5.3 Required Parts for Servo Processor's

- 33C type push-pull cables. The cables are measured from the end of the threads to the end of the threads. Available in 1 foot (0,3m) increments. (If 43C type push-pull cables are required, a 43C Conversion Kit is available from ZF Marine Electronics. Refer to MMC-345 43C Cable Conversion Kit.)
- Many engines, transmissions and inboard/outboard (I/O) drives are delivered with mounting kits. If not, contact the engine/gear dealer/manufacturer for a factory Cable Connection Kit. Refer to MMC-290 Universal Mounting Kit, to show other connection options.

3.5.4 Engine Stop Switch

An engine STOP switch MUST be located at each Remote Station. The Installer supplies the switches. Refer to the installation instructions supplied with the switch and the engine installation instructions for manufacturers recommendations.



WARNING: An Engine STOP Switch MUST be installed at every remote operating station. Refer to CFR 46, Section 62.35-5 (US Coast Guard) and ABYC P-24.5.8.

3.6 DC Power Source

One of the most important (and often overlooked) items for proper operation of your control system is a clean, dedicated, and reliable source of DC Power.

The wiring used to supply power from the power source (battery) through the various components (fuses, distribution panel, relays, etc.) to the Processors must be sized for a voltage drop of 10% or less using 10 amps as the maximum current draw. Refer to **ABYC** Standard E-11, Table X to determine the appropriate wire gauge for the necessary conductor length.

When using ZF Marine Electronics supplied 14 gauge power cable, and in accordance with **ABYC** Standard E-11, the distance from a 12 volt power source (battery or DC Distribution Panel) shall not exceed 30 feet (9,1m). In 24 volt systems, the maximum cable length is 60 feet (18,2m).

ZF Marine Electronics highly recommends using an Automatic Power Selector (APS) and a second power source (battery) to supply power to each Processor. Refer to S-214 Automatic Power Selector Model: 13505 for examples of power supplies.

- The Processor requires a battery source of 12 or 24 VDC.
- Two 5 ampere (when isolated power supplies are required) or one 10 ampere trip-free thermal circuit breaker(s) with manual ON/OFF actuation
- The use of an APS (Automatic Power Selector) is strongly recommended.
- Power should come from the vessel's DC Distribution Panel.

- The cables feeding power from the battery to the Processor must be sized large enough to keep voltage drop, due to current flow, below 10%. Reference S-214 Automatic Power Selector Model: 13505.

Contact a ZF Marine Electronics representative for the Processor's power cable(s) maximum lengths. Refer to S-214 Automatic Power Selector Model: 13505 for examples of the various wiring options. Ultimately, it is the boat builder or installer's responsibility to ensure that the vessel's wiring meets the requirements of American Boating & Yachting Council standard E-11, for AC and DC Electrical Systems on Boats.

4 Installation



NOTE: Before starting the actual installation of the Control System, make sure you have the correct parts and tools on hand. Refer to section 3: Plan The Installation. Read ALL the instructions pertinent to each part before beginning the installation of the part.



CAUTION: Static electricity can destroy electronic components. Connect the wrist strap provided, to the Processor frame whenever working on the Processor with the enclosure cover open. This will drain any static charge you may have on your person.

4.1 Processor

- A Secure the Processor to the mounting surface with three 1/4 inch or M6 fasteners, leaving the fourth fastener unused at this time.
- B Connect the Processor to the Hull or Grounding Bus by running a 12 AWG or larger wire between the Processor's fourth mounting fastener and the Grounding Bus. (The Processor is bonded if mounted directly to a metallic surface that is connected to a metal hull) (Refer to MMC-287 Grounding (Bonding))

4.2 Control Head(s)

4.2.1 400, MC2000 and 700 Series Control Heads

Refer to the appropriate Control Head Dimensions and Variations Service Sheet in section 11: Appendix A - System Components and Specifications for installation.

4.2.2 500 Series Control Heads

Refer to the Installation Manual supplied with the 500 Series Control Head Assembly for installation instructions.

4.2.3 Handheld Remote Controls

Refer to the Installation Manual supplied with the Handheld Remote for installation instructions.

4.3 Wire Harness Installation

The 9000 Premium Processor is supplied with various Pigtails with connectors depending on the Processor being supplied. Harnesses required will depend on the actual Processor used.

Four different styles of plugs and connectors are utilized but are inserted in an identical fashion as follows:

4.3.1 Harness Plug Insertion and Extraction

- A Prior to inserting the Harness plug, pay close attention to the number of pins and the keying of the plug. The plug is designed to be inserted one way only into the connector, but can be incorrectly forced together in the opposite orientation.

When connecting the plugs, ensure that the locking mechanisms are depressed and held until the plug is fully connected or disconnected.




Figure 4-1: Harness Plug Keying

4.3.2 Power/Start Interlock/(optional) Alarm/(optional) Clutch Pressure Harness

This Harness can have a minimum of two (2) cables (DC Power and Start Interlock) up to a maximum of four (4) cables (Power, Start Interlock and/or Clutch Pressure Interlock and External Alarm Circuit).


4.3.2.1 DC Power Cable

(Refer to S-214 Automatic Power Selector Model: 13505)

- A Insert the Harness's black, twelve pin plug into the Processor's Power/Start Interlock Pigtail connector.
- B Run the cable to the DC Distribution Panel or the optional Power Relay.
- C Strip back the appropriate amount of PVC jacketing and conductor insulation.
- D Crimp the appropriate connectors to the conductors.
- E Terminate the conductors to the DC Power Source.

4.3.2.2 Start Interlock Cable

- A Run the cable to the Engine's Starter Solenoid.
- B Disconnect the Starter Switch wire from the Solenoid.
- C Strip back the appropriate amount of PVC jacketing and conductor insulation.
- D Connect one of the conductors to the Solenoid's Starter Switch terminal.
- E Butt splice the second wire to Starter Switch wire.



DWG: 13248A

Figure 4-2: Start Interlock Connections

4.3.2.3 External Alarm Circuit Cable (optional)

Refer to section 8: Control Options, for installation information.

4.3.2.4 Clutch Pressure Switch Cable (optional)

Refer to section 8: Control Options, for installation information.

4.3.3 Serial Communication Harness (Multi Screw)

Not required for Single Screw applications.

4.3.3.1 Twin Screw Applications

- A At the Processors, remove the watertight seals from the Serial pigtail connectors.
- B At the Port Processor, insert the Serial harness's grey, six (6) pin plug into the Serial pigtail connector.
- C Run the harness to the Starboard Processor.
- D Insert the harness's grey, six (6) pin plug into the Starboard Processor's Serial pigtail connector.
- E Secure the Serial Harness at least every 18 in. (45,72 cm).




Figure 4-3: Twin Screw Serial Harness Connections

4.3.4 Control Head Harnesses

The procedure for terminating the Harness at the Remote Station depends on what Control Head is selected (pluggable or hard-wired).

- **Pluggable:** Follow Procedure 1.
- **Hard-wired:** Follow Procedure 2.



NOTE: Multi Screw Applications: Control Heads must be connected to the same numbered Station Pigtail or Circuit Board Station Terminal on ALL Processors.

4.3.4.1 Procedure 1: Harness with a Plug on Both Ends

- A At the Port Processor, insert the harness's grey, eight (8) pin plug into the Station 1 pigtail connector.
- B Run the cable to the Port side of the Control Head located at Station 1.
- C Insert the harness's grey, eight (8) pin plug into the Control Head's Port pigtail connector.

- D Ensure that the cable has a strain relief close to the Control Head to relieve the strain on the connections.
- E Repeat Steps A) thru D) on all Remote Station 1 Control Head pigtails.
- F Repeat Steps A) thru E) for all required Stations (i.e. 2, 3, 4, 5).

If Stations without pigtails are required to be installed, follow the steps in section 4.4: Hard-Wired Cable.

4.3.4.2 Procedure 2: Harness with a Plug on Processor End only

- A At the Port Processor, insert the harness's grey, eight (8) pin plug into the Station 1 pigtail connector.
- B Run the cable to the Port side of the Control Head located at Station 1.
- C Connect the conductors to the Control Head as described in the appropriate Control Head Dimensions and Variations Service Sheet in section 11: Appendix A - System Components and Specifications.
- D Provide a strain relief in close proximity to the Control Head's terminal block.
- E Repeat Steps A) thru D) for all Remote Station 1 Control Heads.
- F Repeat Steps A) thru E) for all required Stations (i.e. 2, 3, 4, 5).

If Stations without Processor pigtails are required to be installed, follow the steps in section 4.4: Hard-Wired Cable.

4.3.5 Tach Sensor Harness (optional)

(required for Active Synchronization)

- A On all Processors, remove the watertight seals from the Tach Sender pigtail connectors.
- B Insert the harness's grey, four pin plug into the Tach Sender pigtail connector at each Processor.
- C Run the Tach Sensor Harness cables to the Tach signal source for each engine.
- D Connect the conductors to the Tach source in the appropriate manner, keeping in mind that some sources are polarity sensitive. **(black wire - negative, red wire - positive)**

4.4 Hard-Wired Cable

4.4.1 Liquid Tight (Watertight) Connector

All cables that enter the Enclosure must go through a Liquid Tight Connector in order to maintain the moisture resistant integrity of the Processor. These connectors must be assembled as shown in Figure 4-4: Liquid Tight (Watertight) Connector Installation





Figure 4-4: Liquid Tight (Watertight) Connector Installation

4.4.2 Processor Enclosure Cable Holes


When hard-wiring a Processor or installing additional Station pigtails, the cables must enter the enclosure through Liquid Tight Connectors in the appropriate holes.

1. Station No.5
2. Station No.3
3. Station No.1
4. Alarm, Clutch Pressure, and Start Interlock
5. DC Power
6. Station No.4
7. Station No.2
8. Not Used
9. Not Used
10. Serial Communication
11. Not Used
12. Tachometer (optional)
13. Not Used



DWG: 12282.1_ART

Figure 4-5: Processor Enclosure Cable Holes



DWG: 15585.1_ART

Figure 4-6: Processor Circuit Board Termination Points

Table 4-1: Circuit Board Hard wire Termination Table

Hole # (Refer to Figure 4-5: Processor Enclosure Cable Holes)	Description and Terminal (Refer to Figure 4-6: Processor Circuit Board Termination Points)	Wire Cable Connections (Refer to Figure 4-6: Processor Circuit Board Termination Points)			
		Pin No.	Cable Color		
1.	Station 5: TB5	1 2 3 4 6 7 8	Black Brown Red Orange Green Blue Violet		
2.	Station 3: TB3				
3.	Station 1: TB1				
6.	Station 4: TB4				
7.	Station 2: TB2				
4.	Alarm: TB6			6 5	Brown Black
	Clutch Pressure: TB6			4 3	Green Blue
	Start Interlock: PB2	1 2	Red Yellow		
	Ground: TB6	2	Orange		
	Backup Input: TB6	1	White		
5.	Power In: PB1	Negative Positive	Black Red		
10.	Serial Communication: TB7	6 7 8 9 10	White Green Red Black Drain		
12.	Tachometer: TB9	1 2 4	Red Green Black		

4.4.3 Hard-wire Installation

4.4.3.1 Seven-Conductor Control Head Cable (Locations 1, 2, 3, 6, and 7)

- A Run the seven-conductor cable from the Remote Station to the Processor.
- B Support the cables using clamps or straps not more than 18 inches (0,5m) apart if not contained in a conduit. Verify cable location protects the cable from physical damage.
- C Label each seven-conductor cable at both ends with the Station Number it connects, and Port or Starboard.
- D Place on your wrist the anti-static wrist strap provided, attach the strap to ground, and then remove the cover from the Processor.
- E Run the seven-conductor cable for each remote station through the corresponding liquid tight cable grip on the Processor to the appropriate Station terminal block. Do not tighten cable grip at this time.
- F Strip the PVC jacket and shielding back approximately 4-1/2 inches (114,3mm) on the seven-conductor cable.
- G Strip the wire 3/8 inch (9,5mm) on each lead.
- H Pull the Shield wire back against the PVC jacket.

- I Slide and shrink a piece of 3/8 inch W. X 1 inch L. heat-shrink over the cable as shown in Figure 4-7: Seven-Conductor Control Head Cable Shield Wire and Heat-Shrink.




Figure 4-7: Seven-Conductor Control Head Cable Shield Wire and Heat-Shrink

- J Secure the seven-conductor cable to the frame using a conductive Clamp. Ensure that the Clamp and Shield wire come in contact with one another. Refer to Figure 4-8: Clamp Views.




Figure 4-8: Clamp Views

- K Clip the Shield wire so that it is flush with the Clamp.
- L Connect the conductors to the appropriate pins as shown on Table 4-2: Connections for Remote Stations, using a small slotted screwdriver as shown in Figure 4-9: Terminal Strip Cable Connections




Figure 4-9: Terminal Strip Cable Connections

- M Connect the other station's seven-conductor cables to the appropriate station terminal strips in the same way.

Table 4-2: Connections for Remote Stations

(Refer to section 11: Appendix A - System Components and Specifications)

Circuit Board Termination	Conductor Color	Left Hand (Port) Control Head Lever	Right Hand (Stbd) Control Head Lever
TB1-1 thru TB5-1	Black	Pin 1	Pin 1
TB1-2 thru TB5-2	Brown	Pin 2	Pin 2
TB1-3 thru TB5-3	Red	Pin 3	Pin 3
TB1-4 thru TB5-4	Orange	Pin 4	Pin 4

Table 4-2: Connections for Remote Stations

(Refer to section 11: Appendix A - System Components and Specifications)

Circuit Board Termination	Conductor Color	Left Hand (Port) Control Head Lever	Right Hand (Stbd) Control Head Lever
TB1-6 thru TB5-6	Green	Pin 6	Pin 6
TB1-7 thru TB5-7	Blue	Pin 5	Pin 7
TB1-8 thru TB5-8	Violet	N/C	Pin 8
		Jumper between Pins 3 and 7	Jumper between Pins 3 and 5

4.4.3.2 Start Interlock Cable (Location 4)

4.4.3.2.1 Connection at the Starter Solenoid

- A Run the length of two-conductor cable between the Engine's Starter Solenoid and the Processor.
- B Disconnect the Starter Switch wire from the Solenoid.
- C Strip back the appropriate amount of PVC jacketing and conductor insulation.
- D Connect one of the conductors to the Solenoid's Starter Switch terminal.
- E Butt splice the second wire to Starter Switch wire.

4.4.3.2.2 Connection at the Processor

- A Install a liquid tight connector into entry hole (No. 4).
- B Run enough of the two-conductor power cable through the liquid tight cable grip so that it can be routed to PB2 on the Circuit Board as shown in the Processor Circuit Board Termination Points Figure.
- C Strip back 2 inches (50,8mm) of the PVC jacketing. Refer to Figure 4-10: Two-Conductor Start Interlock Cable
- D Strip each wire 3/8-inch (9,5mm).
- E Place a 3/8 inch (9,5mm) section of shrink tubing over the cable and heat.




Figure 4-10: Two-Conductor Start Interlock Cable

- F Crimp fork or ring terminals to the wires.
- G Connect the two-conductor cable to PB2, red lead to the terminal labeled (1) and yellow lead to the terminal labeled (2), as indicated on Figure 4-6: Processor Circuit Board Termination Points.
- H Tie wrap the start interlock cable to the Processor's frame.

4.4.3.3 Power Cable (Location 5)

- A Run the length of two-conductor power cable between the DC Power Source and the Processor.
- B Make the connections at the vessel's DC Power Source, but do not turn power ON.

- C Install a liquid tight connector into the DC POWER entry hole.
- D Run enough of the two-conductor power cable through the liquid tight cable grip so that it can be routed as shown in Processor Circuit board Termination Points Figure.
- E Strip back 3 inches (76,2mm) of the PVC jacketing. Refer to Figure 4-11: Two-Conductor Power Cable
- F Strip each wire 3/8-inch (9,5mm).
- G Place a 3/8 inch (9,5mm) section of shrink tubing over the cable and heat.




Figure 4-11: Two-Conductor Power Cable

- H Crimp fork or ring terminals to the wires.
- I Connect the two-conductor cable to PB1, red lead to the terminal labeled (+) and black lead to the terminal labeled (-), as indicated on Processor Circuit board Termination Points Figure.
- J Tie wrap the power cable to the Processor's frame.

4.4.3.4 Serial Communication Cable (Location 10)

- A Install 1/2 inch (12,7mm) liquid tight cable grips into appropriate hole of the Port and Starboard Processors.
- B Run a four-conductor, shielded cable from the Port to the Starboard Processors.
- C Strip back 3 inches (76,2mm) of PVC jacketing from both ends of the cable.
- D Strip each wire 3/8 inch (9,5mm).
- E Clip the drain wire flush with the PVC jacketing on the Starboard Processor only.
- F Place a 1 inch (25,4mm) section of shrink tubing over each end of the cable
- G On the Port end of the cable, bend the drain wire back and tuck it under the shrink tubing so that the drain wire end is exposed past the shrink tubing. (Refer to Figure 4-12: Four-Conductor Serial Communication Cable)




Figure 4-12: Four-Conductor Serial Communication Cable

- H Shrink the Tubing with a heat gun.
- I Insert the four-conductor cable through the liquid tight connectors and tighten the nuts
- J Secure the cables internally using a Clamp. **Make certain that the drain wire makes contact with the Clamp's metallic surface.**
- K Clip the exposed drain wires flush with the Clamps.
- L Connect the conductors to the terminal block as listed in Table 4-3: Processor Circuit Board Connections for Serial Communication Cable.

Table 4-3: Processor Circuit Board Connections for Serial Communication Cable

Conductor Color	Port Processor Termination A	Starboard Processor Termination B
White	TB7-6	TB7-6
Green	TB7-7	TB7-7
Red	TB7-8	TB7-8
Black	TB7-9	TB7-9
Silver (Drain Wire)	Clamp	No Connection

4.4.3.5 Tachometer Cable (Location 12)

- A Run a two-conductor (AC Type) or three-conductor (Open) shielded cable from the Port Processor to the Port engine's tachometer source. (Refer to section 3: Plan The Installation)



NOTE: Three-conductor cable is required with Open Collector Type (Hall Effect) Tachometer Senders only.

- B Run a two- or three-conductor shielded cable from the Starboard Processor to the Starboard engine's tachometer source.
- C Install a 1/2 inch (12,7mm) liquid tight cable grip into the appropriate hole of the Port and Starboard Processors.
- D Strip back 2 inches (50,8mm) of PVC jacketing from both ends of the cable.
- E Strip the ends of each conductor back 3/8 inch (9,5mm).
- Tachometer source side only: Clip off the drain wire flush with the PVC jacketing.
- F Place a 1 inch (25,4mm) section of shrink tubing over each end of the cable.
- Processor side: Bend the drain wire back and tuck it under the shrink tubing so that the drain wire end is exposed past the shrink tubing. (Refer to Figure 4-13: AC Type Tachometer Cable and Figure 4-14: Open Collector Tachometer Cable).




Figure 4-13: AC Type Tachometer Cable




Figure 4-14: Open Collector Tachometer Cable

- G Shrink the tubing with a heat gun.
- H Insert the cable ends through the liquid tight connectors and tighten the nuts.
- I Secure the cables internally using a Clamp. Make certain that the drain wire makes contact with the Clamp's metallic surface.
- J Clip the exposed drain wires flush with the Clamps.
- K Connect the conductors to the terminal block as listed in Table 4-4: Processor Circuit Board Connections for Tachometer.

Table 4-4: Processor Circuit Board Connections for Tachometer

Conduct or Color	Processor Termination	Description	Notes
Red	TB9-1	Sensor Supply (+9VDC)	Required when Open Collector (i.e., Hall Effect Sensors) only
Green	TB9-2	AC Type Tachometer Input	The green wire connects here when AC Type Tach Sensors (i.e., Mechanical Senders, Magnetic Pickup, Alternator AC, etc.) are being used.
	TB9-3	Open Collector Tachometer Input	The green wire connects here when an Open Collector Type Tach Sender is used.
Black	TB9-4	Return for Tachometer Input	Negative connection for both types of Senders.
Silver	Clamp	Drain Wire (Shield) connection	Connection made at Processor side only.

4.5 Engine Stop Switches

An engine stop switch(s) must be located at all Remote Stations and capable of stopping the engine at any RPM. The Installer supplies the Stop Switches. Refer to the installation instruction supplied with the switch and the engine installation instructions for manufacturers recommendations.




WARNING: An Engine Stop Switch at each Remote Station is an absolute requirement. Refer to CFR 46, SEC. 62.35-5 and ABYC P-24.5.8.

4.6 Push-Pull Cable Connections

4.6.1 Processor


- A Remove the #10-32 jam nut and the two rubber seals from the end of each push-pull cable that is to connect to the Processor(s) only; discard the seals, but save the nuts.
- B Remove one screw from each Cable Anchor Clip and loosen the other screw. Swing the two Clips clear.



0658_ART

Figure 4-15: Processor Cable Clamp Rotation

- C Insert the appropriate push-pull cable into the Processor according to the labels located above the cable clips on the Processor enclosure.
- D When the push-pull cable end is visible within the Processor interior, reinstall the #10-32 jam nut.




12280_ART

Figure 4-16: Processor Push-Pull Cable Interior Connections

- E Connect the push-pull cables to the hex nuts (See Figure 4-16: Processor Push-Pull Cable Interior Connections). Use a 7/16 inch socket to turn the hex nut onto the cable rod end until there is approximately 5/16 inch (7,9mm) of thread showing beyond the jam nut.
- F Use a 7/16 inch socket wrench and a 5/16-inch open end wrench to tighten the jam nuts.
- G Position the Cable Anchor Clips to secure the cables to the Processor housing.
- H Install the screws removed in step B.
- I Tighten all Cable Anchor Clip screws.

4.6.2 Engine Throttle Selector Lever

- A Ensure that the Throttle push-pull cable and the engine's throttle lever are in close proximity to one another at Idle. If so, proceed to step C) and if not continue with step B).



12267.1_ART

Figure 4-17: Throttle Push-Pull Idle Orientation to Selector Lever


- B If the throttle lever is at the opposite side from the push-pull cable, change the Throttle Servo Direction **E0** as described in section 5: Set Up Procedures.
- C Adjust the ball joint on the Throttle cable to match the throttle lever at the Idle stop position.
- D Ensure that adequate cable threads are showing.
- E Tighten the jam nut.

4.6.3 Transmission Shift Selector Lever



CAUTION: Mis-adjusted Shift Push-Pull Cables can cause damage to the Transmission's Clutch Pack. Ensure adjustments are made correctly and completely.

- A Check the engine and transmission to see if the push-pull cable anchor brackets have been installed. If the brackets are not on the transmission, select from the MMC-289 Morse Clutch and Throttle Kit or fabricate brackets as shown in MMC-290 Universal Mounting Kit.
- B Turn power ON to the Control System, to ensure that Neutral/Idle is commanded.
- C With the Shift Push-Pull cable disconnected at the clutch selector lever, adjust the Shift cable's ball joint at the transmission to align with the clutch selector lever at Neutral. The push-pull cable must form a 90 degree angle to the clutch selector lever.
- D Connect the ball joint to the clutch selector lever.



12267.2_ART

Figure 4-18: Shift Push-Pull Cable Neutral Connection

5 Set Up Procedures

The Processor utilizes push buttons in conjunction with Display LED's to program, adjust, calibrate and set up the various features. The push buttons also allow you to access and display information regarding the health of the System.

The following paragraphs explain how to locate and use the push buttons and Display LEDs:

5.1 Processor Components Used In Set Up

- Each Processor has a Display LED and Push Buttons.
- The Display LED can be viewed through a window on the Processor's cover.



Figure 5-1: Typical Processor Cover

- The Processor enclosure cover must be removed to access the Push Buttons.
- The **Display LED** is used to view the Function Codes and the Values for those Functions.

- The Push Buttons are used to scroll through Function Codes, select Function Codes and set the Values of the Function Codes.)





Figure 5-2: Processor Shield Push Button and Display LED Locations

5.1.1 Processor Display LED

Starts the Processor Part Number again, one number at a time.



EXAMPLE: Running Actuator Part Number during Normal Operation (9210)

12309_ART

Figure 5-3: Display LED at Normal Operation

- The Processor’s Display LED has four 7-segment LED’s, which light up to show either letters or numbers.
- The Display LED will have the Processor Part Number showing in a running pattern during Normal operation (Figure 5-3: Display LED at Normal Operation)
- Parameter display:
 - The first two digit Display LED’s to the left, indicate the **Function Code**, which is alphanumeric.
 - The second two digit Display LED’s indicate the numeric **Value** that is programmed into the Processor for the Function Code displayed to the left.
 - A **decimal point** indicator is located on the bottom right corner of each Display LED.




Figure 5-4: Decimal Point indicators

5.1.2 Push Buttons

The Processor has four Push Buttons located on the Circuit Board. They are identified by the words LEFT, RIGHT, UP and DOWN silk-screened on the Shield covering the Circuit Board.




Figure 5-5: Push Buttons

5.1.2.1 Up and Down Push Buttons

Pressing the Up or Down Push Buttons once has the following functions:

- Stops Normal Operation Display (running Processor Part Number) and activates the Function Menu.
- While in the Function Menu, scrolls through the Function Codes one at a time.
- When an Error Code is displayed, scrolls through the error messages one at a time. (Refer to section 10.8: Error Codes)
- When in Set Up Mode, increases (Up) or decreases (Down) the Value one digit at a time.

5.1.2.2 Left and Right Push Buttons

Pressing and holding the Left and Right Push Buttons simultaneously has the following functions:

- Activates Set Up Mode as indicated by the blinking Display LED. (must hold the buttons until the blinking begins)
- While in Set Up Mode, deactivates Set Up Mode, saves the displayed Value to memory and returns to the Function Menu. (must hold the button until the blinking stops)

5.1.2.3 Left Push Button Only

Pressing the Left Push Button once has the following functions:

- Deactivates Set Up Mode without any changes to the Value being stored to memory. The Left Push Button must be held down until function code stops blinking. The default value will then be displayed.
- While in Function Menu, changes the Display LED to the Error Menu, if any errors are present. (has no effect if there are no errors stored)
- While in the Error Menu, changes the Display LED back to the Function Menu.




Figure 5-6: Display Error Menu Example

5.1.2.4 Right Push Button Only

Pressing the Right Push Button once has the following functions:

- While in the Error Menu, clears inactive errors. (Active errors blink, inactive do not)

- While in Set Up Mode or Function Menu, allows the Value of the current Function Code to be displayed with all four Display LEDs.




Figure 5-7: Display Four (4) Digit Value

5.2 Activating Set Up Mode



NOTE: To Escape from the Set Up procedure at any time without saving the changed value to memory, depress the Left Push Button. The Function Code will stop flashing and the Function will be saved with the original Value.

- The Display LED is in Normal operating condition with the red running Processor Part Number.
- Depressing either the Up or Down Push Button will activate the Function Menu.
- Depressing the Up or Down Push Button will scroll through the Function Codes one at a time.
- Once the desired Function Code is visible on the Display LED, press and hold down the Left and Right Push Buttons simultaneously, until the Function Code begins to blink.
- Depressing the Up Push Button will increase the Value of the Function, while pressing the Down Push Button will decrease the Value of the Function. (Pressing and holding the Up or Down Push Button will increase or decrease the Value rapidly)

5.3 Storing Values To Memory

Once the desired Value has been reached in Set Up Mode, the Value is stored to memory as follows:

- Depress and hold the right push button first. Then while still depressing the right button, depress and hold the Left push button until the Function Code stops blinking.
 - The new Value is now programmed into memory.
 - Set Up Mode is exited.
- Depress the Up or Down Push Button until the next required Function Code is reached.
- Reactivate Set Up Mode.



NOTE: If no Push Buttons are pressed for five (5) minutes, the selected Mode of operation is automatically exited and the System returns to Normal Operating Mode.
If no Push Buttons are pressed for five (5) minutes while in Set Up Mode, it will be exited without the changes stored to memory

5.4 Function Codes and Values

The following tables list the Function Codes' Name, Default Value and Range or available Options. **Each of the Function Codes are explained in further detail in the following sections.**



NOTE: SINGLE SCREW APPLICATIONS: The Function Values may be entered and stored in any order.
MULTI SCREW APPLICATIONS: The A1 Function must be set FIRST, and the A0 Function must be set SECOND. If ZF Hurth Gears with two (2) proportional solenoids are used, the L1 Function must be the THIRD function set. The rest of the Function Values may be entered and stored in any order.
Once these parameters are set, either cycle power to the Processors or wait five (5) minutes, before continuing set up.

Table 5-1: Processor Function Codes


Function Code	Function Name	Default Value	Value Range or Options
A0	Processor Identification	01	01, 02, 03, 04, 05
A1	Number of Engines	01	01, 02, 03, 04, 05
A2	One Lever Operation	00	00 - Disabled; 01 - Enabled
A3	Station Expander (SE)	00	00 - Disabled; 01 - Enabled
	WARNING: DO NOT ADJUST THE ABOVE FUNCTION! Leave at default Value set by the Factory. Contact a ZF Marine Electronics Authorized Technician if this Function requires adjustment.		
A4	Neutral Indication Tone	00	00 - No Tone 01 - Tone upon Control Head engaging Neutral 02 - Tone upon Transmission shifting to Neutral

Table 5-2: Throttle Servo Function Codes

Function Code	Function Name	Default Value	Value Range or Options
E0	Throttle Servo Direction	20	20 - Push (Extends) for Throttle Increase 21 - Pull (Retracts) for Throttle Increase
E1	Throttle in Neutral	00.0	00.0 to 25.0% of Throttle Range
E2	Throttle Minimum	00.0	00.0 to 20.0% Must be 10% or more below Throttle Maximum (E3).
E3	Throttle Maximum	33.0	10.0 to 100.0% of Maximum Throttle Allowable. Must be 10% or more above Throttle Minimum (E2)
E4	Throttle Maximum Astern	100.0	00.0 to 100.0% of Throttle Maximum (E3)
E5	Throttle Pause Following Shift	00.5	00.0 to 05.0 Seconds
E6	High Idle	00.0	00.0 to 20.0% of Throttle Range.
E7	Synchronization	00	00 - Equal Throttle (Open Loop) Synchronization 01 - Active (Closed Loop) Synchronization (reverts to Equal if Tach Signal lost) 02 - No Synchronization 03 - Active (Closed Loop) Synchronization (no synchronization if Tach Signal is lost)

Table 5-3: Solenoid Clutch Function Codes

Function Code	Function Name	Default Value	Value Range or Options
C0	Clutch Pressure Interlock	00	00 - Not Installed; 01 - Installed 02 - Throttle Clutch Pressure Interlock Mode
C1	Clutch Interlock Delay	00.5	00.5 to 10.0 Seconds
C2	Proportional (Reversal) Pause	00	00 - In-Gear; 01 - Neutral; 02 - Fixed Neutral Delay Enabled (NOTE: If C2 is set to 02, the setting of C3 will set Fixed Neutral Delay C8.)
C3	Proportional (Reversal) Pause Time	04	00 to 99 Seconds
C4	Proportional (Reversal) Pause Ratio	00	00 - 2:1 Ahead to Astern vs. Astern to Ahead 01 - 1:1 Ahead to Astern vs. Astern to Ahead

Table 5-3: Solenoid Clutch Function Codes

Function Code	Function Name	Default Value	Value Range or Options
C5	Clutch Servo Direction	20	20 - Pull [Retracts for Ahead 21 - Push [Extends] for Ahead
C6	Clutch Ahead	80	00-100% of Maximum Ahead Travel from Neutral.
C7	Clutch Astern	80	00-100% of Maximum Astern Travel from Neutral.
C8	Fixed Neutral Delay	00.0	This feature is not available, do not change default value.

Table 5-4: Trolling Valve Function Codes

Function Code	Function Name	Default Value	Value Range or Options
L0	Troll Enable and Control Head Troll Lever Range	00	00 – No Troll 01 – 20 Degrees- Type 1 02 – 35 Degrees- Type 2 03 – 45 Degrees- Type 3 (Throttle limited to 75% of Throttle Range) 04 – 55 Degrees- Type 4 (Throttle limited to 10% of Throttle Range)
Troll Functions are only available and displayed when a P/N 9001 Troll Actuator is connected to the Processor. Refer to MM9001 Manual for Functions.			

Table 5-5: Solenoid Clutch Function Codes

Function Code	Function Name	Default Value	Value Range or Options
H0	Diagnostic	00	Input Voltage (+/- 0.5VDC) Tachometer Sensor Frequency Lever A/D, Stations 1, 2, 3, 4, & 5 Servo 1 & 2 A/D Feedback Transfer Button, Stations 1, 2, 3, 4, & 5 Software Revision Level
H1	Erase EPROM	00	Store to Return to Factory Defaults; (For Authorized Personnel Only)

5.5 System Programming and Adjustments



NOTE: SINGLE SCREW APPLICATIONS: The Function Values may be entered and stored in any order. **TWIN SCREW APPLICATIONS:** The A1 Function must be set FIRST, and the A0 Function must be set SECOND. The rest of the Function Values may be entered and stored in any order.



NOTE: Power must be turned ON to the Processors when programming or making any adjustments to the System.



NOTE: In order to prevent nuisance alarms when first setting up a System, some Function Codes take up to 5 minutes to become ACTIVE. The Functions affected by this are the functions that rely on Serial Communication, such as A0, A1, A2, A3, E7, and L0. Cycling power OFF, then ON, expedites these features making the Functions available immediately.

5.5.1 Processor Functions

5.5.1.1 Function Code A0 – Processor Identification



NOTE: In twin screw or more applications, the Value of Function Code A0 must be changed AFTER the Value in Function Code A1 has been changed to 02 or higher on ALL Processors.

In applications where there is more than one screw, the system must know which Processor is where. Every Processor must have its **OWN UNIQUE** identifying number. At NO time can two or more Processors be identified by the same Processor Identification Number.

The available Values for this Function are:

00 (Default Value), **01**, **02**, **03**, **04** and **05**.



NOTE: If Processors are not connected by a serial communication cable, leave the A0 Function Code at Default Value 00.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **A0**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.
- E Repeat on all Processors **BEFORE** proceeding to the next Function.




Figure 5-8: Display LED Function A0



NOTE: Before continuing set up, wait 5 minutes or cycle power.

5.5.1.2 Function Code A1 – Number of Engines



NOTE: If Processors are not connected by a serial communication cable, leave the A1 Function Code at Default Value 01.

The total number of engines must be entered into the memory of each of the Processors. All Processors in an installation must have the SAME VALUE entered.

The available Values for this Function are:

- 01** Single Screw (**Default Value**)
- 02** Twin Screw

03 Triple Screw (if required, contact a ZF Marine Technician.)

04 Quad Screw (if required, contact a ZF Marine Technician.)

05 Quint Screw (if required, contact a ZF Marine Technician.)



NOTE: Twin screw or more applications require Function Code A1 Value to be changed on ALL Processors prior to changing the Value of Function Code A0.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **A1**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.




Figure 5-9: Display LED Function A1

5.5.1.3 Function Code A2 – One Lever Operation

In Twin Screw or more applications, the System has the ability to command all engines and transmissions to the same speed and direction with a single Control Head lever. This Function allows this Feature to be enabled or disabled. (Refer to section 2: Operation, for operating instructions)

The available Values for this Function are:

00 Disabled (**Default Value**)

01 Enabled

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **A2**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.



Figure 5-10: Display LED Function A2

5.5.1.4 Function Code A3 – SE (Station Expander)



NOTE: This Manual does not go into detail on the Station Expander installation and adjustments. For further information on the Station Expander, refer to section 8: Control Options or contact your local ZF Marine Electronics Representative.

The SE is a separate unit, which gives the System the ability to increase the number of Remote Stations.

The available Values for this Function are:

00 Disabled (Default Value)

01 Enabled

Contact ZF Marine Electronics if this Function Code is going to be changed from the default setting.

5.5.1.5 Function Code A4 – Neutral Indication Tone

This Function allows the installer to turn ON a 1/2 second, low frequency tone to indicate Neutral.

The available Values for this Function are:

00 Disabled (Default Value)

01 Tone sounds when the Control Head’s lever reaches Neutral.

02 Tone sounds when the Processor commands the Transmission to Neutral.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **A4**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.




Figure 5-11: Display LED Function A4

5.5.2 (E) Throttle Functions

The following Throttle Functions are set up in section 6: Dock Trials:

Table 5-6: Throttle Functions Performed during Dock Trials

Code	Function Name
E1	Throttle in Neutral
E2	Throttle Minimum
E3	Throttle Maximum

Code	Function Name
E4	Throttle Maximum Astern
E5	Throttle Pause Following Shift
E6	High Idle

5.5.2.1 (E0) Throttle Servo Direction

This Function determines if the Push-Pull cable is fully extended or retracted when at Idle. The available Values for this Function are:

- **20** Fully Retracted at Idle, extends [Push] for Throttle increase (**Default Value**)
- **21** Fully Extended at Idle, retracts [Pull] for Throttle increase

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):




Figure 5-12: Throttle Push-Pull Cable Orientation




Figure 5-13: Display LED E0 - Servo

- A Ensure that the engine's Governor or Carburetor lever is at the Idle position.
 - If the Throttle Push-Pull cable's ball joint is close to the Throttle lever's position, no change is required to this Function Code.
 - If the Throttle Push-Pull cable's ball joint is at the opposite side of the lever's position, continue with the next step.
- B Scroll to Function Code **E0**.
- C Activate Set Up Mode.
- D Scroll Up or Down until Value **21** is displayed.
- E Store the Value to memory.
 - The Throttle Push-Pull cable's ball joint should drive to the Throttle lever's Idle position.
- F Do not connect the ball joint to the throttle lever at this time.

5.5.2.2 (E7) Synchronization

This Function Code selects the type of Synchronization, if Synchronization is required. The types are described in section 2: Operation .

The available Values for this Function are:

- **00** Equal Throttle (Open Loop)
- **01** Active (Closed Loop) (**reverts to Equal Throttle** if there is no Tachometer Sensor signal)
- **02** No Synchronization (**DEFAULT VALUE**)
- **03** Active (Closed Loop) (**reverts to no Synchronization** if there is no Tachometer Sensor signal)

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **E7**
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.

D Store the Value to memory.




Figure 5-14: Display LED E7

5.5.3 Basic Clutch Functions

The following Clutch Functions are set up in section 7: Sea Trials:

Table 5-7: Basic Clutch Functions Performed during Sea Trials

Code	Function Name	Code	Function Name
C2	Proportional (Reversal) Pause	C3	Proportional (Reversal) Pause Time

5.5.3.1 (C0) Clutch Pressure Interlock

IMPORTANT: This adjustment is to be set to Enabled only if the optional Clutch Pressure Switch is being used with this application.

This Function enables or disables the feature and allows for two different modes of behavior when a Clutch Pressure Switch is used. Refer to section 8: Control Options, for detailed information.

The available Values for this Function are:

- **00** Not Installed (**Default Value**)
- **01** Installed
- **02** Throttle Clutch Pressure Interlock Mode

NOTE: The C002 value is recommended in Gear Boxes that take longer than 10 seconds to reach operating pressure. Refer to section 8: Control Options for more information on the settings.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **C0**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.




Figure 5-15: Display LED C0

5.5.3.2 (C1) Clutch Interlock Delay



IMPORTANT: This adjustment is to be set to Enabled only if the optional Clutch Pressure Switch is being used with this application.

This Function works together with Function Code **C0**. Refer to section 8: Control Options, for further information.

The available Values are **00.5** to **10.0** seconds. The Default Value is **01.0** seconds.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **C1**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.




Figure 5-16: Display LED C1

5.5.3.3 (C4) Proportional (Reversal) Pause Ratio



NOTE: If you have any questions about which type of pause is best for your vessel, consult with a ZF Marine Electronics representative.

This Function Code selects whether the Proportional (Reversal) Pause Time is the same in Ahead and Astern or whether the time in Ahead is twice that in Astern.

Standard vessels with a bow and a stern typically select a pause which is twice as much in Ahead compared to Astern. This is because much more speed is obtainable in Ahead, than Astern. Consequently, more time is required to slow down from Ahead as compared to Astern.



NOTE: When the Controls are installed on a vessel such as a double ended Ferry or the Controls are being used to control a thruster, the proportional pause should be the same in Ahead as Astern or Port and Starboard in the case of a Thruster.

The available Values for this Function are:

00 - 2:1 Ratio (DEFAULT)

- This is the default setting and determines how the value set in the Proportional (Reversal) Pause Time **C3** Function is applied.
- The number of seconds selected is for an Ahead to Astern maneuver only. An Astern to Ahead maneuver will be one-half of the **C3** - Proportional (Reversal) Pause Time selected. This is the typical selection since most vessels do not reach the same throttle in Astern as they would in Ahead.

Therefore, the time required to get to a sufficient water speed for a safe reversal is significantly less.

01- 1:1 Ratio

- When this setting is selected, the value set in the Proportional (Reversal) Pause Time **C3** is the SAME for both Ahead to Astern, as with Astern to Ahead maneuvers.
- This may be selected when the vessel reaches the same water speed in both directions, as would be the case with a Double Ended Ferry. Another application where this option may be selected would be the control of a Bow or Stern Thruster.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- Scroll to Function Code **C4**.
- Activate Set Up Mode.
- Scroll Up or Down to the desired Value.
- Store the Value to memory.





Figure 5-17: Display LED C4

5.5.3.4 (C5) Clutch Servo Direction


This Function allows the Processor to be programmed to retract the Push-Pull cable for Ahead or extend for Ahead.

The available Values are:

- **20** Pull [Retracts] for Ahead (**Default**)
- **21** Push [Extends] for Ahead



DWG: 12267.11_ART



DWG: 12267.12_ART

Figure 5-18: Clutch Push-Pull Cable Orientation

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- Position the Clutch Selector Lever to the Ahead position.
- Move a Control Head lever into the Ahead detent.
- Check the Shift Push-Pull cable to see if it drove in the correct direction for Ahead.
 - If the cable drove in the correct direction, no change to this Function Code is required.
 - If the cable drove in the opposite direction, continue with the next step.
- Scroll to Function Code **C5**.
- Activate Set Up Mode.

- F Scroll Up to change the Value to **21**.
- G Store the Value to memory.




Figure 5-19: Display LED C5 - Servo

5.5.3.5 (C6) Servo Clutch Ahead Travel

This function adjusts the amount of Clutch push-pull cable travel in both the Ahead and the Astern directions.

The available Values are **00.0** to **100.0%** of the maximum available travel from Neutral to Ahead. The Default Value is **80%**.




Figure 5-20: Clutch Push-Pull Cable Ahead Position

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Move the Control Head lever to the Ahead detent.
- B Move the Clutch Selector Lever to the Ahead stop.
- C Does the cable's ball joint and lever align?
 - If yes, no further adjustment of this Function is required.
 - If no, continue with the next step.
- D Scroll to Function Code **C6**.
- E Activate Set Up Mode.
- F Scroll Up or Down until the ball joint and lever align perfectly.




Figure 5-21: Display LED C6 -Servo

- G Store the Value to memory.
- H Return the Control Head lever to the Neutral/Idle position.

5.5.3.6 (C7) Clutch Astern Travel (Servo)

This function is only required when the distance from Neutral to Astern differs from Neutral to Ahead.

This Function Code allows the independent adjustment of Astern travel. Otherwise, the Value selected in Function Code **C6** is automatically entered for Function Code **C7**.

The available Values are **00.0** to **100.0%** of the available travel from Neutral to Astern. The Default Value is **80%**.




Figure 5-22: Clutch Push-Pull Cable Astern Position

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Move the Control Head lever to the Astern detent.
- B Move the Clutch Selector Lever to the Astern stop.
- C Does the cable's ball joint and lever align?
 - If yes, no further adjustment of this Function is required.
 - If no, continue with the next step.
- D Scroll to Function Code **C7**.
- E Activate Set Up Mode.
- F Scroll Up or Down until the ball joint and Clutch Selector lever aligns perfectly.
- G Connect the ball joint to the Clutch Selector lever.




Figure 5-23: Display LED C7 - Servo

- H Store the Value to memory.
- I Return the Control Head lever to the Neutral/Idle position.

5.5.4 Troll Functions

A 9001 Troll Actuator is required to offer Trolling Valve Control. Refer to the 9001 Troll Manual (p/n MM9001) for Installation and Set Up of the Troll Functions.

6 Dock Trials



WARNING: It is imperative that the information provided in the previous Sections have been READ and FOLLOWED precisely, PRIOR to attempting a Dock Trial.



CAUTION: With I/O or Outboard applications, do not attempt to shift into or out of gear with engines stopped. This may cause a jam condition or damage to the linkage to some clutch configurations.



NOTE: On multiple screw applications, the following tests must be performed on all Processors. If any of the following tests fail, consult section 10: Troubleshooting.

6.1 Control Heads (Engines Stopped)

- A Turn power ON to the Control System.
- B The Control Head at each Remote Station should produce an intermittent tone.
- C Take command at a Remote Station.
- D Perform each of the following steps on all Remote Stations.
 1. Move the Control Head's lever(s) full Ahead and full Astern. Ensure that there are no obstructions to the movement, the Processor reacts to the lever movement, and that no tones are generated.
 2. Place the Control Head's lever(s) in the Neutral position.
 3. Depress and hold the Station transfer button while moving the Control Head's lever(s) to the Ahead detent. Release the transfer button.
 - The red LED on the Control Head should blink, indicating Warm-up Mode has been entered. Warm-up Mode operates only in the Ahead direction. If the red indicator light BLINKS, continue with the testing.
 - If the red indicator light DOES NOT BLINK, check connections as stated in the appropriate Control Head Service Sheet in section 11: Appendix A - System Components and Specifications.

6.2 Start Interlock (Engines Stopped)

- A Turn the Processor DC power OFF.
 - Verify that the engine(s) will not start.
- B Turn Processor DC power ON. Do not take command at a Remote Station.
 - Verify that the engine(s) will not start.
- C Take command at a Remote Station. Place the Control Head's lever(s) to approximately 50% of the throttle range.
 - Verify that the engine(s) will not start.
- D Place the Control Head's lever(s) in the Neutral/Idle position. Take command at a Remote Station.
 - Verify that the engine(s) will start in this position.

If any of the above tests fail, verify Start Interlock installation and connections. Refer to section 4: Installation.

6.3 Basic Throttle Settings (Engines Stopped)

6.3.1 (E1) Throttle in Neutral

This Function allows the engine RPM at Neutral to be adjusted independently of the RPM at Idle Ahead and Astern. The available Values for this Function are **00.0%** to **25.0%** of the Throttle Range. The Default Value is **00.0%**.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **E1**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.




Figure 6-1: Display LED E1

6.3.2 (E4) Throttle Maximum Astern

This Function limits the amount of Throttle permitted in Astern. The available Values for this Function are **00.0%** to **100.0%**. The Default Value is **100.0%** of **E3** Throttle Maximum setting.

The Value selected is a percentage of the Value selected in Function Code **E3** – Throttle Maximum.

Example: A Value of **50.0** will allow **50%** of Throttle Maximum when commanding Astern. The Value selected is a matter of personal preference.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **E4**
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.




Figure 6-2: Display LED E4

6.3.3 (E6) High Idle

This Function Code Programs the RPM of the second, elevated Idle. The available Values for this Function are **00.0%** to **20.0%** of **E3** Throttle Maximum. The Default Value is **00.0%**.

The Value selected is a percentage of the Value selected in Function Code **E3** – Throttle Maximum.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Place the Station-in-Command Control Head into Warm-up Mode.
- B Scroll to Function Code **E6**.
- C Activate Set Up Mode.
- D Scroll Up or Down to the desired Value.
- E Store the Value to memory.



Figure 6-3: Display LED E6

- F Return the Control Head levers to Neutral/Idle.

6.4 Servo Throttle Settings (Engines Stopped)

6.4.1 (E3) Throttle Maximum

This Function adjusts the position of the Throttle Push-Pull cable at Full Throttle. The available Values for this Function are **10.0%** to **100.0%**. The Default Value is **33.0%**. This value will always be 10% or more above **E2** Throttle Minimum.

The Value entered is the percentage of the servo's maximum travel of 3.00 inches (76,2mm).

Example: A Value of **50.0**, will equal **1-1/2 inches (38,1mm)** of travel from Idle to Full Throttle.




Figure 5-4: Throttle Push-Pull Cable Full Throttle Position




Figure 6-5: Display LED E3 - Servo

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Take command at a Remote Station.
- B Move the Control Head lever to the Full Ahead position.
- C Check to see if the Throttle Push-Pull cable reaches the Full Throttle stop.

- If the Throttle Selector lever is firmly (not bound) against the Full Throttle stop, no adjustment to Function Code **E3** is required.
- If the Throttle Selector lever does not reach (or is bound against) the Full Throttle stop, continue with the next step.

- D Scroll to Function Code **E3**.
- E Activate Set Up Mode.
- F Scroll Up or Down until the Throttle lever is firmly (not bound) against the Full Throttle Stop.
- G Store the Value to memory.
- H Return the Control Head lever to the Neutral/Idle position.

6.4.2 (E2) Throttle Minimum

This Function further adjusts the Push-Pull cable's Idle position electronically. The primary purpose is to adjust the Push-Pull cable/Throttle Selector Lever's position is so that any further movement will result in an increase in engine RPM. (No Dead-band)

The available Values for this Function are **00.0** to **20.0%**. The Default Value is **00.0%**. This value will always be **10%** or more below the **E3** Throttle Maximum setting.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Ensure that the Throttle push-pull cable is connected to the Throttle lever.
- B Scroll to Function Code **E2**.
- C Activate Set Up Mode.



Figure 6-6: Display LED E2 - Servo

- D Scroll Up until the engine RPM begins to increase above Idle.
- E Scroll Down until Idle RPM is reached.
- F Store the Value to memory.

6.5 Servo Checks (Engines Running)

6.5.1 Push-Pull Cables

- A Check that all Push-Pull cable connection fasteners are tightened securely.
- B Inside of the Processor(s) check that the Push-Pull cable jam nuts are securely tightened. A loose hex nut can back off the Push-Pull cable threaded end and effectively change the cable length.

6.6 Engine Stop Switches (Engines Running)

Start the engine(s) and verify that the Stop switches (normally push buttons) function correctly at all Remote Stations. Refer to the information supplied by the engine manufacturer or switch supplier for set up and adjustments.



CAUTION: An Engine Stop Switch at each station is an absolute requirement. Refer to CFR46, 62.35-5 and ABYC P-24.5.8.



WARNING: Do not attempt to continue tests until all Engine Stop Switches are functioning correctly!

6.7 Control Head Command Checks (Engines Running)

- A Start the engine(s) and let them run at Neutral/Idle.
- B Place one Control Head lever at a time into the Ahead detent, the Astern detent and then Neutral.
 - SERVO SHIFT: Confirm that the push-pull cable movement is in the direction commanded. If incorrect, perform the steps described in section 5.5.3.4: (C5) Clutch Servo Direction.
- C Place the Control System into Warm-Up Mode and confirm that there is control of speed.
- D Run the throttle up to approximately 20% of the throttle range for at least 10 seconds.
- E Return the lever to the Neutral/Idle position.
- F Repeat steps A) thru E) at the remaining Control Head levers.

6.8 (E5) Throttle Pause Following Shift (Engines Running)



NOTE: A Test Control Head and a stop-watch are recommended to determine the correct setting for the Throttle Pause. If a Test Control Head is not available, a second person may be needed.

- A Move the Station-in-Command's lever to the Ahead detent, while monitoring the Shaft.
 - SERVO THROTTLE: Start the stop-watch as soon as the Clutch Push-Pull cable stops moving.
- B When the Shaft begins to rotate, stop the stop-watch.
- C Record the time expired on the stop-watch. Record _____.



NOTE: If the time recorded in step C) exceeds 5.0 seconds, a Clutch Pressure Interlock is required. Refer to section 8: Control Options.

7 Sea Trials



WARNING: It is imperative that the information provided in the previous Sections has been read and followed precisely, prior to attempting a Sea Trial. If any of the following tests fail, discontinue the Sea Trial immediately and return to the dock. Consult section 10: Troubleshooting or a ZF Facility prior to resuming the Sea Trial.



NOTE: On Multi Screw Applications, the following tests must be performed on all engines/transmissions. During the course of the Dock Trial and Sea Trials, fill out the Sea Trial Report in F-226 9000 Series Sea Trial Report. Retain this information for future use.

7.1 Full Speed Setting

- A Warm-up the engine(s) and transmission(s) and slowly move into open water.
- B Gradually move the Control Head lever(s) to Full speed.
- C If synchronization is installed, disable synchronization as explained in section 2: Operation.
 - SERVO THROTTLE: If the engine RPM is low, check whether the engine throttle lever is against the full speed stop. If it is not, adjust **E3** Throttle Maximum, as explained in section 6: Dock Trials.
 - If the engine RPM is high, decrease by using Function Code **E3** Throttle Maximum, as explained in section 6: Dock Trials.
- D For multi screw applications, check that matching Idle, Mid-range and Full speed Control Head lever positions cause equal RPM on both engines.
 - SERVO THROTTLE: If RPM's do not match, check push-pull cable travel. If travel does not match when the Control Head levers are side by side, adjust Function Code **E3** Throttle Maximum, refer to section 6: Dock Trials.

7.2 Proportional (Reversal) Pause - C2

The proportional pause feature provides engine deceleration when making a direction change. The pause is variable and in proportion to:

- The Control Head's lever position prior to the reversal.
- How long the Control Head's lever has been in that position prior to the reversal.

7.2.1 Reversal Pause Type Sequences

The sequence of events, are as follows for the different Reversal Pause types: (Refer to the type being used on your vessel)

7.2.1.1 In-Gear Delay [C200]

1. The Throttle position drops to Idle.
2. The Transmission remains engaged in Ahead or Astern.
3. The Control System pauses at this position until the delay has timed out.
4. The Transmission shifts to the opposite gear (Astern or Ahead).
5. The Throttle position moves to the Control Head's present lever position.

7.2.1.2 Neutral Delay [C201]

1. The Throttle position drops to Idle.
2. The Transmission shifts to Neutral.

3. The Control System pauses at this position until the delay has timed out.
4. The Transmission shifts to the opposite gear (Astern or Ahead).
5. The Throttle position moves to the Control Head's present lever position.

7.2.1.3 Fixed Neutral Delay [C202]



CAUTION: The Fixed Neutral Delay feature was added in order to accommodate Thruster Control installations. Damage to the drive train may occur when used for reverse reduction gear applications.

1. The Throttle position drops to Idle.
2. The Transmission shifts to Neutral.
3. The Control System pauses at this position for the amount of time programmed (duration) with Function **C3** Proportional Pause Time (regardless of prior throttle setting).
4. The Transmission shifts to the opposite gear (Starboard or Port).
5. The Throttle position moves to the Control Head's present lever position.

7.2.2 Select Function Code C2 - Proportional (Reversal) Pause

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **C2**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.



Figure 7-1: Display LED Function C2

7.3 Proportional (Reversal) Pause Time - C3

The Proportional Pause Time feature provides engine deceleration, followed by a pause in throttling to the commanded speed in the new desired direction, upon a Full-Speed Reversal. This pause time is proportional to how much throttle is being commanded and for how long.

In order to build up to the pause value set, the vessel must be at full throttle and Ahead six (6) times the pause set. The default pause from Astern to Ahead is 1/2 the Proportional Pause **C2** value set.

When **C2** Proportional Pause is set to **00**, the throttle position drops to Idle and the transmission remains engaged Ahead; the pause that follows is in proportion to the prior Control Head lever position and how long the lever had been in that position before the reversal.



NOTE: The pause on a through Neutral shift is proportional to the speed commanded and the time at that speed. The Values listed for Function Code **C3** - Proportional (Reversal) Pause Time, are the maximum possible delays. When shifting from Idle Ahead to Idle Astern or vice-versa the delay is zero. The time required to build up to the maximum pause is six times the Value selected. In addition, in order to build up to the maximum delay Value, the System must be commanding Full Throttle. The Pause when shifting from Astern to Ahead is either half or the same as the Ahead to Astern delay depending on the Value selected for Function Code **C4** - Proportional (Reversal) Pause Ratio.

7.3.1 Determine C3 Pause Requirement



NOTE: A stop-watch is required to accurately program the Proportional (Reversal) Pause Time.

The amount of pause required is determined as follows:

- A Place the Control Head lever(s) to the Full Ahead position.
- B Leave the Control Head lever(s) at this position for whichever of the following is longer:
 - Sixty seconds.
 - The vessel's speed through the water reaches maximum.
- C Quickly move the Control Head lever(s) to Ahead Idle or Neutral, (depending on Function Code **C4** setting stored during Set Up Procedures) while starting the stop-watch.
- D When the engine(s) RPM reaches Idle and the vessel's speed through the water is within two knots of the standard Idle Ahead speed, stop the stop-watch. Record Time_____.
- E Program Function Code **C3** to the time expired on the stop-watch.

7.3.2 Store C3 - Proportional Pause Time Value

The available Values are **00** to **99** seconds. The default Value is **04** seconds.

To change the Value (Refer to section 5.2: Activating Set Up Mode and section 5.3: Storing Values To Memory):

- A Scroll to Function Code **C3**.
- B Activate Set Up Mode.
- C Scroll Up or Down to the desired Value.
- D Store the Value to memory.



Figure 7-2: Display LED Function C2

7.3.3 Testing Proportional (Reversal) Pause Time



CAUTION: It is critical that the Proportional (Reversal) Pause is tested as outlined below, to ensure that it is properly programmed. Failure to do so could cause damage to the transmission.

- A Position the boat in open water and slowly increase the Throttle to 25% of the speed range.
- B Leave the Control Head lever(s) at this position for at least 60 seconds.
- C Quickly move the Control Head lever(s) to Idle Astern.
 - The engine(s) RPM should drop to Idle.
 - The Clutch should stay engaged or shift to Neutral for 25% of the time selected with Function Code **C3** Proportional Pause Time.
 - Once the time has expired, the Clutch should Shift to Astern.

- The engine RPM will drop slightly when the Astern load is placed on the engine, but not to the point where it comes close to stalling.
- D Increase the Throttle slightly until the vessel starts moving in the opposite direction.
 - If the engine stalled or came very close to stalling, increase the Value of Function Code **C3** by following the steps in the previous section 7.3.2: Store C3 - Proportional Pause Time Value. Then repeat steps A) through C) of this section.
 - If the engine does not stall or come close to stalling, proceed with the next step.
- E Repeat steps A) through D) with the Throttle at 50%, 75%, and 100% of the speed range.
 - If the engine stalls at any time, increase the Value of Function Code **C3** by one (1) second and repeat the steps A) through D) of this section again.
- F Once a Full Speed Reversal is successful without coming close to stalling, the Proportional Pause is properly adjusted.

7.4 Synchronization Test

7.4.1 Equal Throttle Synchronization

- A Move both Control Head levers side by side to approximately 25% of the Throttle range.
- B If previously disabled, enable the synchronization by depressing the transfer button for two seconds.
 - The green LED on the Control Head should illuminate, indicating synchronization.
- C Check the engine tachometers to see if they are within 1% of one another.
- D Move both Control Head levers side by side to approximately 50% of the Throttle range.
- E Check the engine tachometers to see if they are within 1% of one another.
- F Move both Control Head levers side by side to approximately 75% of the Throttle range.
- G Check the engine tachometers to see if they are within 1% of one another.
- H Move both Control Head levers side by side to 100% of the Throttle range.
- I Check the engine tachometers to see if they are within 1% of one another.
 - While synchronized, if the tachometers have a greater than 1% difference at any engine RPM, Active Synchronization is recommended.

7.4.2 Active Synchronization

- A Move both Control Head levers side by side to approximately 25% of the Throttle range.
- B If previously disabled, enable the synchronization by depressing the transfer button for two seconds.
 - The green LED on the Control Head may blink while driving toward synchronization.
 - Once the engine RPM's are within 1% of one another, the green LED will remain solidly lit.
- C Check the engine tachometers to see if they are within 1% of one another.
- D Move both Control Head levers side by side to approximately 50% of the Throttle range.
- E Check the engine tachometers to see if they are within 1% of one another.
- F Move both Control Head levers side by side to approximately 75% of the Throttle range.
- G Check the engine tachometers to see if they are within 1% of one another.
- H Move both Control Head levers side by side to 100% of the Throttle range.
- I Check the engine tachometers to see if they are within 1% of one another.

While synchronized, if the tachometers have a greater than 1% percent difference at any engine RPM, or if they appear to be continually "hunting" for the correct RPM, refer to the section 10: Troubleshooting.

9000 Series Sea Trial Report

The purpose of this Sea Trial Report is to provide a convenient checklist and record of installation, dock trial set up, and sea trial performance of the ZF Marine Electronics 9000 Series Propulsion Control System. Please enter ALL information. We recommend a copy of this completed form remain aboard the vessel, and require that you fax a copy to ZF Marine Electronics at 425-493-1569.

Table F-226-1: Vessel Information

Your Name:		Date:	
Contact Name:		Telephone:	
Vessel Owner:		Vessel name:	
Builder:		Hull #:	
Engine Manufacturer		Model:	
HP:		RPM:	
Transmission Manufacturer		Model:	
Ratio:		No. of Screws:	
No. of Stations (max 5):		Sta. 1 Location	
Sta. 2 Location		Sta. 3 Location	
Sta. 4 Location		Sta. 5 Location	

Table F-226-2: Processor Information

Processor Information	Port		Stbd	
Processor Serial Numbers				
Is the Processor subject to excessive heat? (Above 70 degrees C)	Yes	No	Yes	No
At least 4 feet (1,2m) from strong magnetic fields?	Yes	No	Yes	No
Accessible for checkout, adjustments, and maintenance?	Yes	No	Yes	No
Are the Processors bonded (grounded)?	Yes	No	Yes	No
Are all Electric Cables supported every 18 inches (45,72cm)?	Yes	No	Yes	No
Does the Shift push-pull cable travel in the correct direction?	Yes	No	Yes	No
Is the amount of push-pull cable travel set properly for Shift?	Yes	No	Yes	No
Does the Throttle push-pull cable travel in the correct direction?	Yes	No	Yes	No
Is the amount of push-pull cable travel set properly for Throttle?	Yes	No	Yes	No
Are all of the push-pull cable's fasteners tightened?	Yes	No	Yes	No
Are the electrical cable connections tight at the Processors and Control Heads?	Yes	No	Yes	No
Is the Processor's Start Interlock Circuit being used? If not, what type of start interlock is being used?	Yes	No	Yes	No
Is there an Engine Stop Switch installed at each Remote Station?	Yes	No	Yes	No

Table F-226-2: Processor Information

Processor Information	Port		Stbd	
	Sta. 1	Sta. 2	Sta. 1	Sta. 2
What is the length of the Control Head Harness?				
	Sta. 3	Sta. 4	Sta. 3	Sta. 4
	Sta. 5		Sta. 5	

Table F-226-3: Power Supply

Processor Information	Port		Stbd	
What is the source of Processor power and how is it charged?				
Is there a backup power supply? APS or other, explain.	Yes	No	Yes	No
Are the power cables protected by 10 Ampere Circuit Breakers?	Yes	No	Yes	No
What is the Voltage when not being charged?	Battery	Processor	Battery	Processor
What is the Voltage when connected to Shore Power?	Battery	Processor	Battery	Processor
What is the Voltage when the engines are running?	Battery	Processor	Battery	Processor

Table F-226-4: Dock Trials

Processor Information	Port		Stbd	
Does the engine start remotely when the Control System is turned OFF?	Yes	No	Yes	No
Does the Engine Stop Switch function at all Stations, regardless of RPM?	Yes	No	Yes	No
Can all Remote Stations take command?	Yes	No	Yes	No
Does the Warm-up Indicator Light blink in Ahead?	Yes	No	Yes	No
What is the Low Idle RPM?		RPM		RPM
High Idle RPM (optional)		RPM		RPM
Does the vessel surge forward with Control Head lever in the Ahead Detent?	Yes	No	Yes	No

Table F-226-5: Record at Dock

Processor Information		Port	Stbd
Throttle in Neutral (Cummins Quantum only)	VDC, mA., Hz. or %		
Throttle Minimum	VDC, mA., Hz. or %		
Throttle Maximum	VDC, mA., Hz. or %		
Troll Minimum (signal)	mA		
Troll Maximum (signal)	mA		

Table F-226-6: Sea Trials

Processor Information	Port		Stbd	
	Yes	No	Yes	No
Do the Dual Control Head levers match position and RPM throughout the speed range?				
Is Synchronization operational?				

Table F-226-7: Record during Sea Trial

Processor Information	Port	Stbd
Engine Idle RPM		
Shaft Idle RPM (Calculate the Shaft Idle RPM as follows: Engine Idle RPM/Gear Ratio)		
Full Throttle RPM		
Troll Minimum (Shaft RPM) RPM (Actual) (The desired Troll Minimum can be calculated as follows: Shaft Idle RPM x 0.3)		
Troll Maximum (Shaft RPM) RPM (Actual) (The desired Troll Maximum can be calculated as follows: Shaft Idle RPM x 0.7)		

Table F-226-8: Processor Parameters Record

Function Code	Function Name	Port	Stbd
PROCESSOR FUNCTIONS			
A0	Processor Identification		
A1	Number of Engines		
A2	One Lever Operation		
A3	SE (Station Expander)		
A4	Neutral Indication Tone		
A5	Engine Room Only / Station 2 Lockout		
A6	DP Mode		
A7	DP Transfer Lockout		

THROTTLE FUNCTIONS		Port	Stbd
E0	Engine Throttle Profile OR Throttle Servo Direction		
E1	Throttle in Neutral		
E2	Throttle Minimum		
E3	Throttle Maximum		
E4	Throttle Maximum Astern		
E5	Throttle Pause Following Shift		
E6	High Idle		
E7	Synchronization		

DP FUNCTIONS		Port	Stbd
D0	Engine Idle Speed		
D1	Engine Full Speed		
D2	Engine Speed in DP Troll		
D3	Gear Ratio		
D4	AutoTroll Slipat Min Prop Shift Speed		
D5	AutoTroll Slipat Max Prop Shift Speed		
D6	Troll Lockup Transition Delay		

CLUTCH FUNCTIONS		Port	Stbd
C0	Clutch Pressure Interlock		
C1	Clutch Interlock Delay		
C2	Proportional Pause		
C3	Proportional Pause Time		
C4	Proportional Pause Ratio		
C5	Shift Solenoid Type OR Clutch Servo Direction		
C6	ZF-Hurth Duty Cycle Ahead OR Clutch Ahead		
C7	ZF-Hurth Duty Cycle Astern OR Clutch Astern		
C8	Fixed Neutral Delay		

TROLL FUNCTIONS		Port	Stbd
(Only Available and Displayed When P/N 9001 Troll Actuator Is Connected To The Processor OR when L0 is programmed to a value other than 0 with integrated troll)			
L0	Troll Enable and Control Head Troll Lever Range		
L1	Troll Valve Function OR Troll Servo Direction		
L2	Troll Minimum Pressure		
L3	Troll Maximum Pressure		
L4	Troll Throttle Limit		
L5	Troll Pulse Duration		
L6	Troll Pulse Percentage		

Speed Boost Functions		Port	Stbd
F0	Boost Percent		
F1	Boost Duration		
F2	Boost Start Delay		
F3	Boost Bypass Clutch Delay		

ABS Functions		Port	Stbd
P0	ABS Transfer Modes		
P1	Transfer Time Out		
P2	Station 4 Transfer Mode		

Comments (Please use additional paper as necessary):

General Installation Condition:

Any Irregularities:


Is the Installation and Troubleshooting Manual on board?	Yes	No	If No, request copy?	Yes	No
Is the Operator Card on board?				Yes	No
Is a copy of this completed Report aboard?				Yes	No
Is a copy of this completed Report faxed to ZF Marine Electronics?				Yes	No

Inspector: _____ Date: _____
 Company: _____ Contact info: _____

MAIL COMPLETED COPY TO:

8 Control Options

8.1 External Alarm Capability





CAUTION: The Processor's Alarm circuit is limited to a maximum current of 0.5 Amperes and a maximum voltage of 100 Volts DC. Exceeding these limits will permanently damage the Alarm circuit.

The Processor comes equipped with a normally open relay contact for connection to an external Status Indication circuit. The relay energizes, closing the contact when the Circuit Board has power applied and the software program is running normally. In the event of a power loss or the software program detects an anomaly, the relay de-energizes and the contact opens.

Table 8-1: Key for Figure 8-1: and Figure 8-2: Designators

Designator	Description
A	DC Power Source (12 or 24 VDC)
B	Fuse
C	Alarm Indication Circuit ON/OFF Switch
D	Relay with a Normally CLOSED Contact and a Diode across the Coil for Surge Suppression

Designator	Description
E	Control System Fail Indicator Light (and/or Audio Alarm).
G	Maximum Current 0.5 A
F	ZF Marine Electronics Processor



8.1.1 Installation

The following items should be considered when designing and installing the Status Indication Panel:

- The Power Wire Harness (p/n 13631-#) must be used if an External Alarm is required.

- The Processor's Alarm Circuit uses a "dry" contact. Therefore, the polarity of the conductors is not a concern.
- The External Status Indication Circuit must not use the same power source as the Processor.
- Since the External Status Indication Circuit is activated on a loss of power to the Processor, an ON/OFF Switch is strongly recommended.
- Figure 8-1: External Alarm Harness Example and Figure 8-2: External Alarm Hard-Wired Example are examples of a suitable circuit, but are not necessarily the only acceptable circuit.
 - A Plug the Power Wire Harness into the Processor's Power pigtail.
 - B Run the Power Wire Harnesses's two-conductor Alarm cable to the location of the Status Indication Circuit.
 - C Connect the black and red conductors to the Status Indication Circuit as shown in Figure 8-1: External Alarm Harness Example and Figure 8-2: External Alarm Hard-Wired Example.

8.2 Clutch Pressure Interlock



NOTE: The Clutch Pressure Interlock C0 must be set to be used. Refer to the section 5: Set Up Procedures for information on setting Function Code C0.

The Clutch Pressure Interlock uses a Pressure Switch which monitors the Ahead and Astern Clutch pressures to prevent high engine RPM when the clutch is not fully engaged.

The Pressure Switch must have a Normally Open (N.O.) contact that closes when adequate Clutch pressure is reached. The primary function of the Interlock is to prevent high engine RPM when the Clutch is not fully engaged. The Interlock option must be selected with Function Code **C0**. There are two selectable methods of operation as described below:

8.2.1 (C0) Methods of Operation

8.2.1.1 (01) Installed

When selected, the Interlock will command the Throttle to Idle if low or a loss of pressure occurs while cruising. The Interlock is activated when the Pressure Switch's contact opens for the minimum period of time selected with Function Code **C1**.

If adequate Clutch pressure is not reached in the time programmed in Function Code **E5**, throttle will only be allowed to increase to this commanded speed for the time programmed in Function Code **C1** and then returned to Idle.

The Throttle will remain at Idle until the Control Head's lever is returned to Idle, the Pressure Switch contact closes and a speed command above Idle is commanded.

8.2.1.2 (02) Throttle Clutch Pressure Interlock

This option is typically selected when the Clutch takes longer than five seconds to reach full pressure. The Throttle will remain at Idle until there is a closure of the Pressure Switch's contact. This prevents speeds above Idle prior to full Clutch engagement.

In the event of a loss of Clutch pressure while cruising, the Throttle will return to Idle after the time selected with Function Code **C1** has expired. Once a closure of the Switch is sensed, indicating adequate pressure, the Throttle immediately returns to the commanded signal, without having to return the Control Head lever to Idle first, as is the case with Value **01**.

Table 8-2: Figure 8-3: and Figure 8-4: Designator

Designator	Description
A	Shuttle Valve
B	Hydraulic Line
C	Pressure Switch

Designator	Description
D	ZF Marine Electronics Processor
E	Ahead Clutch Pack
F	Astern Clutch Pack




Figure 8-3: With Processor Harness




Figure 8-4: With Processor Hard-Wired

8.2.2 Installation

The installation of the Clutch Pressure Switch is the same for both methods of operation. (Refer to Figure 8-3: With Processor Harness and Figure 8-4: With Processor Hard-Wired.)

- A Install a Shuttle Valve on or near the Transmission.
- B Connect hydraulic line from the Ahead and Astern Clutches.
- C Connect a hydraulic line that is no longer than 5 feet (1,524m) and at approximately the same height between the Shuttle Valve and the Pressure Switch.
- D Connect the Power Wire Harness's Clutch Pressure Interlock cable to the Pressure Switch's normally open contact.
- E Calibrate the Pressure Switch to close when adequate Clutch Pressure is reached. (Refer to the Transmission Manufacturers Installation Manual)

8.3 Station Expander (SE)

The Processor allows up to five Remote Stations. The SE allows up to an additional four Remote Stations for a total of nine Stations.

The SE and Processor communicate via the Serial Communication cable. Control Heads connected to the SE offer all of the functionality of a standard Remote Station.

For detailed information on the operation, installation and adjustment of the SE, refer to the Station Expander Installation Manual supplied with the Expander.

If this option is going to be used, please contact a ZF Marine Electronics Representative for further information.

8.4 9001 Actuator Trolling Valve Control

Most Marine Transmissions offer an optional Trolling Valve. A Trolling Valve controls the amount of pressure applied to the Clutch Plate. By doing so, the speed of the propeller can be reduced without decreasing engine RPM.

The Processor allows the operator to control, with a single lever, the Trolling Valve, Clutch and Throttle. In order to do so, a separate Trolling Actuator [p/n 9001] must be installed.

The Trolling Actuator and the main Processor(s) communicate with one another via the Serial Communication cable. The Trolling Actuator contains two Servos, which allows the control of two Trolling Valves with a single Actuator. This option is available only for Processors that do not have Integrated Servo or Solenoid Trolling.

For detailed information on the operation, installation and adjustment of the Trolling Actuator, refer to the Trolling Actuator Installation Manual supplied with the Actuator or contact ZF Marine Electronics.

9 Periodic Checks And Maintenance

The items listed below should be checked on an annual basis, or more frequently where noted:

9.1 Control Heads

- Check the terminal strip for signs of corrosion or a loose connection.
- If used, disconnect the Deutsch connector and check the pins and sockets for signs of moisture and corrosion.

9.2 Processor

- Check all terminal connections for signs of corrosion or loose connections.
- Un-plug and inspect all Deutsch connectors for signs of moisture or corrosion.
- While in the vicinity of the Processor, move the Station-in-Command's lever. If the Servo's are excessively noisy, apply a light coating of silicone grease to the stainless steel lead screws. If there are no Stations in close proximity to the Processor(s), use a Field Service Control Head or have someone assist.

9.2.1 Throttle Servo Processor

- Check mechanical connections within the Processor and at the Throttle selector lever.
- Check the mechanical movement of the Throttle lever from Idle to Full. Ensure that the cable does not bind while positioning the Throttle at Idle or Full speed.

9.2.2 Clutch Servo Processor

- Check mechanical connections within the Processor and at the Transmission selector lever.
- Check the mechanical movement of the Clutch selector lever from Neutral to Ahead, and Neutral to Astern. Ensure that the cable does not bind while positioning the Control Head lever at Ahead or Astern. Ensure that the Clutch selector lever and the Push-Pull cable form a 90 degree angle at Neutral.

9.3 Power

- Check all of the connections from the battery to the DC Distribution Panel to the APS for loose or corroded connections.
- Measure the voltage at the battery and at the Processor while the Clutch or Throttle is driving. There should be no more than 10% difference between these two points. If so, check all devices and connections for excessive voltage drop



NOTE: If an APS is used in the circuit to supply power to the Processor, account for the 0.7V drop across the APS. Example: 12.6V @ battery – 1.26V (10% drop) – 0.7V (APS drop) = 10.64V (Minimum allowable voltage)

10 Troubleshooting

The ZF Marine Electronics Control System consists of one Processor per engine, typically mounted in the engine room, and one to five Control Heads located at the vessel's Remote Stations.

In the event that a malfunction occurs, review the appropriate System Diagram and become familiar with the various components, their functions and locations on the vessel.

The following Sections are a list of the main components that make up a typical system, along with a brief description of their functions:

10.1 Control System Examples

10.1.1 9110X (Throttle Servo, Clutch Servo, X = Pluggable Remote Stations) Processor

The 9110X is designed to precisely control speed and direction on vessels equipped with servo Throttle and servo Clutch selection.

10.2 Typical System Main Components

10.2.1 Control Head

The primary function of the Control Head is to send out a variable DC voltage to the Processor. This DC voltage is representative of the Control Head's present lever position. In addition to the primary function, the Control Head also has audible (Sound Transducer) and visual (LED) status indications, along with a Transfer Button for taking command and performing other system functions.

10.2.2 Processor

The Processor receives the variable DC voltage from the Control Head(s) and converts these inputs to the appropriate electronic or electric outputs at the correct time and sequence to the Governor and Gear Box. The information regarding throttle type, throttle/ clutch sequencing, etc., are all stored on memory within the Processor.

10.2.3 Power Source

All electronic equipment must have power in order to operate. Ensuring a properly charged reliable power source is available and crucial.

- The Processor requires a 12 or 24 VDC power system.

The minimum voltage at which the Processor will continue to operate is 8.00 VDC. The maximum allowable voltage is 30 VDC. Exceeding these limits will not damage the Processor, but will render it unusable temporarily. The power supply must be capable of delivering 10 amperes to each Processor on a continual basis and current surges up to 20 amperes. All cable calculations should be based on a 10 ampere draw with no more than 10% voltage drop.

10.2.4 Electrical Cables and Harnesses

The function of the Electrical Cables and Harnesses are to move electrical information from one point to another. The ZF Marine Electronics' System requires electrical cables and/or pluggable Harnesses. These Harnesses may have plugs on one end or both, depending on its purpose.

There are Harnesses available for Control Head Interface, DC Power, Start Interlock, Clutch Oil Pressure Interlock and External System Status Indication Circuit.

In addition, the application may require Harnesses for one or more of the following:

- Serial Communication

- Tachometer Sensor Signal

10.2.5 Push-Pull Cables

The primary function of a Push-Pull cable is to allow a physical movement on one end to be felt at the opposite end with a minimum of back-lash.

The Push-Pull cables are mechanically connected on one end to the Processor's cross-bars and the governor and/or transmission selector levers on the other end. The Processor uses the 33C Type push-pull cable as standard, or 43C Type with a special adapter. (Refer to MMC-345 43C Cable Conversion Kit)

Prior to attempting to troubleshoot the System, get as much information as possible from the owner or operator. Inspect the System for signs of mis adjustments, loose connections, physical damage or water incursion.

Pay special attention to the following items:

- DC Power Source
- Component Location
- Component Condition
- Interconnecting Wiring and Harnesses
- Wire Terminations
- Plug and Connector Socket Pins
- Mechanical connections at the Selector Levers
- Mechanical connections within the Processor

10.3 Questions

Prior to lifting a tool or stepping on board the vessel, many problems can be resolved by asking the customer the following basic questions:

- A Is the System installed on a Single, Twin or Multiple Screw vessel?
- If the System is installed on a Single Screw vessel, this question does not have much value in narrowing down the source of the problem.
 - If the System is installed on a Twin or more Screw application, this question is quite useful, if you ask the following question.
- B Does the problem or symptom occur on the Port, Starboard or both sides?
- If the problem or symptom occurs on one side only, you have effectively eliminated 50% of the possible causes. For example, the symptom only occurs on the Port side. All of the components on the Starboard side have been eliminated as potential causes.
 - If the problem occurs on both the Port and Starboard sides, you must ask yourself: What do both sides have in common? Most likely answer to your question would be the DC Power source.
- C What is the Part Number and Serial Number of the Processor?
- Whenever the factory is called for technical assistance, the part number and serial number will be required. These numbers provide the Service Technician information about the operating characteristics of the Processor. The numbers are located on the Processor's front cover.
- D How many Remote Stations are there? (If only one Remote Station is present, not much will be gained by asking this question. However, if more than one Remote Station is being used,

command should be taken from one of the other Stations to see if the problem occurs from another Station.)

- If the problem occurs from more than one Remote Station, the odds are that the Control Heads are not the cause of the trouble.
- If the problem occurs at one Remote Station only, there is a greater chance of the Control Head or the Control Head Harness of being the cause.

E Are any tones generated when the problem occurs?

The tones are used to bring the operator's attention to a possible condition or problem. The following basic tones can be produced on all Systems (refer to section 10.6: Audible Tones):

- Slow Repetitive Tone
- One Long- Three Short Tones
- Steady Tone
- Three Second Steady Tone
- Five Seconds On, Five Seconds Off - High Repetitive Rate Tone
- Five Second Steady Tone

The following tones can be produced on all Systems using Servo 2:

- One Long - Two Short Tones
- One Long, Two Short - High Repetitive Rate Tones

The following tones can be produced on all Systems using Servo 1:

- One Long, One Short - High Repetitive Rate Tone
- One Long - One Short Tone

F Are there any Error Messages displayed on the Processor's Display LED?

- In addition to generating a tone, at any time the system detects a malfunction or fault, an error message will be displayed at the Processor. Refer to Table 10-3: Basic Error Codes, for an explanation of the errors.

G What is the status of the Control Head in command's red LED?

- The red LED(s) will be in one of the following states:
 - Lit Steady

When the red LED is Lit Steady, this indicates that the Station is in command and in Normal operative mode.
 - Not Lit

When the red LED is **Not Lit**, that Station is not in command, or there is no power to the Control System.
 - Blinking Slowly

A **Slow Blinking** red LED indicates that the Control Head is in Throttle Only Mode (Warm-up Mode).

H Blinking Rapidly

A red LED that is **Blinking Rapidly** indicates that the System is in Troll Mode.

I Has anything on the vessel changed shortly prior to or when the problem arose?

This question is often overlooked, but should be considered. Obvious changes such as additions or changes to the electrical/ electronic equipment onboard can affect the electrical load and in turn the Processor's power supply.

Ask the operator if any changes or maintenance to the vessel's machinery have occurred lately. Items which are significant to you, the technician, may not seem so to the casual owner or operator. An example would be changes to the engine's fuel system.

Ask about changes, that when initially considered, appear to have nothing to do with the Control System. An example where this really occurred was on a vessel which had recently been repainted. For unknown reasons, the painter took it upon himself to disconnect the connections at a Control Head and then reconnected it incorrectly.

In many cases, these simple questions can resolve a problem with no further action from you, the technician. Take the time to consider these questions. In the long run, you will save yourself and the customer a lot of time and money.

10.4 Problem Resolution

If the problem could not be resolved by asking the questions in the previous section, a careful inspection of the Control System may be the next step. Even in situations where the problem was found and corrected, it is good practice to always perform a careful inspection of the entire Control System each and every time you are asked aboard a boat.

Always verify that the installation of the System is in compliance with the Installation Manual by carefully inspecting the following:

10.4.1 DC Power

- A Ensure that the Processor(s) is connected to a properly charged 12 or 24 VDC battery through a 10 Ampere circuit breaker.
- B To ensure reliable power to the Processors an APS (Automatic Power Selector) is strongly recommended. The APS take inputs from two separate power sources. Whichever power source is at the higher voltage level, will be automatically switched through.
- C Refer to S-214 Automatic Power Selector Model: 13505.

10.4.2 Component Location

10.4.2.1 Control Heads

There are virtually no restrictions regarding the location of the 400 Series and MC2000 Series Control Heads, as long as the bottom is protected from the environment. The 500 Series Control Heads must be mounted to a console and the 700 Series are waterproof from top to bottom.

Refer to section 11: Appendix A - System Components and Specifications for Installation requirements.

10.4.2.2 Processors

The Processors are typically mounted in the engine room, while maintaining a minimum distance of 4 feet (1,22m) from sources of high heat and EMI (Electro Magnetic Interference) or RFI (Radio Frequency Interference).

Refer to section 3: Plan The Installation for requirements.

10.4.3 Component Condition

10.4.3.1 Control Heads

Inspect for any signs of corrosion due to water incursion. If hard-wired, ensure that all the fork connectors are properly secured to the terminal. Verify all wires are fully crimped and do not pull loose.

10.4.3.2 Processors

Inspect the Processor for any signs of physical damage.

10.4.4 Interconnecting Wiring and Harnesses

- A Inspect the wire terminations for loose connections, corrosion or wire strands.
- B Inspect the Harness's pins and sockets for bent pins, torn boots or any signs of corrosion.

The first step in troubleshooting a problem with the Propulsion System is to determine if the problem is with the Control System or something external to the System. In all cases a Control System malfunction will alert the operator of the potential problem. This is accomplished through the audible tone emitted at all Remote Stations. When an audible tone is emitted, it will be accompanied by an Error Message at the Processor. Also, in many cases, the Control System will alert the operator to a problem external to the Control System.

The following are examples of components both internal and external to the Control System which could be a source of trouble:

Table 10-1: Examples of Components (Internal/External)

Internal	External
Processor	DC Power Source
Control Head	Engine
Interconnecting Wiring (Harnesses)	Transmission
Push-Pull Cable	Push-Pull Cable

The following pages should give you a good guideline for making this determination. There is no need to troubleshoot the system to any point further than one of the main components listed above. If the fault is found to be with a Control System component, that component is simply replaced. If the fault is found to be with one of the external components, replace or repair the defective component or contact a qualified mechanic.

10.5 Diagnostic Menu

The Processor has built in diagnostics designed to assist the technician in determining the cause of a problem. The following information is available to view at any time:

- Applied Battery Voltage
- Tachometer Sender Frequency
- Stations 1- 5 A/D's
- Stations 1- 5 Transfer Button Status
- Servo 2 Feedback A/D's (if applicable)
- Servo 1 Feedback A/D's (if applicable)
- Software Revision Level

In order to access this information, follow the steps below:

- A Locate the Display LED on the Port or Starboard Processor. The Display LED will have the Processor Part Number displayed in a running pattern moving from left to right while the program is running in Normal Operation.

- Depress the Up or Down Push Button to activate the Function Code List. The characters **A001** will be shown on the Display like Figure 10-1: Display Function Code




Figure 10-1: Display Function Code

- Depress the Up or Down Push Button repeatedly until **H000** is displayed like Figure 10-2: Display Troubleshooting Function..




Figure 10-2: Display Troubleshooting Function

- B Depress and hold the Left and Right Push Buttons simultaneously until the **H0** begins to blink. (Figure 10-3: Display Function Blinking) Release the Push Buttons; the applied battery voltage will now be displayed:




Figure 10-3: Display Function Blinking

- The displayed value is in “real time” and provides a rough estimate of the DC voltage applied to the Processor. The reading is accurate to within 0.50 DC. Refer to • The Control Head’s lever position, and the resulting output of the Station’s Control Heads can always be monitored. This is regardless of whether that Station is in command or not. Note the placement of the decimal points in the following examples, which show all Stations with the lever positioned at the Neutral/Idle position. This will be covered in further detail later




Figure 10-4: Example Display of Applied Battery Voltage

- C In addition to the applied battery voltage, scrolling through the **Diagnostics Menu** by pressing the Up or Down Push Button can also show the Tachometer Sender Frequency (Figure 10-5: Example Display of Tach Sensor Frequency):
- The information shown is the actual frequency output by the Tachometer Sender. This signal is utilized in “Closed Loop” Synchronization or “Closed Loop” Troll (future) systems
 - The Control Head’s lever position, and the resulting output of the Station’s Control Heads can always be monitored. This is regardless of whether that Station is in command or not. Note the placement of the decimal points in the following examples, which show all Stations with the lever positioned at the Neutral/Idle position. This will be covered in further detail late






Figure 10-5: Example Display of Tach Sensor Frequency

Figure 10-6: Example Display Control Head Lever Current Positions



- D The current status of all the Control Head’s Transfer Buttons can be monitored within the **Diagnostic Menu**. A 1 indicates a closure (depressed Transfer Button) of the switch, while a 0 indicates an open switch.

Figure 10-7: Example Display Control Head Transfer Button Status View



- E Depressing the Up or Down Push Button one more time will show the current revision level of the software. This feature will provide invaluable information in the years to come. Determining the characteristics or capabilities of a certain Processor will be as simple as selecting this feature.
- F Pressing the Up or Down (Scroll) Push Button once more, returns you to the Applied Battery Voltage.
- G The Diagnostic Menu can be exited two ways:
 - Do not touch any Push Buttons for 5 minutes. The system will automatically exit.
 - Depress the Left Push Button until H000 appears. You may now scroll through the Set Up Menu.




Figure 10-8: Example Display Software Revision Level View

10.6 Audible Tones

As mentioned previously, there are various tones emitted from the Control Head if an error were to occur.

10.6.1 Basic Control System Tones

These basic tones are as follows:

10.6.1.1 Slow Repetitive Tone

The Slow Repetitive Tone, also referred to as the "Initialization Tone" is the tone you hear at all Remote Stations when power is initially applied to the control system. When this tone is heard, you know for a fact that the following are true:

- Power has just been applied to the system.
- The Software Program is running normally.
- The Processor is commanding the throttle to Idle.
- The Processor is commanding the clutch to Neutral.

This is a normal tone when power has first been applied to the Processor and no Control Head has taken command. However, if during normal operation the engine's throttle drops to Idle, followed by the clutch to Neutral, the Control Head's red LED goes out and a slow repetitive tone is heard at all remote stations, the tone may be an indication of a problem. This indicates that the voltage at the Processor has momentarily dropped below 8 VDC and then returned to a normal operational level. This could be due to:

- Loose battery power cable connection.
- Under-charged or defective battery.
- Voltage drop due to current flow.

In order to pinpoint the exact cause of the low voltage at the Processor, perform the following checks:

- A Check the Display on the Processor for Error Messages. Error Message **57** may appear indicating Under Voltage. One or more of Error Messages **43** through **54** may also be displayed. This is due to the momentary loss of serial communication between the two Processors. Take note that the Under Voltage error is not only dependent on low voltage, it is also dependent on the duration of the low voltage. The possibility exists that an error message would not be displayed if the duration of the low voltage was short enough. However, the other symptoms mentioned above still occur.

- B In either case, follow the procedure listed under section 10.5: Diagnostic Menu until the Applied Battery Voltage is displayed. Take note of the applied voltage.
- C Go to the battery or Main Distribution Panel which is feeding power to the Processor. With a DC Voltmeter, measure the voltage at this power source. The battery voltage should be greater than 12.4 Volts in 12 VDC systems and 24.8 Volts in 24 VDC systems. If not, the battery or it's charging system needs servicing.
- D The voltage differential between the power source and the Processor should not exceed 1.2 Volts in 12 VDC systems and 2.4 Volts in 24 VDC systems. If so, there is high resistance somewhere between the battery and Processor.



NOTE: If an APS is being utilized in the power circuit, take into account the 0.7 VDC forward voltage drop of the diodes. This would increase the permissible differential between power source and Processor from 1.2 to 1.9 VDC in 12 VDC circuits and 2.4 to 3.1 VDC in 24 VDC circuits.

- E High resistance, resulting in a differential voltage of 1.2 Volts (12 VDC Systems) or 2.4 Volts (24 VDC Systems) or greater, may be the result of corroded or tarnished connections, dirty or pitted relay contacts or an improperly sized power cable.
- F If the voltage differential is less than 1.2 Volts (12 VDC Systems) or 2.4 Volts (24 VDC Systems), which is what you would typically expect, a loose connection may exist between the power source and the Processor. The vibration experienced while the vessel is underway may intermittently cause the circuit to open. Check all the connections between the power source and the Processor for loose bolts, nuts, etc.

10.6.1.2 One Long - Three Short Tones

This tone indicates that there is an invalid command signal at the Station-in-Command. The Processor expects a DC voltage, representative of the Control Head's present lever position.

- This voltage is referred to as the "**Command Signal**". In normally functioning Control Heads, the command signal is between approximately 0.8 VDC at Full Astern to 4.10 VDC at Full Ahead.

The command signal is converted by the Processor to a digital representation, referred to as an A/D (Analog/Digital) Count. More on A/D Counts later. If the command signal drops below 0.6 VDC or exceeds 4.40 VDC, the tone will be generated.


At the same time the tone is heard, throttle command drops to Idle and the clutch will be commanded to Neutral. The following items will cause this to occur:

- An open or high resistance connection between the Control Head and Processor.
- Out of calibration Control Head.
- A defective Control Head.

The exact cause of the malfunction can be found as follows:


- A Check the Processor's Display for error messages. Most likely, one of error messages **13** thru **32** will be shown. The exact number shown depends on which remote station is experiencing the problem and whether the command signal was too high or too low.
- B Enter the **Diagnostic Menu** as outlined in section 10.5: Diagnostic Menu.
- C Depress the Up or Down (Scroll) Push Button until the appropriate Remote Station is displayed.
 - The Remote Station are identified by the position of the decimal points.
 - Station 1 has no decimal point after the first digit to the far right. The remaining three digits all have decimal points.
 - If the digit to the far left had no decimal point following it, but the remaining three do, this would represent Station 4.

Figure 10-9: Display Examples of Remote Stations



D The examples above are shown with no Control Heads connected to any Remote Stations. When a Control Head is connected, the appropriate A/D (Analog/Digital) value for the present position of the Control Head's lever will be shown, as in the following examples:

Figure 10-10: Display Examples of Remote Stations A/D Value



E An A/D value of 910 or greater will generate an Error Code. The code will be **13 to 22** (Control Head # Faulted High), depending on which Station has the high Command Signal.

- If the A/D value is greater than 910, but less than 990, one of the following may be the cause:
 1. The Control Head's potentiometer is out of calibration.
 2. The potentiometer is defective.

In either case, it is recommended that the Control Head is replaced.

- If the A/D value is 995 or higher, most likely the potentiometer's ground has been lost.
- Right hand Control Heads have a jumper between pins 3 and 5 if a Harness is used. This jumper provides the potentiometers ground.
- Left hand Control heads have a jumper between pins 3 and 7 if a Harness is used. This jumper provides the potentiometers ground.

- The potentiometer ground connection for Control Heads are hard-wired to the Processor through the yellow wire (pin 5 on right hand and pin 7 on left hand).
- F If the A/D value is 100 or less, one of Error Codes **23- 32** (Control Head # Faulted Low) will be shown.
- If the A/D value is less than 100, but greater than 75, the following may be the cause:
 1. The Control Head's potentiometer is out of calibration.
 2. The potentiometer is defective.
 3. A high resistance connection exists on pin 6 (green wire) between the Control Head and Processor.
 - If the A/D value is less than 75:
 1. There is an open wire between pin 6 (green wire) of the Control Head and the Processor.
 2. There is an open wire between pin 7 (blue wire) of a right hand Control Head and the Processor.
 3. There is an open wire between pin 5 (blue wire) of a left hand Control Head and pin 7 (blue wire) of the Processor.

G Steady Tone

The Steady Tone is an indication to the operator that something has gone wrong within the Control System. The Steady Tone will typically be accompanied by an Error Message on the Processor's Display. If the tone is heard, the Processor's Display must be referred to in order to further diagnosis the problem.

If the Transfer Button is shorted - Tone will cease when command is taken at another Station.

If the Transfer Button becomes shorted for 12 seconds or more during Normal Operation, a steady tone will be produced at all Remote Stations as long as the Transfer Button remains shorted. Full System control remains. Transferring to another Remote Station silences the Steady Tone. Command cannot be regained at the (shorted) Station until the problem is rectified.

10.6.1.3 Three Second Steady Tone

This tone could indicate one of three things:

- Transfer Button on the Control Head in command is stuck.
- If the Processor for this System includes the use of Back-up Mode, this tone would indicate that there has been a switch closure requesting Back-up Mode.
- If the Processor for this System includes Integrated Solenoid Trolling Valve control, this tone would indicate that there has been a Troll Solenoid error. Refer to the Error Code displayed.

10.6.1.4 Three Second Steady Tone, followed by a Slow Repetitive Tone

This tone indicates that there has been a shorted Transfer Button on power-up. Command can be gained at any other Remote Station, which silences the Slow Repetitive Tone.

10.6.1.5 Five Seconds On, Five Seconds Off - High Repetitive Rate Tone

Loss of communication with Station Expander (SE) or the Troll Actuator (p/n 9001). This tone cannot be cleared unless all Error Codes (Active and In-Active) have been cleared.

10.6.1.6 Five Second Steady Tone

Loss of Serial Communication.

10.6.2 Servo 2 Control System Tones

10.6.2.1 One Long - Two Short Tones

This tone indicates that the feedback signal, which represents the position of the Servo 2 cross-bar, is out of expected range.

This tone will be accompanied by Error Code **66** or **67**.

- If Error Code **66** is displayed, the signal received from the feedback potentiometer is higher than expected. This is due to one of the three following reasons:
 1. The orange wire (ground) between the potentiometer and plug are not making contact, or have a high resistance contact.
 2. The potentiometer is out of calibration.
 3. The potentiometer is defective.
- If Error Code **67** is displayed, the signal received from the feedback potentiometer is lower than expected. This is due to one of the following reasons:
 1. The green (signal) or orange (reference voltage) wires between the potentiometer and plug are not making contact or have a high resistance contact.
 2. The potentiometer is out of calibration.
 3. The potentiometer is defective.
 4. The Control Circuit is defective.

The Servo 2 feedback signal can be viewed within the Diagnostic Menu. The Value displayed depends on the direction and amount of push-pull cable travel. As a general rule:

- When the Value displayed is **1023** or **0**, the problem is with the wiring between the potentiometer and plug.
- If the displayed Value varies, the potentiometer is defective.
- When the Value is too high or too low when fully extended, the potentiometer requires calibration.

10.6.2.2 One Long, Two Short - High Repetitive Rate Tones

This tone is also referred to as a **Jam Tone**. When sounded, Servo 2 is unable to reach the commanded position. In most cases when a **Jam Tone** is encountered, it can be cleared by moving the Control Head lever back to the point prior to where the tone was first encountered.

The tone will be accompanied by Error Code **65** and is typically caused by one of the following reasons:

- Stiff or frozen selector lever.
- Mis-adjusted push-pull cable.
- Defective push-pull cable.
- Low battery voltage.
- Defective Processor.

In order to isolate the cause to one of these five items, follow the steps below:

- A Turn the power ON to the Processor.
 - If the tone is not present continue with step C)
 - If the tone is present, check the DC voltage to the Processor by accessing the Diagnostic Menu **H0**. If the voltage is adequate continue with step B.
- B Disconnect the push-pull cable from the selector lever.
 - If the tone is still present after cycling power, replace the Processor.
 - If the tone is no longer present, continue with step C)

- C If disconnected, reconnect the push-pull cable.
- D Depress the Transfer Button while moving the Control Head lever to the Ahead detent.
- E Release the transfer button and continue to move the Control Head lever through the speed range.
 - If the tone does not sound until the Control Head lever is close to full throttle, Function Code **E3** Throttle Maximum is mis-adjusted.
 - If the tone sounds earlier than full throttle, continue with step F).
- F Disconnect the push-pull cable from the selector lever.
- G Manually reposition the selector lever (Idle to Full).
 - If the selector lever is very stiff it needs to be serviced.
 - If the selector lever moves freely, the push-pull cable is defective and needs replacing.

10.6.3 Servo 1 Control System Tones

10.6.3.1 One Long - One Short Tone

This tone indicates that the feedback signal, which represents the position of the Servo 1 cross-bar, is out of the expected range.

This tone will be accompanied by Error Code **63** or **64**.

- If Error Code **63** is displayed, the signal received from the feedback potentiometer is higher than expected. This is due to one of the three following reasons:
 1. The orange wire (ground) between the potentiometer and plug are not making contact, or have a high resistance contact.
 2. The potentiometer is out of calibration.
 3. The potentiometer is defective.
- If Error Code **64** is displayed, the signal received from the feedback potentiometer is lower than expected. This is due to one of the following reasons:
 1. The green (signal) or orange (reference voltage) wires between the potentiometer and plug are not making contact or have a high resistance contact.
 2. The potentiometer is out of calibration.
 3. The potentiometer is defective.
 4. The Control Circuit is defective.

The Servo 1 feedback signal can be viewed within the Diagnostic Menu. The Value displayed depends on the direction and amount of push-pull cable travel. As a general rule:

- When the Value displayed is **1023** or **0**, the problem is with the wiring between the potentiometer and plug.
- If the displayed Value varies, the potentiometer is defective.
- When the Value is slightly too high or too low when fully extended, the potentiometer requires calibration.

10.6.3.2 One Long, One Short - High Repetitive Rate Tones

This tone is also referred to as a Jam Tone. When sounded, Servo 1 is unable to reach the commanded position. In most cases when a Jam Tone is encountered, it can be cleared by moving the Control Head lever back to the point prior to where the tone was first encountered.

The tone will be accompanied by Error Code 62 and is typically caused by one of the following reasons:

- Stiff or frozen selector lever.

- Mis-adjusted push-pull cable.
- Defective push-pull cable.
- Low battery voltage.
- Defective Processor.

In order to isolate the cause to one of these five items, follow the steps below:

- A Disconnect the push-pull cable from the selector lever.
- B Move the Control Head lever to Ahead, Astern, and back to Neutral.
 - If the tone ceases continue with step C.
 - If the tone is still present, skip ahead to step D.
- C Grab a hold of the selector lever and manually reposition the lever.
 - If the selector lever is very stiff it needs servicing.
 - If the selector lever moves freely, the push-pull cable's travel is mis-adjusted and needs to be corrected.
- D If the tone did not cease in step B, remove the push-pull cable from the Processor.
- E Move the Control Head lever back and forth from Neutral to Ahead to Astern.
 - If the tone ceases, the push-pull cable is defective and needs to be replaced.
 - If the tone did not cease, check the DC Voltage to the Processor by accessing the Diagnostic Menu **H0**. If the voltage is adequate, replace the Processor.

10.7 Station Transfer

In order to transfer command from one Remote Station to another, the following must occur:

- There must be a valid "Command Signal" at the Station being transferred to.
- The "Command Signal" must indicate that the Control Head's lever(s) is at the Neutral/Idle position.
- The Transfer Button must be depressed which takes the "Station Select" signal from 5.00 VDC to 0.00 VDC.

If a transfer from one Remote Station to another is requested, but does not take place; the items required for successful transfer can be tested as follows:

10.7.1 Command Signal

- The Command Signal is a DC voltage which varies in relationship to the Control Head's lever position.
- The Processor provides each Control Head 5.00 +/- 0.20VDC, which is referred to as the "Reference Voltage".
- The Reference Voltage is applied to a 5K Ohm Potentiometer in the Control Head.
- The potentiometer's "Wiper" taps off a portion of the Reference Voltage and sends it back to the Processor.
- The amount of DC voltage which is tapped off, is dependant on the position of the Control Head's lever.
- When the lever is fully Astern, a small portion of the Reference Voltage is tapped off by the wiper, and therefore, the voltage is at its lowest point (approximately 0.80 VDC).
- When the lever is positioned fully Ahead, a larger portion is tapped off and the voltage is at its highest point (approximately 4.10 VDC).

10.7.2 A to D Counts

Since all the calculations within the control system are performed digitally, these DC voltages are expressed as and converted to a digital representation.

- The “Reference Voltage” (approximately 5.00 VDC) by which all analog inputs are based, is represented as 1023 A/D (Analog to Digital) Counts.
- This allows for the possibility of a 1024 possible positions when 0 is included in the count.
- The value of the Command Voltage with the lever at the Neutral/Idle position is 49- 51% of the Reference Voltage when measured at the Station terminal block. The actual value read by the Processor is 2% below that value or 47% to 49% of 1023 A/D Counts (485- 505 A/D).



NOTE: The A/D values listed for Full Ahead and Full Astern represent the point where maximum throttle is reached. The A/D count when the Control Head lever is physically at it’s maximum point will be higher, but may not exceed the out-of-range values listed in Table 10-2: Control Head Lever A/D Counts.

- The Command Signal at Full Ahead is 82- 84% of the Reference Voltage when measured at the Station terminal block. The actual value read by the Processor is 2% below that value or 80- 82% of 1023 A/D Counts (821- 841 A/D).
- The Command Signal at Full Astern is 17 - 19% of the Reference Voltage when measured at the Station terminal block. The actual value read by the Processor is 2% below that value or 15- 17% of 1023 A/D Counts (153- 173 A/D).
- Since the Command Signal is based on a percentage of the Reference Voltage, the distance of the Control Head from the Processor has no impact on the performance of the system.
- The amount of voltage drop, due to current flow, is the same for both the Reference and Command Voltages.
- The relationship between the Reference and Command Voltages when thought of as a percentage, will remain the same regardless of distance. For instance, here are two examples.

Example 1

- Reference Voltage 5.00 VDC 1023 A/D Counts
- Command Voltage 2.45 VDC 501 A/D Counts

Example 2

- Reference Voltage 4.80 VDC 1023 A/D Counts
- Command Voltage 2.35 VDC 501 A/D Counts

As you can see by the examples, even though the Command Voltages are different between Examples 1 and 2, the resulting A/D counts, are the same because of the different Reference Voltages. This would result in the Processor commanding the identical outputs (Clutch & Throttle) in both cases.

- A The A/D count for a specific Control Head’s lever can be seen on the Processor’s Display by following the steps outlined in section 10.5: Diagnostic Menu.
- B Once the appropriate remote station is reached, ensure that the displayed A/D Count represents the Neutral/Idle position (485- 505 A/D counts). Command will not be accepted unless the Control Head’s lever is at the Neutral/Idle position.

The following table shows the appropriate A/D Counts for various Control Head lever positions:

Table 10-2: Control Head Lever A/D Counts

Control Head Lever Position	A/D Count
Lever Out of Range Low	100
Full Astern	153 - 173

Table 10-2: Control Head Lever A/D Counts

Control Head Lever Position	A/D Count
Neutral/ Idle	485 - 505
Control Head Lever Position	A/D Count
Ahead Shift Point	537
Full Ahead	821 - 841
Lever Out of Range High	910

10.7.3 Remote Station Select

The second required item for taking command is “Station Select” or depressing of the Transfer Button.

- The Transfer Button can be tested by entering the Diagnostic Menu **H0**.
 - A Depress the Up or Down (scroll) Push Button until four zeroes are displayed without decimal points as shown in Figure 10-11: Display Station A/D’s No Station Transfer Button Depressed.



Figure 10-11: Display Station A/D’s No Station Transfer Button Depressed

- B For Stations 1 - 4 when the Transfer Button is depressed, the 0 which represents that remote station, will change to a 1 as shown in Figure 10-12: Example Display Station A/D’s Transfer Button Depressed for Stations 1 - 4. For Station 5 when the Transfer Button is depressed, all four decimal points will light as shown in Figure 10-13: Display Station A/D/s Transfer Button Depressed for Station 5




Figure 10-12: Example Display Station A/D’s Transfer Button Depressed for Stations 1 - 4




Figure 10-13: Display Station A/D/s Transfer Button Depressed for Station 5

- Whenever command cannot be gained at a particular remote station, the Station Select and Command Signals are the first to be investigated. If either the Command Signal is out of range or the Station Select is inoperable, command will not be accepted at that remote station.

10.7.4 Stuck Transfer Button

The Transfer Button is a normally open, momentary switch. The only time the switch should close is when it is depressed to take command or when entering or departing various other functions. In the event that the Transfer Button became stuck in the closed position, the following will occur:

- The Transfer Button would have to be closed for 15 seconds or more.

- The throttle and clutch are not affected.
- A solid tone is heard from all remote stations, until the button's contact opens or transfer to another remote station has taken place.

If a Control Head that is not in command has a stuck transfer button, the following will happen:

- If Control Head levers are positioned at Neutral/Idle, a solid tone is heard from all remote stations.
- If Control Head levers are positioned other than Neutral/Idle, a three (3) second tone is heard from all remote stations.
- Error Code **33 - 42**, depending on which remote station, will be shown on the Processor Display.
- Command can be taken at any other operational remote station.
- After one (1) second command can be regained at the remote station with the stuck button as long as the problem has been corrected by depressing the transfer button.

If a stuck Transfer Button is suspected, this can be verified by looking at the Station Select status (**1** or **0**) as outlined in section 10.7.3: Remote Station Select.

- An Error Code **33 - 42** will be shown on the Display, depending on which Station is experiencing the problem.

10.7.5 Engine Room / Remote Switch

A defective (open) switch will prevent the transfer of command on one side (port or starboard) only, while command is transferred to the Engine Room Station on the other side (split control). A switch with a shorted contact will prevent any station, other than Station 1 from taking command on one side.

A suspected faulty switch can be verified by following the steps below:

- A Turn the Engine Room/ Remote 'OFF' (open contact).
- B Measure the DC voltage across the switch contact.
 - If 5.00 ± 0.2 VDC is measured, continue with step C).
 - If approximately 0 VDC is measured, skip ahead to step F).
- C Turn the Engine Room/ Remote Switch 'ON' (closed contact).
- D Measure the DC voltage across the switch contact.
 - If 5.00 ± 0.2 VDC is measured, the switch is defective and must be replaced.
 - If approximately 0 VDC is measured, continue with step E).
- E At the Processor, scroll down to Function Code **A5** and ensure a value of **01** or **03** is entered.
 - If **A5** is not set to **01** or **03**, it must be changed.
 - If **A5** is set to **01** or **03**, the Processor is defective and must be replaced.
- F If 0 VDC was measured in step B), measure the DC voltage at TB10, pins 1 and 2 on the Processor's circuit board.
 - If 5.00 ± 0.2 VDC is measured, the cable between the switch and the Processor has an open conductor or is not terminated properly.
 - If approximately 0 VDC is measured, continue with step G).
- G Disconnect the two conductors from TB10, pins 1 and 2.
- H Measure the DC voltage across TB10, pins 1 and 2.
 - If approximately 0 VDC is measured, the Processor is defective and must be replaced.

- If 5.00 ± 0.2 VDC is measured, continue with step I).
- I Disconnect the two conductors from the switch contact.
- J Measure the resistance across the switch contact.
 - If infinite resistance is measured, the switch is good and the cable's conductors are short circuited and must be replaced.
 - If approximately 0 Ohms is measured, the switch is defective and must be replaced.

10.7.6 Station 2 Lockout Switch

If the switch itself failed, the failure would be either an OPEN contact (will not CLOSE) or a CLOSED contact (will not OPEN).

If the switch were to fail in a manner where the contact will not CLOSE, the system would not prevent a Remote Station from taking command on one side.

If the switch were to fail in a CLOSED manner, no station would be able to take command away from Station 2, other than Station 1.

A suspected faulty switch can be verified as follows:

- A Turn the Station 2 Lockout Switch 'OFF' (OPEN contact).
- B Measure the DC voltage across the switch contact.
 - If 5.00 ± 0.2 VDC is measured, continue with step C).
 - If approximately 0 VDC is measured, skip ahead to step F).
- C Turn the Station 2 Lockout Switch 'On' (closed contact).
- D Measure the DC voltage across the switch contact.
 - If 5.00 ± 0.2 VDC is measured, the switch is defective and must be replaced.
 - If approximately 0 VDC is measured, continue with step E).
- E At the Processor, scroll down to Function Code A5 and ensure a value of 01 or 03 is entered.
 - If A5 is not set to 02 or 03, it must be changed.
 - If A5 is set to 02 or 03, the Processor is defective and must be replaced.
- F If 0 VDC was measured in step B), measure the DC voltage at TB10, pins 3 and 4 on the Processor's circuit board.
 - If 5.00 ± 0.2 VDC is measured, the cable between the switch and the Processor has an open conductor or is not terminated properly.
 - If approximately 0 VDC is measured, continue with step G).
- G Disconnect the two conductors from TB10, pins 3 and 4.
- H Measure the DC voltage across TB10, pins 3 and 4.
 - If approximately 0 VDC is measured, the Processor is defective and must be replaced.
 - If 5.00 ± 0.2 VDC is measured, continue with step I).
- I Disconnect the two conductors from the switch contact.
- J Measure the resistance across the switch contact.
 - If infinite resistance is measured, the switch is good and the cable's conductors are short circuited and must be replaced.
 - If approximately 0 Ohms is measured, the switch is defective and must be replaced.

10.8 Error Codes

As stated previously, if a problem with the Control System is detected, the Processor is programmed to display numerous Error Codes to aid in the isolation of the cause. The following tables list these Error Codes, along with a brief description.

Table 10-3: Basic Error Codes

Error #	Title	Description
13	Station No.1 Faulted High	Station No.1 Control Head's lever position is out of range. The input appears to be too high.
14	Station No.2 Faulted High	Station No.2 Control Head's lever position is out of range. The input appears to be too high.
15	Station No.3 Faulted High	Station No.3 Control Head's lever position is out of range. The input appears to be too high.
16	Station No.4 Faulted High	Station No.4 Control Head's lever position is out of range. The input appears to be too high.
17	Station No.5 Faulted High	Station No.5 Control Head's lever position is out of range. The input appears to be too high.
18	Station No.6 Faulted High	Station No.6 Control Head's lever position is out of range. The input appears to be too high.
19	Station No.7 Faulted High	Station No.7 Control Head's lever position is out of range. The input appears to be too high.
20	Station No.8 Faulted High	Station No.8 Control Head's lever position is out of range. The input appears to be too high.
21	Station No.9 Faulted High	Station No.9 Control Head's lever position is out of range. The input appears to be too high.
22	Station No.10 Faulted High	Station No.10 Control Head's lever position is out of range. The input appears to be too high.
23	Station No.1 Faulted Low	Station No.1 Control Head's lever position is out of range. The input appears to be too low.
24	Station No.2 Faulted Low	Station No.2 Control Head's lever position is out of range. The input appears to be too low.
25	Station No.3 Faulted Low	Station No.3 Control Head's lever position is out of range. The input appears to be too low.
26	Station No.4 Faulted Low	Station No.4 Control Head's lever position is out of range. The input appears to be too low.
27	Station No.5 Faulted Low	Station No.5 Control Head's lever position is out of range. The input appears to be too low.
28	Station No.6 Faulted Low	Station No.6 Control Head's lever position is out of range. The input appears to be too low.
29	Station No.7 Faulted Low	Station No.7 Control Head's lever position is out of range. The input appears to be too low.
30	Station No.8 Faulted Low	Station No.8 Control Head's lever position is out of range. The input appears to be too low.

Table 10-3: Basic Error Codes

Error #	Title	Description
31	Station No.9 Faulted Low	Station No.9 Control Head's lever position is out of range. The input appears to be too low.
32	Station No.10 Faulted Low	Station No.10 Control Head's lever position is out of range. The input appears to be too low.
33	Station No.1 Button Stuck Closed	Station No.1 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
34	Station No.2 Button Stuck Closed	Station No.2 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
35	Station No.3 Button Stuck Closed	Station No.3 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
36	Station No.4 Button Stuck Closed	Station No.4 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
37	Station No.5 Button Stuck Closed	Station No.5 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
38	Station No.6 Button Stuck Closed	Station No.6 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
39	Station No.7 Button Stuck Closed	Station No.7 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
40	Station No.8 Button Stuck Closed	Station No.8 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
41	Station No.9 Button Stuck Closed	Station No.9 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
42	Station No.10 Button Stuck Closed	Station No.10 Control Head's Transfer Button has either been closed too long or has been closed since power-up.
43	CAN Communication Stuffing Error	The Control-Area-Network protocol has detected an error in communication with other devices on the network. The error type is a stuffing error.
44	CAN Communication Form Error	The Control-Area-Network protocol has detected an error in communication with other devices on the network. The error type is a form error.
45	CAN Communication Acknowledge Error	The Control-Area-Network protocol has detected an error in communication with other devices on the network. The error type is an acknowledge error.
46	CAN Communication Bit 1 Error	The Control-Area-Network protocol has detected an error in communication with other devices on the network. The error type is a Bit 1 error.
47	CAN Communication Bit 0 Error	The Control-Area-Network protocol has detected an error in communication with other devices on the network. The error type is a Bit 0 error.
48	CAN Communication CRC Error	The Control-Area-Network protocol has detected an error in communication with other devices on the network. The error type is a CRC error.
49	CAN Communication Bus Error	The Control-Area-Network protocol has detected an error in communication with other devices on the network. The error type is a Bus failure error. The error cannot be recovered from without cycling power to the Processor.
50	Comm. Error Time-out System 1	Communication with System 1 has been too long without a Refresh message

Table 10-3: Basic Error Codes

Error #	Title	Description
51	Comm. Error Time-out System 2	Communication with System 1 has been too long without a Refresh message
52	Comm. Error Time-out System 3	Communication with System 1 has been too long without a Refresh message
53	Comm. Error Time-out System 4	Communication with System 1 has been too long without a Refresh message
54	Comm. Error Time-out System 5	Communication with System 1 has been too long without a Refresh message
55	SE Communication Error	Communication with the Station Expander has been too long without a Refresh message.
56	High Battery Voltage Fault	The applied battery voltage is 30VDC or higher for at least two seconds.
57	Low Battery Voltage Fault	The applied battery voltage is 10VDC or lower for at least two seconds.
58	Reset Due to Software Watchdog	The system has had an unexpected Reset, due to a software problem.
59	Reset Due to Software Fault	The system has had an unexpected Reset, due to a software problem.
60	Reset Due to Hardware Watchdog	The system has had an unexpected Reset, due to a hardware problem.
61	Oscillator Watchdog	The system Oscillator has experienced a malfunction.

Table 10-4: Servo 1 Error Codes

Error #	Title	Description
62	Servo 1 Jam	Servo one is unable to make any progress toward its commanded position
63	Servo 1 Feedback High	Servo one's position feedback voltage is higher than the acceptable range.
64	Servo 1 Feedback Low	Servo one's position feedback voltage is lower than the acceptable range.

Table 10-5: Servo 2 Error Codes

Error #	Title	Description
65	Servo 2 Jam	Servo two is unable to make any progress toward its commanded position
66	Servo 2 Feedback High	Servo two's position feedback voltage is higher than the acceptable range.
67	Servo 2 Feedback Low	Servo two's position feedback voltage is lower than the acceptable range.

10.9 Problem Causes And Solutions

The following table lists the various Error Codes and provides possible causes and solutions. Error Codes appearing on the Port side Processor's Display LED are port side errors and vice versa. The Causes and Solutions provided are the most likely, but are not the only possible causes for the Errors Codes listed.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE	SOLUTION
13	a Station No.1 Control Head is defective.	a Replace Station No.1 Control Head.
	b No continuity between pin 5's of the Control Head Harness connectors.	b Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c Control Head jumper (pin 3 to 5 or 7) is missing.	c Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads
14	a The Station No.2 Control Head is defective.	a Replace Station No.2 Control Head.
	b No continuity between pin 5's of the Control Head Harness connectors.	b Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c Control Head jumper (pin 3 to 5 or 7) is missing	c Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
15	a The Station No.3 Control Head is defective.	a Replace Station No.3 Control Head.
	b o continuity between pin 5's of the Control Head Harness connectors.	b Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c Control Head jumper (pin 3 to 5 or 7) is missing.	c Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
16	a The Station No.4 Control Head is defective.	a Replace Station No.4 Control Head.
	b No continuity between pin 5's of the Control Head Harness connectors.	b Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c Control Head jumper (pin 3 to 5 or 7) is missing.	c Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
17	a The Station No.5 Control Head is defective.	a Replace Station No.5 Control Head.
	b No continuity between pin 5's of the Control Head Harness connectors.	b Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c Control Head jumper (pin 3 to 5 or 7) is missing.	c Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
18	a The Station No.6 Control Head is defective.	a Replace Station No.6 Control Head.
	b No continuity between pin 5's of the Control Head Harness connectors.	b Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c Control Head jumper (pin 3 to 5 or 7) is missing.	c Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE		SOLUTION	
19	a	The Station No.7 Control Head is defective.	a	Replace Station No.7 Control Head.
	b	No continuity between pin 5's of the Control Head Harness connectors.	b	Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c	Control Head jumper (pin 3 to 5 or 7) is missing.	c	Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
20	a	The Station No.8 Control Head is defective.	a	Replace Station No.8 Control Head.
	b	No continuity between pin 5's of the Control Head Harness connectors.	b	Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c	Control Head jumper (pin 3 to 5 or 7) is missing.	c	Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
21	a	The Station No.9 Control Head is defective.	a	Replace Station No.9 Control Head.
	b	No continuity between pin 5's of the Control Head Harness connectors.	b	Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c	Control Head jumper (pin 3 to 5 or 7) is missing.	c	Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
22	a	The Station No.10 Control Head is defective.	a	Replace Station No.10 Control Head.
	b	No continuity between pin 5's of the Control Head Harness connectors.	b	Ensure that the red conductor is properly crimped to pin 5 at both connectors.
	c	Control Head jumper (pin 3 to 5 or 7) is missing.	c	Install a jumper from pin 3 to 5 on right hand and 3 to 7 on left hand Control Heads.
23	a	The Station No.1 Control Head is defective.	a	Replace Station No.1 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
24	a	The Station No.2 Control Head is defective.	a	Replace Station No.2 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
25	a	The Station No.3 Control Head is defective.	a	Replace Station No.3 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE		SOLUTION	
26	a	The Station No.4 Control Head is defective.	a	Replace Station No.4 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
27	a	The Station No.5 Control Head is defective.	a	Replace Station No.5 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
28	a	The Station No.6 Control Head is defective.	a	Replace Station No.6 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
29	a	The Station No.7 Control Head is defective.	a	Replace Station No.7 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
30	a	The Station No.8 Control Head is defective.	a	Replace Station No.8 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
31	a	The Station No.9 Control Head is defective.	a	Replace Station No.9 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.
32	a	The Station No.10 Control Head is defective.	a	Replace Station No.10 Control Head.
	b	No continuity between pin 6's of the Control Head Harness connectors.	b	Ensure that the green conductor is properly crimped to pin 6 at both connectors and there is continuity.
	c	No continuity between pin 7's of the Control Head Harness connectors.	c	Ensure that the blue conductor is properly crimped to pin 7 at both connectors and there is continuity.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE	SOLUTION
33	a The Station No.1 transfer button was held down for 15 seconds or longer	a Clear the Error Code from memory
	b The Station No.1 Control Head transfer button is defective	b Replace the Control Head
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. In addition, ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.
34	a The Station No.2 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.2 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.
35	a The Station No.3 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.3 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE	SOLUTION
36	a The Station No.4 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.4 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.
37	a The Station No.5 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.5 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.
38	a The Station No.6 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.6 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE	SOLUTION
39	a The Station No.7 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.7 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.
40	a The Station No.8 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.8 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.
41	a The Station No.9 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.9 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE	SOLUTION
42	a The Station No.10 transfer button was held down for 15 seconds or longer.	a Clear the Error Code from memory.
	b The Station No.10 Control Head transfer button is defective.	b Replace the Control Head.
	c The Control Head Harness is mis-wired.	c Ensure that the orange conductor is crimped to pin 4 at both ends and the red wire is crimped to pin 5 at both ends of the Harness.
	d The Control Head's Pigtail is mis-wired.	d Ensure that the orange conductor is crimped to pin 4 of the connector and connected to pin 4 of the Control Head's terminal block. Ensure that the red conductor is crimped to pin 5 of the connector and connected to pin 3 of the Control Head's terminal block.
43	a The Serial Harness is in excess of 120 feet (37m).	a Reposition the Processor(s) so that the Serial Harness is less than 120 feet (37m).
	b The Processor is defective.	b Replace the faulty Processor.
	c The Serial Harness's shield is not properly terminated.	c Ensure that the shield is terminated and the termination is at one side only.
44	a The Serial Harness is in excess of 120 feet (37m).	a Reposition the Processor(s) so that the Serial Harness is less than 120 feet (37m).
	b The Processor is defective.	b Replace the faulty Processor.
	c The Serial Harness's shield is not properly terminated.	c Ensure that the shield is terminated and the termination is at one side only.
45	a The Serial Harness is not connected at one or more Processors.	a Ensure that the Serial Harness is properly seated at all Processors.
	b The Serial Harness is incorrectly wired.	b Refer to the Serial Plug pin-out in Appendix B. Correct or replace the Harness.
	c Loss of power to one of the Processor.	c Restore Power to the Processor.
46	a The Serial Harness is in excess of 120 feet (37m)	a Reposition the Processor(s) so that the Serial Harness is less than 120 feet (37m).
	b The Processor is defective.	b Replace the faulty Processor.
	c The Serial Harness's shield is not properly terminated.	c Ensure that the shield is terminated and the termination is at one side only.
47	a The Serial Harness is in excess of 120 feet (37m).	a Reposition the Processor(s) so that the Serial Harness is less than 120 feet (37m).
	b The Processor is defective.	b Replace the faulty Processor.
	c The Serial Harness's shield is not properly terminated	c Ensure that the shield is terminated and the termination is at one side only.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE	SOLUTION
48	a The Serial Harness is in excess of 120 feet (37m).	a Reposition the Processor(s) so that the Serial Harness is less than 120 feet (37m).
	b The Processor is defective.	b Replace the faulty Processor.
	c The Serial Harness's shield is not properly terminated.	c Ensure that the shield is terminated and the termination is at one side only.
49	a The Serial Harness is in excess of 120 feet (37m).	a Reposition the Processor(s) so that the Serial Harness is less than 120 feet (37m).
	b The Processor is defective.	b Replace the faulty Processor.
	c The Serial Harness's shield is not properly terminated.	c Ensure that the shield is terminated and the termination is at one side only.
50	a The Serial Harness is not connected at Processor ID No.1.	a Connect the Serial Harness into Processor ID No.1.
	b None of the Processors has ID No. 1 selected.	b Identify one of the Processors as ID No.1 with the A0 function.
	c Loss of power to Processor ID No.1.	c Restore power to Processor ID No.1.
51	a The Serial Harness is not connected at Processor ID No.2.	a Connect the Serial Harness into Processor ID No.2.
	b None of the Processors has ID No.2 selected.	b Identify one of the Processors as ID No.2 with the A0 function.
	c Loss of power to Processor ID No.2	c Restore power to Processor ID No.2.
52	a The Serial Harness is not connected at Processor ID No.3.	a Connect the Serial Harness into Processor ID No.3.
	b None of the Processors has ID No.3 selected.	b Identify one of the Processors as ID No.3 with the A0 function.
	c Loss of power to Processor ID No.3.	c Restore power to Processor ID No.3.
53	a The Serial Harness is not connected at Processor ID No.4.	a Connect the Serial Harness into Processor ID No.4.
	b None of the Processors has ID No.4 selected.	b Identify one of the Processors as ID No.4 with the A0 function.
	c Loss of power to Processor ID No.4.	c Restore power to Processor ID No.4.
54	a The Serial Harness is not connected at Processor ID No.5.	a Connect the Serial Harness into Processor ID No.5.
	b None of the Processors has ID No.5 selected.	b Identify one of the Processors as ID No.5 with the A0 function.
	c Loss of power to Processor ID No.5.	c Restore power to Processor ID No.5.

Table 10-6: Basic Control System Problem Causes and Solutions

Error #	CAUSE	SOLUTION
55	a The Serial Harness is not connected to the SE.	a Connect the Serial Harness to the SE.
	b The Serial Harness is not connected to the Processor reporting the fault.	b Connect the Serial Harness to the Processor reporting the fault.
	c No power to the SE.	c Turn power 'On' to the SE.
56	a The battery is being overcharged.	a Repair or replace the charging system.
	b There's a loose terminal on the battery while being charged.	b Clean and tighten the battery posts and terminals.
57	a Battery will not take a charge and is defective.	a Replace the battery.
	b The battery is not being properly charged	b Repair or replace the charging system.
	c There's a high resistance connection between the battery and the Processor.	c Locate and repair the high resistance connection
58	a External Interference, such as a lightning strike.	a If the error message is displayed once and you are able to clear the error, take no further actions at this time. If the error cannot be cleared, replace the Processor.
	b Component failure.	b Replace the Processor.
59	a External Interference, such as a lightning strike.	a If the error message is displayed once and you are able to clear the error, take no further actions at this time. If the error cannot be cleared, replace the Processor.
	b Component failure.	b Replace the Processor.
60	a External Interference, such as a lightning strike.	a If the error message is displayed once and you are able to clear the error, take no further actions at this time. If the error cannot be cleared, replace the Processor.
	b Component failure.	b Replace the Processor.
61	a External Interference, such as a lightning strike.	a If the error message is displayed once and you are able to clear the error, take no further actions at this time. If the error cannot be cleared, replace the Processor.
	b Component failure.	b Replace the Processor.

Table 10-7: Servo 1 Clutch Problem Causes and Solutions

Error #	CAUSE	SOLUTION
62	a Excessive Clutch Push-Pull cable travel.	a Readjust Function Code C6 and or C7.
	b The load on the Push-Pull cable exceeds 40 Lbs.	b Contact a certified Marine Transmission technician to determine the cause of the excessive load.
	c The Push-Pull cable is defective.	c Replace the Push-Pull cable
	d The Processor's Clutch Servo (Servo 1) is defective.	d Replace the Processor.
	e Low battery voltage.	e Charge, repair or replace the battery, charging system or power distribution system.

Table 10-7: Servo 1 Clutch Problem Causes and Solutions

Error #	CAUSE	SOLUTION
63	a The Clutch Servo's feedback potentiometer is out of calibration.	a Replace the Processor or calibrate the potentiometer.
	b The Clutch Servo's feedback potentiometer is defective.	b Replace the Processor or replace the potentiometer.
	c The Processor's Circuit Board is defective.	c Replace the Processor or the Circuit Board.
64	a The Clutch Servo's feedback potentiometer is out of calibration.	a Replace the Processor or calibrate the potentiometer.
	b The Clutch Servo's feedback potentiometer is unplugged from the Circuit Board.	b Plug the feedback potentiometer's brown plug into the Circuit Board.
	c The Clutch Servo's feedback potentiometer is defective.	c Replace the Processor or the feedback potentiometer
	d The Processor's Circuit Board is defective.	d Replace the Processor or the Circuit Board.

Table 10-8: Servo 2 Throttle Problem Causes and Solutions

Error #	CAUSE	SOLUTION
65	a Excessive Throttle Push-Pull cable travel.	a Readjust Function Code E2 and or E3.
	b The load on the Push-Pull cable exceeds 40 Lbs.	b Contact a certified Marine Transmission technician to determine the cause of the excessive load..
	c The Push-Pull cable is defective.	c Replace the Push-Pull cable
	d The Processor's Throttle Servo (Servo 2) is defective.	d Replace the Processor.
	e Low battery voltage.	e Charge, repair or replace the battery, charging system or power distribution system.
66	a The Throttle Servo's feedback potentiometer is out of calibration.	a Replace the Processor or calibrate the potentiometer.
	b The Throttle Servo's feedback potentiometer is defective.	b Replace the Processor or replace the potentiometer.
	c The Processor's Circuit Board is defective.	c Replace the Processor or the Circuit Board.
67	a The Throttle Servo's feedback potentiometer is out of calibration.	a Replace the Processor or calibrate the potentiometer.
	b The Throttle Servo's feedback potentiometer is unplugged from the Circuit Board.	b Plug the feedback potentiometer's brown plug into the Circuit Board.
	c The Throttle Servo's feedback potentiometer is defective.	c Replace the Processor or the feedback potentiometer
	d The Processor's Circuit Board is defective.	d Replace the Processor or the Circuit Board.

10.10 Problems Without Error Codes

In addition to the Error Codes listed above, some problems may not necessarily generate Error Codes. The following give some examples where the Processor may not detect a fault, though the operation may not be perfect:

10.10.1 Basic Control System Problems Without Error Codes

- A **SYMPTOM:** No audible tones heard at one Control Station when power is first applied to the Processor. All other features function normally.

Table 10-9: Basic Control System Problems Without Error Codes (Symptom: A)

Cause		Remedy	
a.	Incorrectly wired Station Harness/ Cable.	a.	Verify that the black wire is properly connected to pin 1 on the Control Head and Pin 8 at the Processor.
b.	The Control Head's Sound Transducer is defective.	b.	Measure the AC voltage at pins 1 & 3 of the Control Head. If 20- 25 VAC is present, replace the Control Head.

- B **SYMPTOM:** The Control Head's red LED doesn't light when in command, but otherwise functions properly

Table 10-10: Basic Control System Problems Without Error Codes (Symptom: B)

Cause		Remedy	
a.	Incorrectly wired Station Harness/ Cable.	a.	Verify that the brown wire is properly connected to pin 2 on the Control head and pin 2 at the Processor.
b.	The Control Head's red LED or circuit is open.	b.	Measure the DC voltage at pins 2 & 3 at the Control Head. The measurement will be approximately 2.20 VDC when the red LED is lit. If 4.00 VDC is measured, the red LED or its circuit is open. Replace the Control Head.

- C **SYMPTOM:** The engine begins to turn-over while starting and then stops. A slow repetitive tone is heard from all Remote Stations

Table 10-11: Basic Control System Problems Without Error Codes (Symptom: C)

Cause		Remedy	
a.	The voltage available at the Processor has dropped too low, due to the starter's current requirement	a.	Supply power to the Processor from a battery other than the starting battery or supply power from two sources through an APS (Automatic Power Selector).
b.	Battery charge is too low	b.	Recharge/ replace the battery or supply battery power from two sources through an APS.

- D **SYMPTOM:** When power is turned ON to the Processor, there are no tones from any of the Remote Stations, the Control Head red LED does not light when the Transfer Button is pressed, and the Display is not lit at the Processor.

Table 10-12: Basic Control System Problems Without Error Codes (Symptom: D)

Cause		Remedy	
a.	No power to the Processor.	a.	Disconnect the Power Harness from the Processor. Measure the DC voltage at pins 10 (+) and 11 (-) of the Harness plug. If 12 or 24 VDC is not present, check the circuit breakers, switches and cables feeding power to the Processor. Correct the power source as required.
b.	The battery's polarity is reversed at the Processor.	b.	Disconnect the Power Harness from the Processor. Connect a voltmeter's red lead to pin 10 and the black lead to pin 11 of the Harness's plug. If negative voltage is measured, reverse the wires.
c.	Defective Processor.	c.	If Causes a. and b. were not the fault, replace the Processor.

- E **SYMPTOM:** Active Synchronization is inoperable.

Table 10-13: Basic Control System Problems Without Error Codes (Symptom: E)

Cause		Remedy	
a.	There is no Tachometer Sensor signal at the Port or Starboard Processor.	a.	The Tachometer Sensor frequency can be seen on the Processor's Display by accessing the Diagnostic Menu H0 . If the frequency is not measured, check the Tachometer Sensor and the wiring.
b.	Loss of Serial Communication between the Processors.	b.	If Active Synchronization is inoperative due to a lack of Serial Communications, one or more Error Codes will be displayed indicating the loss of communication.
c.	The Processor's Identification number(s) have not been set properly.	c.	All Processors must have a unique identification number as set with Function Code A0 . Refer to section 5: Set Up Procedures.
d,	The correct number of engines has not been set.	d,	All Processor must have the same number of engines selected as programmed with Function Code A1 . Refer to section 5: Set Up Procedures.

10.10.2 Servo Clutch Problems Without Error Codes

- A **SYMPTOM:** Cannot obtain Warm-up Mode while moving the Control Head lever in the Ahead direction, only in the Astern direction.

Table 10-14: Servo Clutch Problems Without Error Codes (Symptom: A)

Cause		Remedy	
a.	The Processor is sensing that the Control Head's lever is moving in the Astern direction	a.	<p>Depress the Transfer Button while moving the Control Head lever in the Astern direction. If the LED begins to blink, the Control Head is incorrectly wired.</p> <ul style="list-style-type: none"> • Check the colors of the wires at pins 5 and 7. • A right hand Control Head should have yellow at pin 5 and blue at pin 7. • A left hand Control Head should have blue at pin 5 and yellow at pin 7. • The Clutch Servo's direction of travel must be changed with Function Code C5 if the yellow and blue wires are reversed.

- B **SYMPTOM:** The engine RPM's vary, without moving the Control Head lever (synchronization disabled).

Table 10-15: Servo Clutch Problems Without Error Codes (Symptom: B)

Cause		Remedy	
a.	Problem with the Governor or Carburetor.	a.	Observe the Throttle push-pull cable. If variations are seen, proceed to Step b.
b.	Erratic Command Signal.	b.	Refer to section 10.7.1: Command Signal . If variations of the A/D counts occur, connect the Control Head to another Station (if available) on the Processor. If variations persist, replace the Control Head.

- C **SYMPTOM:** The engine's Idle speed is too high.

Table 10-16: Servo Clutch Problems Without Error Codes (Symptom: C)

Cause		Remedy	
a.	Idle was not adjusted mechanically correct at the Idle stop.	a.	Adjust the throttle Push-Pull cable as specified in section 5: Set Up Procedures.
b.	Function Code E2 Throttle Minimum is incorrectly set.	b.	Adjust Throttle Minimum as specified in section 5: Set Up Procedures.
c.	The Governor or its Control Module is incorrectly adjusted or faulty.	c.	After Causes a. and b. have been eliminated, contact a certified engine mechanic to properly adjust.

10.11 Synchronization Troubleshooting

If you encounter a problem with Synchronization, it will more than likely one of the following; failure to attempt to synchronize, synchronizing at different RPM's or RPM variations of one or both engines while synchronized. Each problem is distinct and the cause may differ depending on the type of Synch. Therefore, each type is discussed individually.

10.11.1 Equal Throttle Synchronization

A SYMPTOM: Will not synchronize.

Table 10-17: Equal Throttle Synchronization (Symptom: A)

Cause		Remedy	
a.	Synchronization is Disabled	a.	At the Station-in-Command, move both Control Head levers to more than 5% of the speed range. Press and hold the transfer button for 5 seconds. If synch is disabled, the green LED will light as long as the button is pressed. If synch was enabled, the green LED would have blinked twice.
b.	The Serial Communication Harness is not plugged into both Processors.	b.	Plug the Serial Communication Harness into both Processors.
c.	The Port and Starboard Processors are not set up for Twin Screw operation.	c.	Plug the Serial Communication Harness into both Processors.
d.	The Port and Starboard Processors have the same ID number.	d.	On the Port Processor, scroll to Function A0 and enter a Value of 01. On the Starboard Processor, scroll to Function A0 and enter a Value of 02.

10.11.2 Servo Clutch Troubleshooting

A SYMPTOM: Will not synchronize.

Table 10-18: Servo Clutch Troubleshooting (Symptom: A)

Cause		Remedy	
a.	The Processor(s) think Astern is being commanded.	a.	Place both the Port and Starboard Processors into Warm-up Mode by pressing the transfer button while moving the Control Head levers to the Ahead detent. Both red LED's on the Control Head should be blinking. If not, reverse the wires at pins 5 and 7 at the Control Head. Change the Clutch direction with Function Code C5.

- B **SYMPTOM:** One or both of the engines continually changes RPM (hunts). Will not synchronize properly.

Table 10-19: Servo Clutch Troubleshooting (Symptom: B)

Cause		Remedy	
a.	A Control Head's Command Signal is varying.	a.	Scroll to the Diagnostic Menu Function Code H0. Go to the appropriate Station A/D Count's display. The Value should not change by more than +/- 1 A/D Count. If so, check the connections and if good, replace the Control Head.
b.	The push-pull cable's travel from Idle to Full is too short.	b.	Lengthen the Governor or Carburetor's selector lever and attach the push-pull cable to a point where the travel is in excess of 2.00 inches (50,8mm).

- C **SYMPTOM:** Will not synchronize.

Table 10-20: Servo Clutch Troubleshooting (Symptom: C)

Cause		Remedy	
a.	Excessive bends in the push-pull cable(s).	a.	Reroute the push-pull cable(s) or install Tach Sender and enable Active Synchronization with Function Code E7.

- D **SYMPTOM:** The green LED is lit solid, though the Engine RPM's differ by a significant amount.

Table 10-21: Servo Clutch Troubleshooting (Symptom: D)

Cause		Remedy	
a.	The throttle travel from Idle to Full is set differently on the Port and Starboard Processors.	a.	Scroll to Function Codes E2 and E3 on both Processors and compare the Values. The Values of E2 and E3 must be the same for both Processors.
b.	The engines run at different RPM's with equal travel of the Governors'/ Carburetors' selector lever.	b.	While underway at cruising speed, decrease the Value of Function Code E3 on the Processor running at the higher RPM until both engine are at the same RPM. This is not a normal condition and is masking the actual problem with the engine. Top speed may be sacrificed by doing so. Install Tach Senders and enable Active Synchronization with Function Code E7
c.	Excessive back-lash in the push-pull cable(s) or linkage.	c.	Remove the excessive back-lash or install Tach Senders and enable Active Synchronization with Function Code E7.

Table 10-21: Servo Clutch Troubleshooting (Symptom: D)

Cause		Remedy	
d.	Excessive bends in the push-pull cable(s).	d.	Reroute the push-pull cable(s) or install Tach Sender and enable Active Synchronization with Function Code E7.

10.11.3 Active Synchronization

- A **SYMPTOM:** The green LED is lit solid, though the Engine RPM's differ by a significant amount..

Table 10-22: Active Synchronization (Symptom: A)

Cause		Remedy	
a.	The Tach Sender signal has been lost by one or both Processors.	a.	Scroll to Function Code H0. Go to the Value for the Tach Sender's input frequency. If the frequency displayed is 0000, the signal has been lost and the system diverted to Equal Throttle Synch. Correct the wiring or replace the Sender.

- B **SYMPTOM:** Will not synchronize..

Table 10-23: Active Synchronization (Symptom: B)

Cause		Remedy	
a.	Synchronization is Disabled	a.	At the Station-in-Command, move both Control Head levers to more than 5% of the speed range. Press and hold the transfer button for 5 seconds. If synch is disabled, the green LED will light as long as the button is pressed. If synch was enabled, the green LED would have blinked twice.
b.	The Serial Communication Harness is not plugged into both Processors.	b.	Plug the Serial Communication Harness into both Processors.
c.	The Port and Starboard Processors have the same ID number.	c.	On the Port Processor, scroll to Function Code A0 and enter a Value of 01. On the Starboard Processor, scroll to Function Code A0 and enter a Value of 02.
d.	The Port and Starboard Processors are not set up for twin screw operation	d.	Scroll to Function Code A1, on the Port and Starboard Processor. Enter a Value of 02 into both Processors.

10.11.4 Servo Throttle Troubleshooting

A **SYMPTOM:** One or both of the engines continually changes RPM. Will not synchronize properly.

Table 10-24: Servo Throttle Troubleshooting (Symptom: A)

Cause		Remedy	
a.	A Control Head's Command Signal is varying.	a.	Scroll to the Diagnostic Menu Function Code H0. Go to the appropriate Station A/D Count's display. The Value should not change by more than +/- 1 A/D Count. If so, check the connections and if good, replace the Control Head.
b.	The engine(s) is not running smoothly.	b.	Increase the engines' RPM's in Warm-up Mode. Scroll to Function Code H0 and display the Tach Sender's input frequency. If the frequency is varying, check the push-pull cable for movement. If the push-pull cable is not moving, swap the Port and Starboard Tach Senders. If the frequency still varies on the same side, the engine needs servicing.
c.	Defective Tach Sender	c.	Same procedure as b. However, if the frequency variations move to the opposite side, replace that Tach Sender.

10.11.5 Servo Clutch Troubleshooting

A **SYMPTOM:** Will not synchronize properly.

Table 10-25: Servo Clutch Troubleshooting (Symptom: A)

Cause		Remedy	
a.	Will not synchronize properly	a.	Place both the Port and Starboard Processors into Warm-up Mode by pressing the transfer button while moving the Control Head levers to the Ahead detent. Both red LED's on the Control Head should be blinking. If not, reverse the wires at pins 5 and 7 at the Control Head. Change the Clutch direction with Function Code C5.

10.12 Wire Harnesses

The following Sections list the various Harnesses manufactured for use with the Processor. These tables are invaluable when troubleshooting a suspected interface problem or when manufacturing your own Harnesses.

10.12.1 Basic Control System Harnesses

10.12.1.1 Serial Wire Harnesses

Table 10-26: Wire Harness - Serial Communication (p/n 13316-XX)





Table 10-27: Wire Harness - Serial Communication Multi-Screw (p/n 15544-XX)


Termination A



PIN 1: BLUE (CAN LOW)
 PIN 2: WHITE (CAN HIGH)
 PIN 6: DRAIN WIRE (SHIELD)


DWG: 15544.2_ART

Termination B




CABLE 1 - PIN 1: BLUE (CAN LOW)
 CABLE 1 - PIN 2: WHITE (CAN HIGH)
 CABLE 2 - PIN 5: BLUE (CAN LOW)
 CABLE 2 - PIN 4: WHITE (CAN HIGH)

DWG: 15544.4_ART




PIN 1: BLUE (CAN LOW)
 PIN 2: WHITE (CAN HIGH)
 PIN 6: DRAIN WIRE (SHIELD)

DWG: 15544.3_ART




DWG: 15544.1_ART

Table 10-28: Wire Harness - Serial Communication / CANtrak (p/n 70422-XX)



10.12.1.2 Tachometer Wire Harnesses


Table 10-29: Wire Harness - Tachometer Sensor Harness Pin-Out (p/n 13239-XX)



10.12.1.3 Clutch Wire Harnesses

Table 10-30: Wire Harness- Clutch, Ahead, Astern, Troll Command, Troll On-Off (p/n 70390-XX)


Termination A



- PIN 3: RED (+) (CABLE #1 AHEAD)
- PIN 4: BLACK (-) (CABLE #1 AHEAD/ASTERN)
- PIN 5: WHITE (+) (CABLE #1 ASTERN)
- PIN 9: RED (+) (CABLE #2 TROLL ON/OFF)
- PIN 10: BLACK (-) (CABLE #2 TROLL ON/OFF)
- PIN 11: RED (+) (CABLE #3 TROLL COMMAND)
- PIN 12: BLACK (-) (CABLE #3 TROLL COMMAND)


DWG: 70390.2_ART

Termination B




- PIN A: RED (+) (CABLE #1 AHEAD)
- PIN B: WHITE (+) (CABLE #1 ASTERN)
- PIN F: BLACK (-) (CABLE #1 AHEAD)

DWG: 70390.3_ART




- PIN A: RED (+) (CABLE #3 TROLL COMMAND)
- PIN B: RED (+) (CABLE #2 TROLL ON/OFF)
- PIN C: BLACK (-) (CABLE #2 TROLL ON/OFF)
- PIN F: BLACK (-) (CABLE #3 TROLL COMMAND)

DWG: 70390.4_ART



DWG: 70390.1_ART

Table 10-31: Wire Harness- Clutch, Ahead, Astern, ZFF Transmission (p/n 70673-XX)



10.12.1.4 Power Wire Harnesses

Table 10-32: Power, Start Interlock Harness Pin-Out (p/n 13756-XX)




Table 10-33: Wire Harness - Power, SI & Clutch Pressure Switch (p/n 13552-XX)




Table 10-34: Wire Harness - Power, SI, Clutch Pressure Switch & Alarm (p/n 13631-XX)





Table 10-35: Wire Harness- Power Use W/existing St Intlk Only (p/n 15023-XX)



10.12.1.5 Control Head Wire Harnesses

Table 10-36: Wire Harness - Control Head One Connector (p/n 13557-XX)





Table 10-37: Wire Harness - Control Head Two Connectors (p/n 14261-XX)


Termination A



- PIN 1: GREEN/YELLOW (SHIELD) OR OPTIONAL SHIELD TO SOCKET
- PIN 2: BROWN RED LED (+)
- PIN 3: VIOLET GREEN LED (-) (SYNC)
- PIN 4: ORANGE TRANSFER BUTTON (+)
- PIN 5: RED GROUND
- PIN 6: GREEN LEVER COMMAND SIGNAL
- PIN 7: BLUE VREF (+5VDC)
- PIN 8: BLACK TONE (+)


DWG: 14261.2_ART

Termination B



- PIN 1: GREEN/YELLOW (SHIELD) OR OPTIONAL SHIELD TO SOCKET
- PIN 2: BROWN RED LED (+)
- PIN 3: VIOLET GREEN LED (-) (SYNC)
- PIN 4: ORANGE TRANSFER BUTTON (+)
- PIN 5: RED GROUND
- PIN 6: GREEN LEVER COMMAND SIGNAL
- PIN 7: BLUE VREF (+5VDC)
- PIN 8: BLACK TONE (+)

DWG: 14261.2_ART



DWG: 14261.1_ART



NOTE: (P/N 14261) Starboard Side of Control Head - Jumper Pins 3 to 5;
Port Side of Control Head - Jumper Pins 3 to 7

10.13 Processor Pigtails

The number and types of Pigtails used varies with the different Processors and their configurations. The basic off-the-shelf Processors are available with no Pigtails (hard-wired) or pre-wired for up to a total of eight Pigtails when all five Remote Stations are being used.

The following Tables describe the pin outs and functions of the conductors within the various Pigtails.

10.13.1 Basic Processor Pigtails

Table 10-38: Power, Start Interlock, Clutch Oil Pressure Switch, and Alarm Pigtail Pin-Out (p/n 15710-XX)




Table 10-39: Wire Harness - Serial Com, Processor Lead (p/n 15705-XX)




Table 10-40: Wire Harness - Control Head, Processor Lead (p/n 15706-XX)




Table 10-41: Wire Harness - Throttle, Processor Lead (p/n 15703-XX)




Table 10-42: Wire Harness - Solenoid Clutches, Processor Lead (p/n 15701-XX)





Table 10-43: Wire Harness - Mag Pickup, Processor Lead (p/n 15704-XX)


Termination A

Termination B



- PIN 1: RED
- PIN 2: GREEN
- PIN 3: BLACK
- PIN 4: GRN/YEL (SHIELD)

DWG: 15704.2_ART



DWG: 15704.1_ART

11 Appendix A - System Components and Specifications

protection from water or spray. Consider using a Weather Mount Enclosure, which is available from ZF Marine Electronics.

2. Mounting And Installation:

- A Select the desired mounting locations and make cutouts per template. Refer to Figure MMC-280-3: Dimensions.
- B Check that the four mounting screws will start into the Control Head. Remove the Control Head from the cutout.
- C Remove the backing from the adhesive gasket and apply the gasket adhesive side to the console around the cutout.
- D Run cable/harnesses between Processor and Control Head. Label both ends with the Station ID. (EXAMPLE: Port, Center, or Starboard; Port Thrust, Port Throttle; etc.)

There are two types of Control Head connections available: Plug or Terminal Connected. Both types may be used with MicroCommander, ClearCommand, or CruiseCommand using the appropriate cable or harness. Follow the appropriate steps for the Control Head that has been supplied for your system.



WARNING: Do not mount control head less than 100mm from Compass. Mounting control head too close to compass can cause the compass to malfunction.

3. Type 1 - Pluggable

Plug Control Head cable into the pigtail at the Control Head. (Ensure the correct Processor Cable is being plugged into the corresponding Control Head lever pigtail).

When connecting the plugs, ensure that the release button or buttons are depressed and held until plug is fully connected or disconnected. Connecting or disconnecting plugs without depressing and holding the release button or buttons will damage the plug.

4. Type 2 - Hard-wired

- A Strip back the PVC cover on the shielded cable approximately 2-1/2" (63,5mm) at the Control Head.
- B At the Control Head end of the cable strip and cut off the shielding and drain wire flush with the end of the PVC cover (the drain wire at the Control Head is not connected to ground).
- C Strip 3/8" (9,5mm) insulation off each wire.
- D Twist the individual strands of the wires to minimize fraying.
- E Crimp a locking fork terminal (included with each Control Head) to each of the conductors.
- F Make connections to the Control Head as indicated in the following TERMINAL CONNECTIONS diagrams.




Figure MMC-280-3: Dimensions

ALWAYS REFER TO THE MANUAL THAT IS SUPPLIED WITH THE CONTROL SYSTEM FOR ANY UNIQUE CONTROL HEAD CONNECTIONS FOR YOUR SYSTEM.

When cable connections are complete, MOUNT Control Head to the console using the four (4) mounting screws and washers supplied with the Control Head.

5. CABLE/HARNESS CONNECTIONS:




Figure MMC-280-4: Terminal Connections

Cable/Jumper connections 5 and 7 at the Port and Starboard terminal block are direction sensitive.

MicroCommander/ClearCommand				CruiseCommand/9000 Series			
Port Lever:		Starboard Lever:		Port Lever:		Starboard Lever:	
Terminal 3	Red	Terminal 3	Red	Terminal 3	Red & JUMPER	Terminal 3	Red & JUMPER
Terminal 5	Blue	Terminal 5	Yellow	Terminal 5	Blue	Terminal 5	JUMPER
Terminal 7	Yellow	Terminal 7	Blue	Terminal 7	JUMPER	Terminal 7	Blue

6. Pluggable Connections

Pluggable Control Heads are supplied with a harness pigtail for each lever. When disconnecting/connecting the plugs, ensure that the release button or buttons are depressed and held until plug is fully disconnected or connected. Disconnecting/connecting plugs without depressing and holding the release button or buttons WILL damage the plug.

7. AFT FACING CONTROL HEADS





Figure MMC-280-5: AFT Facing Control Head

For dual lever Control Head Stations that have the user facing aft: Reverse connections 5 and 7.

For single lever Control Head Stations that have the user facing aft and the one Control Head lever on the user's right, reverse connections 5 and 7.

Handheld Control is a Station option. Contact your ZF Marine Electronics Dealer for further information on Handheld requirements and options.



WARNING: Do not mount control head less than 100mm from Compass. Mounting control head too close to compass can cause the compass to malfunction.



WARNING: Note that the dimensions are out of scale, pay attention to properly size the cut out before use !

MC2000 Series Standard Control Head Variations

MMC-329 Revision List

Rev	Date	Description
- to E.1	03/11	Previous date unavailable
E.2	02/15/12	Added compass distance note

This Service Sheet reflects all current variations of the standard 3-detent ZF Marine Electronics MC2000 Series Control Heads




Figure MMC-329-1: Part Numbering Configurations Detents Available

REQUIREMENTS:

MicroCommander/ClearCommand: one (1) 8-Conductor Cable per Control Head lever.

Pluggable MicroCommander/ClearCommand: one (1) Control Head Harness per Control Head lever.

CruiseCommand: one (1) Control Head Harness per Control Head lever.

Included with the Control Head:

- Mounting screws
- Terminals (For 8-Conductor or 1-Connector Harnesses)
- Watertight cable grip for the cable entrance on the Processor (For 8-Conductor)

When the Control Head is properly mounted on a console, it is spray proof from the top only. An adhesive gasket is mounted on the bottom of the Control Head to seal it to the mounting surface. However, below the mounting surface it needs protection from water or spray. Consider using a Weather Mount Enclosure, which is available from ZF Marine Electronics.

MOUNTING AND INSTALLATION:

- A Select the desired mounting locations and make cutouts per template. Refer to Figure MMC-329-2: Dimensions.
- B Check that the two mounting screws will start into the Control Head. Remove Control Head from cutout.
- C Run cable/harnesses between Processor and Control Head. Label both ends with the Station ID. (EXAMPLE: Port, Center, or Starboard; Port Thrust, Port Throttle; etc.)



WARNING: Do not mount control head less than 250mm from Compass.
Mounting control head too close to compass can cause the compass to malfunction.

Dimensions




Figure MMC-329-2: Dimensions

There are two types of Control Head connections available: Plug or Terminal Connected. Both types may be used with MicroCommander, ClearCommand, or CruiseCommand using the appropriate cable or harness. Follow the appropriate steps for the Control Head that has been supplied for your system.

Pluggable

- A Plug Control Head cable into the pigtail at the Control Head. (Ensure the correct Processor Cable is being plugged into the corresponding Control Head lever pigtail).
- B When connecting the plugs, ensure that the release button or buttons are depressed and held until plug is fully connected or disconnected.
- C Connecting or disconnecting plugs without depressing and holding the release button or buttons will damage the plug.

Standard Cable

- A Strip back the PVC cover on the shielded cable approximately 2-1/2" (63,5mm) at the Control Head.
- B At the Control Head end of the cable strip and cut off the shielding and drain wire flush with the end of the PVC cover (the drain wire at the Control Head is not connected to ground).
- C Strip 3/8" (9,5mm) insulation off each wire.
- D Twist the individual strands of the wires to minimize fraying.
- E Crimp a locking fork terminal (included with each Control Head) to each of the conductors.
- F Make connections to the Control Head as indicated in the following TERMINAL CONNECTIONS diagrams.

ALWAYS REFER TO THE MANUAL THAT IS SUPPLIED WITH THE CONTROL SYSTEM FOR ANY UNIQUE CONTROL HEAD CONNECTIONS FOR YOUR SYSTEM.

When cable connections are complete, MOUNT Control Head to the console using the two (2) mounting screws and washers supplied with the Control Head.

CABLE/HARNESS CONNECTIONS:

Dual Control Head Connections




Figure MMC-329-3: Terminal Connections

Cable/Jumper connections 5 and 7 at the Port and Starboard terminal block are direction sensitive.

MicroCommander/ClearCommand		CruiseCommand/9000 Series	
Port Lever:	Starboard Lever:	Port Lever:	Starboard Lever:
Terminal 3 Red	Terminal 3 Red	Terminal 3 Red & JUMPER	Terminal 3 Red & JUMPER
Terminal 5 Blue	Terminal 5 Yellow	Terminal 5 Blue	Terminal 5 JUMPER
Terminal 7 Yellow	Terminal 7 Blue	Terminal 7 JUMPER	Terminal 7 Blue

Pluggable Connections

Pluggable Control Heads are supplied with a harness pigtail for each lever. When disconnecting/connecting the plugs, ensure that the release button or buttons are depressed and held until plug is fully disconnected or connected. Disconnecting/connecting plugs without depressing and holding the release button or buttons WILL damage the plug.

Aft Facing Control Heads

For dual lever Control Head Stations that have the user facing aft: Reverse connections 5 and 7.

For single lever Control Head Stations that have the user facing aft and the one Control Head lever on the user's right, reverse connections 5 and 7.





Figure MMC-329-4: AFT Facing Control Head

Handheld Control is an option. Contact your ZF Marine Electronics Dealer for further information on Handheld requirements and options.



WARNING: Do not mount control head less than 250mm from Compass.
Mounting control head too close to compass can cause the compass to malfunction.

700 Series Standard Control Head Variations

This Service Sheet reflects all current variations of the standard 3-detent ZF Marine Electronics 700 Series Control Heads.




Figure MMC-307-1: Part Numbering Configurations




Figure MMC-307-2: Detents Available

1. REQUIREMENTS:

MicroCommander/ClearCommand: one (1) 8-Conductor Cable per Control Head lever.

Pluggable MicroCommander/ClearCommand: one (1) Control Head Harness per Control Head lever.

CruiseCommand: one (1) Control Head Harness per Control Head lever.

Included with the Control Head:

- (4) Flat-washer - Stainless Steel, 1/4 inch
- (4) Screw - Stainless Steel, Philip Pan Head, 1/4 inch-20 x 1-3/4 inch
- (4) Nut - Stainless Steel, 1/4 inch-20
- (14) Terminal - Flanged For, #6
- (2) Liquid Tight Connector (in addition to those installed at the factory)

When the Control Head is properly mounted on a console, the Control Head is watertight.




Figure MMC-307-3: Dimensions

2. MOUNTING AND INSTALLATION:

Select the desired mounting locations and drill screw and cable holes as indicated on the template diagram. Refer to the Dimensions Diagram on the next page.

Run cable/harnesses between Processor and Control Head. Label both ends with the Station ID. (EXAMPLE: Port, Center, or Starboard; Port Thrust, Port Throttle; etc.)

There are two types of Control Head connections available: Plug or Terminal Connected. Both types may be used with MicroCommander, ClearCommand, or CruiseCommand using the appropriate cable or harness. Follow the appropriate steps for the Control Head that has been supplied for your system.

3. Standard Cable

- A Remove the six screws holding the bottom cover of the Control Head housings and set aside.
- B Insert cable through the correct cable grip in the bottom cover.
- C Strip back the PVC cover on the shielded cable approximately 2-1/2" (63,5mm) at the Control Head.
- D At the Control Head end of the cable strip and cut off the shielding and drain wire flush with the end of the PVC cover (the drain wire at the Control Head is not connected to ground).
- E Strip 3/8" (9,5mm) insulation off each wire.
- F Twist the individual strands of the wires to minimize fraying.
- G Crimp a locking fork terminal (included with each Control Head) to each of the conductors.

Make connections to the Control Head as indicated in the following TERMINAL CONNECTIONS diagrams.

4. Pluggable

- A Plug Control Head cable into the pigtail at the Control Head. (Ensure the correct Processor Cable is being plugged into the corresponding Control Head lever pigtail).
- B When connecting the plugs, ensure that the release button or buttons are depressed and held until plug is fully connected or disconnected. Connecting or disconnecting plugs without depressing and holding the release button or buttons will damage the plug.

ALWAYS REFER TO THE MANUAL THAT IS SUPPLIED WITH THE CONTROL SYSTEM FOR ANY UNIQUE CONTROL HEAD CONNECTIONS FOR YOUR SYSTEM.


When cable connections are complete:

- A Replace Control Head bottom cover using the six (6) mounting screws removed earlier. Ensure seal is in place.
- B Tighten watertight cable grip(s).
- C Remove front cover from the Control Head
- D Mount Control Head with supplied hardware.
- E Replace front cover when mounting is complete.

5. Bottom Panel Assembly Designations

- A Front Cover
- B Cable Grip Nut
- C Seal
- D Bottom Cover
- E 750-R = Plug; 750-L & 760 = Watertight Cable Grip (Cable O.D..275 -.393 [7mm - 10mm])
- F 750-L = Plug; 750-R & 760 = Watertight Cable Grip (Cable O.D..275 -.393 [7mm - 10mm])

Bottom Panel Assembly




6. CABLE/HARNESS CONNECTIONS:

MicroCommander/ClearCommand			
Port Lever:		Starboard Lever:	
Terminal 3	Red	Terminal 3	Red
Terminal 5	Blue	Terminal 5	Yellow
Terminal 7	Yellow	Terminal 7	Blue

CruiseCommand/9000 Series			
Port Lever:		Starboard Lever:	
Terminal 3	Red & JUMPER	Terminal 3	Red & JUMPER
Terminal 5	Blue	Terminal 5	JUMPER
Terminal 7	JUMPER	Terminal 7	Blue

585CE and Earlier MicroCommander and MS Series ClearCommand



CruiseCommand, 9000 Series, Pluggable 585CE MicroCommander and Pluggable MS Series ClearCommand




Figure MMC-307-4: Dual Control Head Connections

7. Pluggable Connections

Pluggable Control Heads are supplied with a harness pigtail for each lever. When disconnecting/connecting the plugs, ensure that the release button or buttons are depressed and held until plug is fully disconnected or connected. Disconnecting/connecting plugs without depressing and holding the release button or buttons WILL damage the plug.

8. Aft Facing Control Head

For dual lever Control Head Stations that have the user facing aft: Reverse connections 5 and 7.

For single lever Control Head Stations that have the user facing aft and the one Control Head lever on the user's right, reverse connections 5 and 7.





Figure MMC-307-5: Aft Facing Control Head

Handheld Control is a Station option. Contact your ZF Marine Electronics Dealer for further information on Handheld requirements and options.



"A" HOLE SIZE:

ø.280 THRU
[ø7.1]
4 PLACES

"B" HOLE SIZE:

ø1.000/1.100 THRU
[ø25.4/27.9]
2 PLACES

DWG: 11403B




WARNING: Do not mount control head less than 600mm from Compass. Mounting control head too close to compass can cause the compass to malfunction.



WARNING: Note that the dimensions are out of scale, pay attention to properly size the cut out before use !

400 Series Weather Mount Enclosure



Deck Mount or Exposed Mount

Ideal for outside Weather Mount

To prevent internal condensation and moisture build up the mount is drilled to allow air circulation.

Part No. 12110

DT Type


Step 1: Contact Removal



1. Remove wedgelock using needle-nose pliers or a hook shaped wire. Pull wedge straight out.



2. To remove the contacts, gently pull wire backwards, while at the same time releasing the locking finger by moving it away from the contact with a screwdriver.



3. Hold the rear seal in place, as removing the contact may displace the seal.

Step 2: Wire Stripping

Solid Contacts

Contact Part Number	Wire Gauge Range	Strip Length (inches)
0460-202-20141 0462-201-20141	20 AWG	.156-.218
0460-202-16141 0462-201-16141	16, 18 & 20 AWG	.250-.312
0460-215-16141 0462-209-16141	14 AWG	.250-.312
0460-204-12141 0462-203-12141	12 & 14 AWG	.222-.284
0460-204-08141 0462-203-08141	8 & 10 AWG	.430-.492
0460-204-0490 0462-203-04141	6 AWG	.430-.492

Step 3: Contact Crimping

Use Crimp Tool #HDT48-00




1. Strip insulation from wire. (See Step 2).
2. Raise selector knob and rotate until arrow is aligned with wire size to be crimped.
3. Loosen locknut, turn adjusting screw in until it stops.



4. Insert contact with barrel up. Turn adjusting screw counter-clockwise until contact is flush with indenter cover. Tighten locknut.



5. Insert wire into contact. Contact must be centered between indicators. Close handles until crimp cycle is completed.
6. Release handles and remove crimped contact.



7. Inspect terminal to ensure that all strands are in crimp barrel. **NOTE:** Tool must be readjusted for each type/size of contact. Use HDT04-08 for size 8 and 4 contacts.

Step 4: Contact Insertion



1. Grasp crimped contact approximately (25.2 mm) one inch behind the contact barrel.



2. Hold connector with rear grommet facing you.



3. Push contact straight into connector grommet until a click is felt. A slight tug will confirm that contact is properly locked in place.



4. Once all contacts are in place, insert wedgelock with arrow pointing toward exterior locking mechanism. The wedgelock will snap into place. Rectangular wedges are not oriented. They may go in either way.
NOTE: The receptacle is shown –use the same procedure for plug.



Automatic Power Selector (APS) Model: 13505

ATTACHMENTS: DC POWER SOURCE DWG 11488

A GENERAL INFORMATION

The APS, Model 13505, provides a simple, solid state solution to the need for routing redundant DC power sources for vital electronic equipment while maintaining isolation of the DC power sources.

Two independent batteries rated at the same nominal voltage are wired to separate terminals on the APS and internal diodes maintain total isolation between them. A single output terminal is wired to the ZF Marine Electronics Propulsion Control System.

The APS is rated for loads of up to 70 Amps on 12-24VDC systems. The unit is ruggedly constructed with heavy-duty wiring studs and epoxy-potted components in an anodized aluminum case.

B APS SPECIFICATIONS

Model: 13505

Maximum Load Current: 70 amps

Operating Temperature: - 40 degrees C to +80 degrees C; derate linearly from 100% @ 50 degrees C to 70% @ 80 degrees C

Voltage Drop: 0.7 VDC @ 50% load; 0.9 VDC @ full load

Dimensions: 3.25" x 4.5" x 3.1" (8,3 x 11,4 x 7,9 cm)

C MATERIALS PROVIDED

The single APS is supplied with a hardware packet containing (6) hex nuts, (3) lock washers, (4) self-tapping mounting screws, (1) instructions diagram.



NOTE: Not all of the hardware will be used in the installation; some spares are provided. Nut size is M-6.

The twin APS is supplied with (2) single APS hardware packets.

D INSTALLATION

Refer to Drawing 11488 DC Power Source Kit.

1. Shut off all charging sources and disconnect the negative (ground) side of each battery which will be wired to the APS.
2. Mount the APS(s) in a suitable location which will keep wire runs to a minimum length, and is (preferably) ventilated, for cooler operation. The case of the APS is electrically isolated from the internal diodes, so mounting on either a metal or non-metal surface is acceptable.
3. Complete the wiring as indicated.
4. Reconnect the negative battery posts.

E IMPORTANT NOTE ABOUT BATTERY SOURCES

Whenever the load is turned on, it can be drawing power from the batteries. Therefore, if the batteries are not simultaneously being recharged, or if charging will not be available for an extended period, it is recommended that the load be shut off to prevent complete discharge of batteries.

NOTES: UNLESS OTHERWISE SPECIFIED

1 WIRE SIZE (REF ABYC E 11.16:1.2.9, TABLE X 3%),

12VDC POWER SYSTEMS

WIRE HARNESS LENGTHS FEET [METRIC]	WIRE GAUGE AWG [METRIC EQUIV.]
0-15 FT. [0-4.6M]	12 AWG [#4]
15-25 FT. [4.6M-7.6M]	10 AWG [#6]
25-40 FT. [7.6M-12.2M]	8 AWG [#10]
40-70 FT. [12.2-21.3M]	6 AWG [#6]

24VDC POWER SYSTEMS

WIRE HARNESS LENGTHS FEET [METRIC]	WIRE GAUGE AWG [METRIC EQUIV.]
0-20 FT. [0-6.1M]	14 AWG [#2.5]
20-30 FT. [6.1M-9.1M]	12 AWG [#4]
30-50 FT. [9.1M-15.2M]	10 AWG [#6]
50-80 FT. [15.2-24.3M]	8 AWG [#10]

2 WIRE SIZE (RECOMMENDED: TWISTED PAIR)

12VDC POWER SYSTEMS

WIRE HARNESS LENGTHS FEET [METRIC]	WIRE GAUGE AWG [METRIC EQUIV.]
0-20 FT. [0-6.1M]	14 AWG [#2.5]
20-30 FT. [6.1M-9.1M]	12 AWG [#6]

24VDC POWER SYSTEMS

WIRE HARNESS LENGTHS FEET [METRIC]	WIRE GAUGE AWG [METRIC EQUIV.]
0-40 FT. [0-12.2M]	14 AWG [#2.5]
40-65 FT. [12.2M-19.8M]	12 AWG [#4]

3. AUTOMATIC POWER SELECTOR (APS) OUTPUT IS STRICTLY FOR ZF MARINE ELECTRONIC CONTROLS.

4. POWER SOURCES MAY BE 12VDC OR 24VDC.

5. PART NUMBER: 13983 (SINGLE SCREW KIT MATERIAL LIST)

SEE SHEET 3 FOR BOM AND WIRING PART NUMBER: 13984 (TWIN SCREW KIT MATERIAL LISTS) SEE SHEETS 4 FOR BOM AND WIRING

6. MAXIMUM WIRE SIZE ALLOWED IN FUSEHOLDER IS 12 AWG. IF A LARGER WIRE SIZE IS REQUIRED FOR INSTALLATION, THE CUSTOMER SHALL PROVIDE AN APPROPRIATE FUSE AND FUSE HOLDER. (SUGGESTED MANUFACTURER BLUE SEA SYSTEMS, MAXI FUSE BLOCK SERIES).

7. IF THIS CONFIGURATION IS USED WITH AN ELECTRONIC ENGINE, THE THE CIRCUIT BREAKER MUST BE TURNED ON PRIOR TO APPLYING POWER TO THE REMOTE SWITCH.

8. FOR SUGGESTED HARDWARE STACKING FOR SYSTEMS UTILIZING MULTIPLE OUTPUTS FROM THE APS, SEE SHEET 2.

ZONE	REV	DESCRIPTION	INC. BY	ENG. APR	QC/CE APR
A		REVISED WIRING TO APS	JIC 6-01	-	-
B		ADDED FLAGNOTES 6 AND 7	TU 7-02	-	-
C		ADDED FLAGNOTE 8, REVISED FLAGNOTE 6.	TU 3-03	-	-
D		REVISED FLAGNOTES 1 AND 2.	MW 4-03	-	-
E		MOVED DRAWING TO NEW FORMAT AND UPDATED. ADDED NEW SHEET 2, CREATING 4 SHEETS.	D.MONTIZ 10/05/06	C.ESTES 10/11/06	RBH 10/12/06
F		SHEET 2, ADDED SCHEMATIC DIAGRAM SHEETS 3 AND 4; ADDED DIODES TO APS (93 PLACES) PER SHEET 2 SCHEMATIC. REVISED PER EGN 5141.	RAC 12/15/08	RS4 12/15/08	RBH 12/15/08
G		SHEET 3: ADDED TOR TWIN SCREW APPLICATION ONLY" REVISED WITHOUT EGN.	GIG 07/20/10	AAN 07/20/10	JIS 07/20/10
H		EXTENSIVE CHANGES TO ALL SHEETS. UPDATED APS, CIRCUIT BREAKER AND REMOTE SWITCH SCHEMATIC TO NEW ZF WIRING DIAGRAM STANDARDS. SEE EGN ARCHIVES FOR PREVIOUS CONFIGURATION.	RAC 08/11/12	AAN 08/18/12	RBH 08/18/12

SHEET	DESCRIPTION
1	NOTES
2	AUTOMATIC POWER SELECTOR (APS) DIMENSIONS AND HARDWARE STACKING
3	SINGLE SCREW, SINGLE APS CONNECTIONS
4	TWIN SCREW, SINGLE APS CONNECTIONS
5	TWIN SCREW, DUAL APS CONNECTIONS

UNLESS OTHERWISE SPECIFIED TOLERANCES

FRACTIONAL = ±1/64 IN.

XX = ±.05

XX = ±.01

XXX = ±.005

ANGLE = ±2°

DIMENSIONS ARE IN INCHES (mm) UNLESS OTHERWISE SPECIFIED. DIMENSIONS APPLY PRIOR TO FINISH BREAK. ALL SHARP EDGES DO NOT SCALE DRAWING.

APPROVAL	DATE
DRI WILSON	1-30-01
ENG JHC	-
CHK -	-
QC -	-
MFG -	-


ZF MARINE ELECTRONICS, LLC
12125 HARBOUR REACH DR., SUITE B, MUKILTEO WA 98275

DC POWER SOURCE KIT



SCALE: NONE PART NO. SEE NOTE 5 SHEET 1 OF 5

SIZE: B CAD CODE: DWG NO. 11488 REV: H

THE INFORMATION CONTAINED HEREIN IS PROPRIETARY TO ZF MARINE ELECTRONICS, LLC AND SHALL NOT BE REPRODUCED IN WHOLE OR IN PART OR USED FOR ANY DESIGN OR MANUFACTURE EXCEPT WHEN USED FOR ANY PURPOSES SPECIFICALLY AUTHORIZED BY ZF MARINE ELECTRONICS, LLC.





APS DIMENSIONS
DIMENSIONS ARE IN INCHES [mm]
SCALE: NONE



APS HARDWARE STACKING
FOR SYSTEMS UTILIZING MULTIPLE OUTPUTS FROM
THE P/N: 13505 (AUTOMATIC POWER SELECTOR).

ZONE	REV	DESCRIPTION	INC. BY	ENG. APR	Q.C. APR
		-SEE SHEET 1-			

 ZF MARINE ELECTRONICS, LLC 12125 HARBOUR REACH DR., SUITE B, MUKILTEO WA 98275					
TITLE DC POWER SOURCE KIT					
SIZE B	CAGE CODE	DWG NO. 11488	REV H		
SCALE NONE	PART NO.	SEE NOTE 5	SHEET 2 OF 5		



P/N: 13983 MATERIAL LIST (NOT INCLUDING BACKUP)

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	13505	AUTOMATIC POWER SELECTOR (APS)
2	1	810ETA	CIRCUIT BREAKER, 10 AMP
3	2	AGC-30	FUSE, 30 AMP
4	2	HFB	FUSEHOLDER


ZF BACKUP POWER SOURCE MATERIAL LIST

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	13505	AUTOMATIC POWER SELECTOR (APS)
2	1	810ETA	CIRCUIT BREAKER, 10 AMP
3	2	AGC-30	FUSE, 30 AMP
4	2	HFB	FUSEHOLDER

SINGLE SCREW,
SINGLE APS CONNECTIONS
WITH ALTERNATE REMOTE SWITCH
AND OPTIONAL ZF BACKUP



ZF MARINE ELECTRONICS, LLC
1215 HARBOUR REACH DR., SUITE B, MUKILTEO WA 98275

TITLE			
DC POWER SOURCE KIT			
SIZE	CAGE CODE	DWG NO.	REV
B		11488	H
SCALE	PART NO.	SEE NOTE 5	SHEET 3 OF 5
NONE			



ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	13505	AUTOMATIC POWER SELECTOR (APS)
2	2	810ETA	CIRCUIT BREAKER, 10 AMP
3	4	AGC-30	FUSE, 30 AMP
4	4	HFB	FUSEHOLDER

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	13505	AUTOMATIC POWER SELECTOR (APS)
2	1	810ETA	CIRCUIT BREAKER, 10 AMP
3	2	AGC-30	FUSE, 30 AMP
4	2	HFB	FUSEHOLDER



ALTERNATE REMOTE SWITCH
 TO BE USED FOR LONG CABLE RUN FOR
 REMOTE "ON/OFF" SWITCH IN EXCESS OF 40 FT.

(RELAY COIL VOLTAGE MUST
 MATCH POWER SOURCE)

TWIN SCREW, DUAL APS CONNECTIONS
 WITH ALTERNATE REMOTE SWITCH
 AND OPTIONAL ZF BACKUP

ZF MARINE ELECTRONICS, LLC
 1215 HARBOUR REACH DR., SUITE B, MUKILTEO WA 98275

TITLE: DC POWER SOURCE KIT

SIZE: B DRAWING NO.: 11488 REV: H

SCALE: NONE PART NO.: SEE NOTE 5 SHEET: 5 OF 5

Grounding (Bonding)

Grounding (Bonding) - 46 CFR 111.05 and ABYC Section E-11

Grounding (Bonding) should be done according to ABYC Section E-11 and Code of Federal Regulations 46 CFR 111.05.

Each grounded system must have only one point of connection to ground regardless of the number of power sources operating in parallel in the system

A vessel's hull must not carry current as a conductor. A metallic hull, or the bonding and DC grounding systems, shall not be used as a return conductor.


There are some limited exceptions: (1) Impressed current cathodic protection systems. (2) Limited and locally rounded systems, such as a battery system for engine starting that has a one-wire system and the ground lead connected to the engine. (3) Insulation level monitoring devices if the circulation current does not exceed 30 milliamperes under the most unfavorable conditions. (4) Welding systems with hull return except vessels subject to 46 CFR Subchapter D.

Grounding conductors should be green or green with a yellow stripe.

References:

CFR Sec. 111.05-13, Sec. 111.05-11

ABYC E-11 11.5.2.2, ABYC E-11.4, ABYC 11-18 shall not be used as a return conductor.



^a Grounding is used courtesy of American Boat and Yacht Council.

All parts of figure except processors and processor connection ©

2003 American Boat and Yacht Council

Metal - Hull Vessels

The hull of a metal hull vessel may serve as the common grounding conductor. If it is desirable for the item being installed to be bonded to the vessel grounding system, and the installation or mounting method does not provide the desired path, a separate grounding conductor may be required.

References and Parts Source

References

- A American Boat & Yacht Council (ABYC)
 - 3069 Solomons Island Road
 - Edgewater, MD 21037-1416
 - E-3 Wiring Identification on Boats
 - E-11 AC and DC Electrical Systems on Boats
 - H-2.4e or 32.4g Ambient Temp. 50 degrees C
 - P-24 Electric/Electronic Propulsion Controls
- B Code of Federal Regulations
 - 33 CFR 183 Subpart I - Electrical Systems
 - 33 CFR 183.410 Ignition protection
 - 33 CFR 183.415 Grounding
 - 33 CFR 183.425 Conductors: General
 - 33 CFR 183.430 Conductors in circuit of less than 50 Volts
 - 33 CFR 183.445 Conductors: Protection
 - 33 CFR 183.455 Over-current and Protection: General
 - 46 CFR 111.01 - 15(b) Ambient Temp. Machinery Spaces 50 degrees C
 - 46 CFR 111.05- System Grounds
- C Society of Automotive Engineers
 - 400 Commonwealth Drive
 - Warrendale, PA 15096
 - J1171 External Ignition Protection
 - J1428 Marine Circuit Breakers
 - J378 Marine Engine Wiring
- D National Marine Manufacturers Association
 - 401 North Michigan Avenue
 - Chicago, IL 60611
- E Underwriters Laboratories

Parts Source

Anti-Static Wrist Strap - - - - - P/N 517 [Thomas & Betts (P/N AWCC)]
 Automatic Power Selector - - - - - P/N 13505
 Circuit Breaker- UL Approved - - - - - P/N 810 [E-T-A (P/N 41-2-514-LN2-10)]
 Fuse - - - - - P/N 1030 [Bussman (P/N. GDC-1A)]
 Relay 12 VDC - - - - - P/N 1114 [Potter-Brumfield (P/N KRPA5D6-12)]
 Relay 24 VDC - - - - - P/N 1122 [Potter-Brumfield (P/N KRPA5D6-24)]
 Service Field Test Unit (Break-out Box) - P/N 13927
 WAGO Tool - - - - - P/N 397 [WAGO (P/N 236-332)]
 Field Test Control Head - Dual- - - - - P/N 14000

Engine Tachometer Sender Requirements

Engine Type	Engine	Model	Sender	Comments
Gasoline	Inboard	3, 4, 6, 8 Cylinder	Alternator's Stator AC Terminal or Point Side of the Coil	N/A
Gasoline	Outboard	4, 6, 8, 14 Pole	Alternator's Stator AC Terminal or Point Side of the Coil	N/A
Diesel	Caterpillar	Most Older & 3208, D336, D346, D348, D398, D399 & D334	8902	N/A
Diesel	Caterpillar	3116, 3126, 3176, 3196, 3406, 3408, 3306, 3412, 3056, 3512 & 3516	8922	Some use 8912. New engines have Magnetic Pickup already installed on flywheel.
Diesel	Caterpillar	All Electronic	N/A	Use ECM output. Outputs 12 PPR.
Diesel	Cummins	Most Older & 555	8902	N/A
Diesel	Cummins	B & C Series, KTA19M3, MTA855, * KTA1150M	8912	Most have Magnetic Pickup already installed on flywheel.
Diesel	Detroit	DDEC Electronic System	8902	Must have Detroit data-link output module.
Diesel	Detroit	53, 71, & 92 Series	8902	Engines manufactured before 1976 use Aetna Part No. 8152 drive key with Sender.
Diesel	Detroit	8.2 Liter 2 Cycle, Some 71 & 92 Series	8912	N/A
Diesel	EMD	Mechanical Sender Applications	8902	N/A
Diesel	EMD	Flywheel Applications	8912	N/A
Diesel	Hino	All Engines	8902	250 HP: Tach drive on front Port side of engine. 310HP: Tach drive on rear center, just below the head.
Diesel	John Deere	Older Engines	8902	Tach drive usually at rear Starboard side of engine.
Diesel	John Deere	Newer Engines	8912	Magnetic Pickup usually already installed.

TROUBLESHOOTING

Engine Type	Engine	Model	Sender	Comments
Diesel	Lehman (Ford)	All Engines	8902	Engine built after 1977 require the Aetna Part No. 8619 tachometer drive adapter.
Diesel	Lugger	All Engines	8912	N/A
Diesel	MAN	In-line	8902	N/A
Diesel	MAN	V-Engines	8902	An extension tachometer cable Aetna Part No. 9212 is usually required.
Engine Type	Engine	Model	Sender	Comments
Diesel	MAN	826	8912	It may be necessary to manufacture a mounting plate for the magnetic pickup.
Diesel	MAN	2840, 2842, 2848, 2866 & 2886	8912	N/A
Diesel	MTU	All Engines	8902	N/A
Diesel	Perkins	1980 and earlier	8902	N/A
Diesel	Perkins	4-236 & 6-354	8902	Perkins Part No. 8875 drive adapter needed on 1980 and newer engines.
Diesel	Perkins	4-107, 4-108 & M-800TI	8902	N/A
Diesel	Perkins	4-154	N/A	Aetna Part No. 8709 Magnetic Sensor must be used in lieu of SAE drive.
Diesel	Perkins	M-135, M225, M-300 & M30	8912	N/A
Diesel	Volvo	70, 100 & 120 A or B Series	8902	N/A
Diesel	Volvo	3, 6A, 17 & 30	8912	N/A
Diesel	Volvo	31 & Up, 41	N/A	Aetna Part No. 8709 Magnetic Sensor must be used in lieu of SAE drive.
Diesel	Volvo	40, 60, 61 & Up, 71 & Up, 100C & Up, 102, 121C & Up, 122, 2010 & 2020	N/A	Magnetic pickup already installed on cam gear.
Diesel	Volvo	42 & 43	N/A	Connect at blower box. Black wire is ground and grey is signal
Diesel	Volvo	2030 & 2040	N/A	Magnetic pickup already installed on cam gear.
Diesel	Yanmar	All Engines	N/A	A metric Magnetic pickup is already installed on all engines.

P/N 8902

Dual Mechanical Sender

P/N 8912

Dual Magnetic Pickup (3/4-16)

P/N 8922

Single Magnetic Pickup (5/8-18) Available through Aetna Engineering only.

Morse Clutch and Throttle Kit Selection
Pre-Engineered Throttle Connection Kits

MAKE	ENGINE MODEL	KIT NO.
Caterpillar	3208NA 3208TA 334, 3304, 3306 3406 & 343 3408	300172 305403 36680 36680 36680
Cummins	A11 w/MVSGOV AFC Fuel Pump V504M, V555M, V903M, VT903M, VTA903M, NT855M, VT1710M, VTA1710M, KT & KTA 1150M, KT & KTA 2300M, 1975 and later	36680 300580
General Motors	3, 4, & 6-71 w/var.sp.gov. 6, 8, 12 V-71 & 6, 8 V-92 w/var.sp.gov. 6-71 inclined 2, 3, 4-53 w/left hand gov. Right hand gov. 6V-53 Rear entry 6V-53 Front entry 6, 8V-71 Front entry 12, 16V-149	41736 41736 36680 36680 36680 36680 36680 36680
Perkins	4, 236M 6, 3544M; T6, 3544M; ST6, 3544M; SST6, 3544M 4, 108 W/shut off	48931 302026 303878


MAKE	TRANSMISSION MODEL	KIT NO.
Allison	M & MH	41482
Borg Worner	70, 71, 72 In line w/red gear rear entry	301474
Capital	12400 2, 3, & 4 HD & HE	36680 36680
MerCruiser	Inboard w/o Warner reduction gear	62355
Paragon	HF-7	36680
Twin Disc	MG508, 509, 510, 510A, 512, 514C, 514CHP, 518, 521, 527, 530, 540 MG502, 506, 507, W/x9994, xA7022, A7048 Valves	42577 63696
Twin Disc Trolling Valve	MG509, 510A, 511A, 514C	307171

ENGINE MAKE	KIT NO.
Chrysler 1975 & later	300465

ENGINE MAKE	KIT NO.
Evinrude/Johnson 55-235 H.P. 1978 to date	301729
Mercury 40-300 H.P.	301901
Mercruiser I/O	302123
OMC Sterndrive I/O	300557
Volvo I/O Engine and out drive brackets are provided by Volvo	

Universal Mounting Kit

Fabricate Bracket to match
dimensions shown



43C Cable Conversion Kit

Rev	Date	Revision Description
A	8/03	Added 9000 Series.
A.1	10/11	Converted document name from MM13821 to MMC-345





Figure 1: Actuator/Processor Preparation



CAUTION: Static electricity can destroy electronic components. Anytime the Actuator/Processor cover is off, use an anti-static wrist strap and connect it to the Actuator/Processor frame. This will drain any static charge you may have on your person.



NOTE: 43C cable and jam nut are supplied by others.




Figure 2: Actuator/Processor Cable Installation

13 Appendix B - Sales and Service Information

Factory Authorized Sales & Service - North America

USA

Alabama

Company:	Gulf Coast Air & Hydraulics
Contact:	Chuck Moorehead, Mike Ellis
Address:	PO Box 161134
	Mobile, AL 36613
Shipping:	3415 Halls Mills Road
	Mobile, AL 33693
Phone:	251-666-6683
Fax:	251-666-6684
Email:	cmoore41984@aol.com
Website:	www.wegetstuffdone.com

California

Company:	TDC Equipment
Contact:	Terry Brown
Address:	15886 Manufacture Lane
	Huntington Beach, CA 92649
Phone:	714-373-8099
Fax:	714-898-1996
Email:	tbrown@tdcequipment.com
Website:	www.tdcequipment.com

Company:	Trans Pacific Distributors
Contact:	Henry Bramhall
Address:	1941 Walters Court
	Fairfield, CA 94533
Phone:	707-426-6670
Fax:	707-426-0206
Email:	sales@marinegate.com

Florida

Company:	Control Masters
Contact:	Ed Raffaniello
Address:	14603 Beach Blvd Ste 600
	Jacksonville, FL 32250
Phone:	904-260-9756
Fax:	904-260-9727
Email:	edr@controlmastersinc.com
Website:	www.controlmastersinc.com

Company:	D.S. Hull Company, Inc.
Contact:	Lou Moran
Address:	3320 SW Third Ave
	Ft Lauderdale, FL 32258
Phone:	954-463-4307
Fax:	954-527-4173
Email:	loudshull@yahoo.com

Company:	H & H Marine Sales & Service
Contact:	John Fox, Andy Glen
Address:	10220 San Martin Blvd. N
	St Petersburg, FL 33702
Phone:	727-576-0923
Fax:	727-576-9727
Email:	hhmarine@ij.net

Michigan

Company:	Yacht Equipment & Parts
Contact:	Jim Monroe, Lee Moore
Address:	3355 SW 2nd Ave Ft Lauderdale, FL 33315
Phone:	954-463-7222
Phone:	800-349-9224
Fax:	954-463-9009
Email:	jmonroe@bowboat.com

Company:	Marysville Marine North
Contact:	Randy Hall, John Dillon
Address:	1551 Michigan Ave Marysville, MI 48040
Phone:	810-364-7653
Phone:	800-367-0987
Fax:	810-364-4112
Email:	rhall@marysvillemarine.com
Website:	www.marysvillemarine.com

Company:	ZF Marine – US Headquarters
Contact:	A.J. Halavacs
Address:	15351 SW 29th Street, Ste 300 Miramar, FL 33027
Phone:	954-441-4040
Fax:	954-441-4140
Email:	aj.halavacs@zf.com
Website:	www.zf-marine.com

New Jersey

Company:	Airline Hydraulics Corporation
Contact:	Bernie Keppel
Address:	428 Woodbine-Ocean View Road Ocean View, NJ 08230
Phone:	609-624-3700
Fax:	909-624-0863
Email:	sales@airlinehyd.com
Website:	www.airlinehyd.com

Louisiana

Company:	Donovan Marine, Inc.
Contact:	Steve Garver, Richard McConnell
Address:	6316 Humphreys Street Harahan, LA 70123
Phone:	504-488-5731
Phone:	800-347-4464
Fax:	504-486-3258
Email:	rbenton@donovanmarine.com

Ohio

Company:	Marysville Marine - Ohio
Contact:	Jeff Mechan
Address:	1470 South Danbury Rd Port Clinton, OH 43452
Phone:	419-734-3104
Fax:	coming soon
Email:	jmechan@marysvillemarine.com
Website:	www.marysvillemarine.com

Company:	ZFI Marine – Gulf Coast
Contact:	Mike Gauthreaux, Laura Heckler
Address:	161 James Drive West, Suite 120 St Rose, LA 70087
Phone:	504-443-0501
Fax:	504-443-0504
Email:	mike.gauthreaux@zf.com
Website:	www.zf-marine.com

Tennessee

Company:	Marysville Marine South
Contact:	Randy Hall
Address:	127 Industrial Drive White House, TN 37188
Phone:	615-672-1142
Fax:	615-851-9465
Email:	rhall@marysvillemarine.com
Website:	www.marysvillemarine.com

Texas

Company:	Donovan Marine, Inc.
Contact:	Trey Grant
Address:	4757 South Loop East
	Houston, TX 77033
Phone:	713-734-4171
Phone:	800-669-8392
Fax:	713-734-167
Email:	treygrant@donovanmarine.com

Virginia

Company:	Engines 1
Contact:	Tim Walters
Address:	PO Box 7788
	Portsmouth, VA 23707
Shipping:	3504 Shipwright Street
	Portsmouth, VA 23703
Phone:	757-673-7200
Phone:	800-548-6252
Fax:	757-673-7211
Email:	info@engines1.com
Website:	www.engines1.com

Washington

Company:	Fisheries Supply Co
Contact:	Mike Gibbons
Address:	1900 N. Northlake Way
	Seattle, WA 98103
Phone:	206-632-4462
Phone:	800-426-6930
Fax:	206-634-4600
Email:	mail@fisheriessupply.com
Website:	www.fisheriessupply.com

Company:	Pinnacle Marine Services
Company:	Dave Hanson
Address:	160 Cascade Place, #229
	Burlington, WA 98233
Phone:	360-404-2063
Fax:	360-404-2064
Email:	pinmar@aol.com

Company:	PPC – Systems, Inc
Contact:	Bill Mol
Address:	12147 Bayhill Road
	Burlington, WA 98233
Phone:	360-336-9698
Fax:	360-757-8747
Cell:	206-915-0712
Email:	ppcsystemsinc@verizon.net

Company:	ZFI Marine – West Coast
Contact:	Bud Bloom, Kevin Zwicker
Address:	12125 Harbour Reach Dr Ste B
	Mukilteo, WA 98275
Phone:	425-583-1900
Fax:	425-493-1579
Email:	bud.bloom@zf.com; kevin.zwicker@zf.com
Website:	www.zf-maine.com

Wisconsin

Company:	Marysville Marine West
Contact:	Brian Hunter
Address:	282 Progress Way
	Sun Prairies, WI 53590
Phone:	608-825-3875
Phone:	800-992-3878
Fax:	608-825-2790
Email:	bhunter@marysvillemarine.com
Website:	www.marysvillemarine.com

CANADA

Eastern Canada

Company:	CMC Electronics
Contact:	Mark Newcomb
Address:	40 Thornhill Drive, Unit 6
	Dartmouth, Nova Scotia
	Canada B3B 1S1
Phone:	902-468-8480
Fax:	902-468-8484
Email:	mark.newcomb@cmcelectronics.ca

Company:	CMC Electronics
Contact:	Brian Sibley
Address:	8 Brown Street / PO Box 5
	Yarmouth, Nova Scotia
	Canada B5A 1N1
Phone:	902-742-3423
Fax:	902-742-5593
Email:	brian.sibley@cmcelectronics.ca

Company:	CMC Electronics
Contact:	Bill Taaffe, Dave Duff
Address:	29 Hallett Cresent
	St John's, Newfoundland
	Canada A1B 3T2
Phone:	709-726-2422
Fax:	709-726-2428
Email:	bill.taaffe@cmcelectronics.ca; dave.duff@cmcelectronics.ca

Central Canada

Company:	CMC Electronics
Contact:	Graham Taylor
Address:	3600 B Laird Road Unit 12
	Mississauga, Ontario
	Canada L5L 6A7
Phone:	905-607- 4262
Fax:	905-607-1576
Email:	graham.taylor@cmcelectronics.ca

Company:	CMC Electronics
Contact:	Michel Roy
Address:	566 Duphare Street East
	Mantane, Quebec
	Canada G4W 3P6
Phone:	418-562-6637
Fax:	418-562-5335
Email:	michel.roy@cmcelectronics.ca

Company:	CMC Electronics
Contact:	Walter Timmerman
Address:	600 Dr Frederik Phillips Blvd
	Ville St Laurent, Quebec
	Canada H4M 2S9
Phone:	514-748-3000, ext 4800
Fax:	514-748-3006
Email:	walter.timmerman@cmcelectronics.ca

Western Canada

Company:	Western Marine
Contact:	Bill Falk, Alan Stovell
Address:	1494 Powell Street
	Vancouver, British Columbia
	Canada V5L 5B5
Phone:	604--253-7721
Phone:	800-663-0600
Fax:	604-253-2656
Email:	astovell@westernmarine.com

Company:	CMC Electronics
Contact:	Jeff Bailey
Address:	3839 Still Creek Ave
	Burnaby, British Columbia
	Canada V5C 4E2
Phone:	604-435-1455
Fax:	604-435-2231
Email:	Jeffrey.Bailey@cmcelectronics.ca

Company:	CMC Electronics
Contact:	Brad Funk, Jim Goodfellow
Address:	6680 Mirah Road
	Saanichton, British Columbia
	Canada V8M 1Z4
Phone:	250-544-1561
Fax:	250-544-2061
Email:	brad.funk@cmcelectronics.ca; jim.goodfellow@cmcelectronics.ca

Electronic Propulsion Control Systems Limited Warranty

- A Limited Warranty: Your ZF Marine Electronics product was designed and manufactured by experienced engineers and craftsmen. ZF Marine Electronics, LLC warrants for the period indicated below, each product manufactured by ZF Marine Electronics, LLC to be free from defects in materials and workmanship. If during the applicable warranty period a product is determined by ZF Marine Electronics, LLC to be in breach of this limited warranty, ZF Marine Electronics, LLC, at its option, will repair or replace the defective product.
- B Warranty Exclusions: This warranty covers only failures due to defects in materials or workmanship that occurs during normal use. This warranty does not cover damage that occurs in shipment, failures that are caused by products not supplied by ZF Marine Electronics, LLC, failures that result from installation that is not in compliance with ZF Marine Electronics specifications, accident, misuse, abuse, neglect, water damage, mishandling, misapplication, set-up adjustments, improper maintenance, alterations, modification or service by anyone other than a ZF Marine Electronics Authorized Service Center, damage that is attributable to acts of God or other causes unrelated to defects in materials and workmanship.
- C Warranty Period: The length of the applicable warranty period will depend on the use of your vessel. For Commercial Craft the standard warranty period is for 24 months from the date of original shipment by ZFME or 12 months after commissioning of the craft, whichever occurs first. A commercial craft is defined as any vessel used for any commercial purpose including but not limited to any use as a workboat, passenger vessel, charter or rental fleet.
- D For Pleasure Craft the warranty period is 36 months from the date of original shipment by ZFME or 24 months after commissioning of the craft, whichever occurs first. A Pleasure Craft is any vessel that is or has not been used for any commercial purpose including but not limited to any use as a workboat, passenger vessel, charter or rental fleet.
- E Repair or replacement parts provided under this Warranty will not be covered by the remainder of the unexpired warranty in effect on the complete unit.
- F No Coverage Under Warranty: The exclusive remedy under this warranty is the repair or replacement of the defective component and this warranty specifically does not provide coverage for:
1. Towing or transportation of the vessel, or travel to and from the job site or vessel.
 2. Original installation charges or start-up costs.
 3. Loss of use or income from the vessel and/or rental of equipment during the performance of warranty repairs.
- G To Obtain Warranty Service: Please go to www.zf.com or call 1-425-583-1900 or (U.S. only) 1-800-546-5455 for the nearest ZF Marine Electronics Factory or Authorized Service Center.
1. The Service Center will contact ZF Marine Electronics Service Department for a Service Return Authorization (SRA) number. Return the product freight prepaid, marked clearly with the SRA number, and with a description of the malfunction included.
 2. If there are defects covered by this warranty, ZF Marine Electronics will, at its option, either repair or replace the defective part or product. If after inspection, ZF Marine Electronics determines that the product is not defective, ZF Marine Electronics will charge a testing fee and return the product to the sender, freight collect.
 3. Repair or replacement during the warranty period will not extend the warranty period.
 4. All SRA claims must be requested and submitted within 30 days from the date of repair service.
 5. Claims for over 3 hours labor must be pre-approved by the ZF Marine Electronics Service Department.

This warranty is expressly in lieu of all other warranties, express or implied. Except to the extent prohibited by applicable law, ZF Marine Electronics hereby disclaims all other implied or express warranties of any kind, including warranties of merchantability and fitness for a particular purpose. Under no circumstances shall ZF Marine Electronics be liable for any incidental or consequential damages sustained in connection with the product or its use, including any costs or damages that result from loss of use of the product or any engine or boat with which it is used. ZF Marine Electronics does not authorize any representative or agent to assume for it any obligation or liability other than those expressly set forth above. Some States and other jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of consequential damages, so above limitations may not apply to you. All implied warranties, if any, are limited to the duration of this express warranty. This warranty gives you legal rights, and you may have other rights that may vary from State to State.

Warranty Registration

Processor, Serial #		Serial #	
Number of Remote Stations			
Purchase Date			
Dealer's Name			
Installer's Name			
Phone Number		Cell Number	
E-Mail Address		Fax Number	
Purchaser's Name			
Street Address			
City		State	Zip
Phone			
YOUR VESSEL:			
Engine, Make & Model			
Length			
Manufacturer			

ZF Marine Electronics, LLC. Product First Seen At:

Boat Show | Dealer | Magazine | Friend

Factory Authorized Service Centers - North America

USA

Alaska

Company:	Alaska Professional Marine
Contact:	Keith Stephens
Address:	PO Box 32083
	Juneau, AK 99803
Shipping:	1900 Fritz Cove Road
	Juneau, AK 99803
Phone:	907-780-3960
Fax:	907-789-0054

Company:	Brick's Electronics
Contact:	Brick Lobaugh
Address:	1035 Mendenhall Peninsula Road
	Juneau, AK 99801
Phone:	907-789-2787
Fax:	907-789-4778
Email:	bricks@gci.neet

Company:	Kodiak DC Electric
Contact:	Dennis McCusker
Address:	2561 Beaver lake Drive
	Kodiak, AK 99615
Phone:	907-486-5323
Email:	debmccusker@yahoo.com

Company:	Kodiak Service
Contact:	Fred Lentz
Address:	PO Box 1018
	Kodiak, AK 99615
Phone:	907-486-6556
Fax:	907-486-6022
Email:	ksci@worldnethtt.net

Company:	Rainbow Glacier Company
Contact:	Karl Johnson
Address:	PO Box 821
	Haines, AK 99827
Phone:	907-766-2218
Fax:	907-766-2585

Company:	Redden Marine Supply Formerly - Kachemak Gear Shed
Contact:	John and Butch
Address:	3625 East End Road
	Homer, AK 99603
Phone:	907-235-7993
Fax:	907-235-7233

Company:	Spaulding Sports Supply
Contact:	Steve Spaulding
Address:	2017 Badger Road
	North Pole, AK 99708
Phone:	907-488-6998
Phone:	907-488-5242
Fax:	907-488-6385

Company:	The Bay Company
Contact:	Chet Powell, Mike Ottesen
Address:	431 Front Street
	Wrangell, AK 99929
Phone:	907-874-3340
Fax:	907-874-2592

APPENDIX B - SALES AND SERVICE INFORMATION

Company:	Timber & Marine
Contact:	Ken Perry
Address:	2547 Tongass Avenue
	Ketchikan, AK 99001
Phone:	907-225-6644
Fax:	907-225-0644

Company:	Wikan Enterprises
Contact:	Sheri and John Wikan
Address:	PO Box 929
	Petersburg, AK 99833
Shipping:	103 Dock Street
	Petersburg, AK 99833
Phone:	907-772-4155
Fax:	907-772-4153
Email:	wikanent@alaska.com

Arizona

Company:	Aramark / Lake Powell Resorts & Marinas
Contact:	Mark Suttie
Address:	PO Box 1597
	Page, AZ 86040
Phone:	928-645-1186
Fax:	928-645-1101
Email:	suttee-mark@aramark.com

Company:	Desert Recreation, Inc.
Contact:	Jim Ronnie
Address:	315 Long Ave.
	Bull head, City, AZ 86429
Phone:	928-754-4391
Fax:	928-754-3335
Email:	desrec@ctaz.com

Company:	Donn's Boat Shop, Inc.
Contact:	Donn DeVore
Address:	PO box 3826
	Page, AZ 86040
Shipping:	486 Haul Road
	Page, AZ 86040
Phone:	928-645-0313
Fax:	928-645-0323
Email:	boatfxr@donnsboatshop.com

Company:	Mobile Marine Repair, Inc.
Contact:	Steve Ringleman
Address:	PO Box 2988
	Page, AZ 86040
Phone:	928-645-1406
Fax:	928-645-1406

Company:	Old West Marine Service
Contact:	Len Cook, Jason Giffen
Address:	PO Box 4798
	Page, AZ 86040
Shipping:	1002 Vista
	Page, AZ 86040
Phone:	928-645-2705
Fax:	928-645-2542
Email:	oldwest@oldwestmarine.com

Company:	Skipperliner
Contact:	Jay Phelps, Jerry Apalategui
Address:	PO Box 3058
	Page, AZ 86040
Shipping:	550 Haul Road
	Page, AZ 86040
Phone:	928-645-2444
Fax:	928-645-5753

Company:	Skipperliner – Lake Pleasant
Contact:	Mike Montgomery, Glenn Carson
Address:	40202 N. 87th Ave
	Peoria, AZ 85382
Phone:	928-501-2444
Fax:	928-501-2443
Email:	phelpsja@skipperliner.com

Company:	Fishing Boats Unlimited
Contact:	Tony Greyshock, Jason Greyshock
Address:	624 Terminal Way
	Costa Mesa, CA 92627
Phone:	949-642-0882
Fax:	949-642-0419
Email:	crew@fishingboatsunlimited.com
Website:	www.fishingboatsunlimited.com

Company:	Tony's Dri-Dock & Marine
Contact:	Tony Ferrando
Address:	PO Box 897
	Page, AZ 86040
Shipping:	902 Hemlock
	Page, AZ 86040
Phone:	928-645-2732
Fax:	928-645-5237

Company:	Channel Coast Marine
Contact:	Marc Hermann
Address:	2949 W. 5th Street
	Oxnard, CA 93030
Phone:	805-985-0220
Fax:	805-985-7707

Arkansas

Company:	Dreamchaser Houseboats
Contact:	Tiny Joe
Address:	PO Box 356
	Mt Ida, AR 71957
Shipping:	60 Marina Drive
	Mt Ida, AR 71957
Phone:	870-867-3480
Fax:	870-867-2665

Company:	Chris Marine
Contact:	Chris Schjoth
Address:	14265 Holiday Road
	Redding, CA 96003
Phone:	530-275-3097
Fax:	530-275-3096

California

Company:	Bayside Marine Electric
Contact:	Mike Vihel
Address:	PO BOX 685
	Bayside, CA 95524
Phone:	707-498-9999

Company:	Dependable Marine
Contact:	Ernie Monroe, Syd Arnold
Address:	3134 Main Street
	San Diego, CA 92113
Phone:	619-226-2015
Fax:	619-226-0027
Email:	erniedepmar@aol.com

Company:	Easley Consulting
Contact:	Ron Easley
Address:	1048 Irvine Ave #315
	Newport Beach, CA 92660
Phone:	949-287-1619
Email:	roneasley93@yahoo.com

APPENDIX B - SALES AND SERVICE INFORMATION

Company:	Fish Head Marine
Contact:	Robert Johnson (RJ)
Address:	603 Seagaze Dr Ste 162
	Oceanside, CA 92054
Phone:	760-271-0829
Email:	fishheadmarine@gmail.com

Company:	Hoffman Yacht Management
Contact:	Soren Megling
Address:	2330 172 Shelter Is Dr
	San Diego, CA 92106
Phone:	619-990-1409
Email:	steve@hoffmanyachtmgt.com

Company:	John Gumb Yacht Management, LLC
Contact:	Charles (Boomer) Walling
Address:	2330 Shelter Is Dr Ste 160
	San Diego, CA 92106
Phone:	619-247-6697
Fax:	619-437-4324
Email:	dgum@pacbell.net

Company:	Johnson Hicks Marine, Inc.
Contact:	Joe Donatini, Mark Egon, Larry Scroggins
Address:	333 C Lake Ave
	Santa Cruz, CA 95062
Phone:	831-475-3383
Fax:	831-475-1498
Email:	jhme6@cs.com

Company:	Jones Valley & Shasta Lake Resorts
Contact:	Mike Han, Kip Fatout
Address:	22300 Jones Valley Marina Road
	Redding, CA 96003
Phone:	530-275-7950
Fax:	530-275-3523

Company:	Outbound Yacht Service
Contact:	Kevin Ryan
Address:	34241 Pacific Coast Hwy #105
	Dana Point, CA 92629
Phone:	949-488-0652
Fax:	949-489-0704
Email:	kevin@outboundyachtservices.com

Company:	Reliable Marine Electronics
Contact:	Roger Nunez
Address:	1925 Lafayette Street
	Alameda, CA 94501
Phone:	510-885-0525
Fax:	510-885-0526
Email:	radarrog@aol.com

Company:	Ron's Marine Service
Address:	5449 Maricopa Dr
	Simi Valley, CA 93063
Phone:	310-508-2228
Email:	ronsmarine@sbcglobal.net

Company:	Scoles Marine Services
Contact:	Brian Scoles
Address:	615 LeHarve Avenue
	Lake Elsimore, CA 92530-5386
Phone:	909-678-6171
Fax:	909-678-7807

Company:	Sherrill's Marine Service
Contact:	Robert Sherrill, Caleb Linn
Address:	PO Box 2112eet
	Avalon, CA 90704
Phone:	310-510-1610
Fax:	310-510-1352

Company:	Ship Shape Marine
Contact:	Tony Travis
Address:	909 Marina Village Pkwy, #186
	Alameda, CA 94501
Phone:	510-206-0420
Email:	Shipshapemarine@gmail.com

Connecticut

Company:	Mystic River Marina
Contact:	Greg Schroder
Address:	36 Quarry Road
	Mystic, CT 06355
Phone:	860-536-3936

Delaware

Company:	Hinckley Yacht Service
Contact:	Tom Turner
Address:	PO Box 369
	Oxford, MD 21654
Shipping:	Bank Street
	Oxford, MD 21654
Phone:	410-226-5113
	Covers Delaware & Maryland

Florida

Company:	ATM Marine, Inc.
Contact:	Mike Handschmann
Address:	18730 Lenaire Drive
	Miami, FL 33157
Phone:	305-251-7547
Cell:	786-429-7068
Fax:	305-926-3813
Email:	atmmarine1@bellsouth.net

Company:	Dave Gillen Diesel
Contact:	Dave Gillen
Address:	811 N.E. 3RD Street
	Dania Beach, FL 33004
Phone:	954-927-6500
Fax:	954-927-6090
Email:	Gillenda@GillenDiesel.net
Website:	www.Gillendiesel.net

Company:	Mega Yacht Service
Contact:	Dave Laschomb
Address:	408 SE STREAMLET AVE
	Port St. Lucy, FL 34983
Phone:	772-284-9638
Email:	megayacht@bellsouth.net

Company:	Naval Electrical Systems
Contact:	Alain Lauchy
Address:	14681 SW 124th PI
	Miami, FL 33186
Phone:	305-962-7104
Email:	lauchy33@yahoo.com

Company:	Sea Wiz
Contact:	Melody Dodamead
Address:	PO Box 501396
	Marathon, FL 33050
Shipping:	8025 Gulf Stream Blvd
	Marathon, FL 33050
Phone:	305-289-4044
Cell:	305-289-3090
Fax:	305-481-0449

Company:	Yacht Electric Corporation
Contact:	Enrique Giner
Address:	7770 NW 53rd Street
	Miami, FL 33166
Phone:	404-376-8599
Fax:	770-979-4872

Georgia

Company:	J & W Marine Services
Contact:	Jerry Sumrel
Address:	3292 McEver Road, Suite 103
	Buford, GA 30518
Phone:	404-376-8599
Fax:	770-979-4872

Company:	Mobile Marine
Contact:	Painter Stevenson
Address:	4603 Countryside Drive
	Flowery Branch, GA 30542
Phone:	770-480-3805
Fax:	770-965-1864
Email:	sst3485@aol.com

Company:	On Site Marine Service
Contact:	Tim McNeil
Address:	2835 Still Meadows Way
	Buford, GA 30519
Shipping:	6109 Holiday Road
	Buford, GA 30518
Phone:	770-614-0106
Fax:	770-271-1909
Cell:	404-867-1235

Hawaii

Company:	Uhane Enterprises, LLC
Contact:	Jack Womack
Address:	74-425 Kealakehe Parkway #11
	Kailua-Kona, HI 96740
Phone:	808-557-9622
Fax:	808-329-4157
Email:	kalani444@aol.com

Iowa

Company:	S & S Rentals, Inc.
Contact:	Greg Stirn
Address:	PO Box 389
	Lansing, IA 52151
Shipping:	990 South Front Street
	Lansing, IA 51251
Phone:	563-538-4135
Fax:	563-538-4454

Kentucky

Company:	Monticello Mobile Marine
Contact:	Mark Tucker, Pam Tucker
Address:	PO BOX 1090
	Monticello, KY 42633
Shipping:	472 Barleson Sub Rd
	Monticello, KY 42633
Phone:	606-307-7077
Fax:	606-348-3587
Email:	mark@monticellomobilemarine.com
Website:	www.monticellomobilemarine.com

Company:	Pluckebaum Custom Boats, Inc.
Contact:	Jamie Donahue
Address:	1231 State Road 1793
	Prospect, KY 40059
Phone:	502-228-0111
Fax:	502-228-4767

Company:	The Boat Doctor
Contact:	Ancil Shelton
Address:	950 Duncan Valley Rd
	Monticello, KY 42633
Phone:	606-348-3484
Fax:	606-307-4960

Louisiana

Company:	Total Electric Service of Arcadiana
Contact:	Barry LaGrange
Address:	200 Rue Degravelle
	New Iberia, LA 70563
Phone:	337-367-6756
Fax:	337-367-6765

Maryland

Company:	Hinckley Yachts Services
Contact:	Tom Turner
Address:	PO Box 369
	Oxford, MD 51654
Shipping:	Bank Street
	Oxford, MD 51654
Phone:	410-226-5113
Fax:	410-226-5602
	Covers Delaware & Maryland

Company:	Middle River Electronics
Contact:	John Weaver, Darren Weaver
Address:	233 C Nanticoke Road
	Baltimore, MD 21221
Phone:	410-687-6474
Fax:	410-687-3353

Massachusetts

Company:	Niemiec Marine
Contact:	Martin Niemiec
Address:	173 Popes Island
	New Bedford, MA 02740
Phone:	508-997-7390
Fax:	508-997-8978

Nevada

Company:	A & M Marine
Contact:	Jim Bell, Scott Wall
Address:	1630 Foothill Drive
	Boulder City, NV 89005
Phone:	702-293-1321
Fax:	702-293-5896
Cell:	609-517-5595
Email:	anmmarine@aol.com

Company:	Callville Bay Resort & Marina
Contact:	Carl Ward
Address:	HCR 30 Box 100
	Las Vegas, NV 89124
Phone:	702-565-4813
Fax:	702-566-9899

New Jersey

Company:	Authority Marine Service
Contact:	Scott Self
Address:	1 Marine Bay Ct
	Highland, NJ 07732
Phone:	732-291-0012
Email:	authoritymarineservice@verizon.net

Company:	Martek Electronics
Contact:	Charles Hewitt
Address:	47 South Shore Road
	Marmora, NJ 08223
Phone:	609-390-3355
Fax:	609-369-0849
Cell:	609-517-5595

APPENDIX B - SALES AND SERVICE INFORMATION

New York

Company:	Den-Mac Sales
Contact:	Dennis McGowen
Address:	8 Ramick Drive West
	Amityville, NY 11701
Phone:	631-842-8967
Fax:	631-842-5274

Company:	Marine Control Systems
Contact:	Gary Sorenson
Address:	76 May Apple Lane
	Franklyn, NC 28734
Phone:	828-508-4201
Fax:	828-369-7572

Oregon

Company:	Montauk Marine Basin, Inc
Contact:	Mark Jarboe
Address:	PO Box 610
	Montauk, NY 11954
Shipping:	426 Westlake Drive
	Montauk, NY 11954
Phone:	631-668-5900
Fax:	631-668-5659
	Covers 60 miles west only

Company:	Cook Engine & Co.
Contact:	Jeff Dykes
Address:	503 NE Tomahawk Island Drive
	Portland, OR 97217
Phone:	503-289-8466
Fax:	503-286-2836
Email:	sales@cookengine.com

North Carolina

Company:	Demann Marine Power
Contact:	Tom Demann
Address:	107 Bryan Road
	Wilmington, NC 28412
Phone:	910-791-6222
Fax:	910-791-7056

Company:	Curry Marine
Contact:	Terry Wheeler, Scot Graf, Laurie Wheeler
Address:	PO Box 610
	Newport, OR 97365
Shipping:	1211 SE Bay Blvd
	Newport, OR 97365
Phone:	541-265-7655
Fax:	541-265-4226

Company:	Griffin Marine, Inc.
Contact:	Don Griffin, Don Griffin Jr., Casey Carr
Address:	PO Box 458
	Wanachese, NC 27981
Shipping:	898 Harbor Road
	Wanachese, NC 27981
Phone:	252-473-1422
Fax:	252-473-4654
Email:	griffinmarine@mindspring.com

Company:	George's Marine Electric
Contact:	Bill Elderkin, Paul Kepford
Address:	PO Box 5530
	Charleston, OR 97420
Phone:	541-888-5209
Fax:	541-888-9557

Company:	Sells Marine
Contact:	Paul Wilson
Address:	1111 NE Marine Drive
	Portland, OR 97211
Phone:	503-285-3838

Puerto Rico

Company:	Yacht Specialty
Contact:	David Davila
Address:	RR #2 Box 693
	San Juan, PR 00926
Phone:	787-755-4406
Fax:	787-755-4406
Cell:	787-397-7518

South Carolina

Company:	MacKay Communications
Contact:	Tony Smircic
Address:	1369 B Ashley River Road
	Charleston, SC 29407
Phone:	865-966-8481
Fax:	843-571-5301

Company:	Tidal Marine Electronics Ltd.
Contact:	Jeff Sechrest
Address:	1643 B Savannah Hwy, Suite 340
	Charleston, SC 29407
Phone:	843-763-8553
Fax:	843-763-8554
Email:	tidalmarineelec@aol.com

Tennessee

Company:	Simpson Marine Electronics
Contact:	R.S. Simpson
Address:	PO Box 22213
	Knoxville, TN 37933
Shipping:	665 Chapel Point Lane
	Knoxville, TN 37922
Phone:	865-966-8481
Fax:	865-966-9707

Texas

Company:	Lakewood Yacht Service
Contact:	Dennis Osborne, Danny Baldwin
Address:	POBox 536
	Seabrook, TX 37933
Shipping:	2301 Nasa Road 1
	Seabrook, TX 77586
Phone:	281-474-2885
Fax:	281-474-2885
Email:	jjohnston@lakewoodyachtservice.com

Utah

Company:	Aramark – Halls Crossing
Contact:	Mark Grahn
Address:	PO Box 5101
	Lake Powell, UT 84533
Phone:	435-684-7019
Fax:	281-474-2885

Company:	Bullfrog Boat Shop
Contact:	Tami Luckson
Address:	PO Box 4055
	Lake Powell, UT 84533
Phone:	435-684-3018
Fax:	435-684-3005

Company:	Offshore Marina, Inc.
Contact:	Daryl Hickson, Chris Pear
Address:	PO Box 330330
	Lake Powell, UT 84533
Shipping:	Hwy 276, Mile Marker 30
	Lake Powell, UT 84533
Phone:	435-788-2303
Fax:	offshoremarinaLP@aol.com
Email:	435-788-2303

APPENDIX B - SALES AND SERVICE INFORMATION

Virginia

Company:	Bluewater Yacht Sales
Contact:	Craig Messick
Address:	26 Marina Yacht Charters
	Hampton, VA 23702
Phone:	757-723-0793
Fax:	757-723-3320

Company:	Maritime Fabrications / LaConner Maritime
Contact:	Tony Ford, Joe Franett
Address:	PO Box 816
	LaConner, WA 98257
Shipping:	920 W. Pearle Jensen Way
	LaConner, WA 98257
Phone:	360-466-3629
Fax:	360-466-3632

Washington

Company:	Anacortes Yacht Charters
Contact:	Sandy
Address:	2415 T Avenue, #112
	Anacortes, WA 98221
Phone:	360-293-4555
Fax:	360-293-6683

Company:	North Harbor Diesel, Inc.
Contact:	Dave Williams, Mike Curran
Address:	720 30th Street
	Anacortes, WA 98221
Phone:	360-293-5551
Fax:	360-293-0728
Email:	nharbor@fidalgo.net

Company:	Complete Controls
Contact:	Jim Palmer
Address:	9306 NE 7th Street
	Vancouver, WA 98664
Phone:	360-904-7525
Fax:	360-254-7846
Email:	palmer.jim@comcast.net

Company:	Ocean Alexander Marine Center
Contact:	Scott Morris
Address:	1115 N. Northlake Way
	Seattle, WA 98103
Phone:	206-547-1395
Fax:	206-547-3789

Company:	Islands Marine Center, Inc
Contact:	Ron Meng
Address:	PO Box 88
	Lopez Island, WA 98261
Shipping:	Fisherman's Bay Road
	Lopez Island, WA 98261
Phone:	360-468-3377
Fax:	360-468-2283

Company:	Puget Sound Yacht Service
Contact:	Paul Waits
Address:	9611 146th Place SE
	Snohomish, WA 98296
Phone:	206-660-3630
Fax:	206-483-0710
Email:	psyachtservice@aol.com

Company:	Marine Service Center, Inc. – ANA
Contact:	Skip Dassler
Address:	2417 T Avenue
	Anacortes, WA 98221
Phone:	360-293-8200
Fax:	360-293-9648

Company:	Radar Marine Electronics
Contact:	Bill Pulse
Address:	16 Squallicum Mall Blvd
	Bellingham, WA 98225
Phone:	360-733-2012
Fax:	360-733-2383

Company:	Reliance Marine Electronics
Contact:	Randy Widen
Address:	2436 NW 61st
	Seattle, WA 98107
Phone:	206-781-1105
Fax:	206-789-9775
Email:	randy@wolfenet.com
Works in Alaska – May & June Only - Call:907-842-3917	

Company:	Roberts Maritime
Contact:	Bill Roberts
Address:	PO BOX 1592
	Coupeville, WA 98239
Phone:	360-678-4235
Fax:	360-678-5576
Email:	boatzz@comcast.net

Company:	Yacht Care, Inc
Contact:	Jim Brown
Address:	26010 West Marina Place, Suite K
	Seattle, WA 98199
Phone:	206-285-2600
Fax:	206-285-2610
Cell:	360-914-0256

Factory Authorized Sales & Service Centers - International

Argentina

Company:	Transmisiones Marinas S.A.
Contact:	Ing. Daniel Canoura
Address:	Hernandarias 3656
	B7603GNH Mar Del Plata
	Argentina
Phone:	54-223- 410 7975
Fax:	54-223- 480 7174
Email:	TM@tmgroup.com.ar; tmventas@tmgroup.com.ar
Website:	www.tmgroup.com

Company:	Trimer S.A.
Contact:	Carlos Dorian Freidlander
Address:	Attn: Mariano Castroverde
	PO Box 772
	1000 Buenos Aires, Argentina
Shipping:	Fray J.S.M. de Oro 2030-40
	1425 Buenos Aires, Argentina
Phone:	54-11-4580-0444
Fax:	54-11-4580-0440
Email:	trimer@trimer.com.ar

Australia

Company:	ZF Services Australia Pty, Ltd.
Contact:	Gary Bain, Rodney Lean
Address:	Locked Bag 6305
	Blacktown BC NSW 2148
	Australia
Shipping:	14 Lidco Street
	Arndell Park, NSW 2148
	Australia
Phone:	61- (0)2-9679-5555
Fax:	61-(0)2-9679-5500
Email:	gary.bain@zf.com.au or oesales@zf.com
Website:	www.zf.com.au

Brazil

Company:	ZF do Brazil S.A.
Contact:	Richard Bergamini
Address:	Avenida Conda Zeppelin, 1935
	CEP 18103-0000 Sorocaba, Brazil
Phone:	5515-235-2301
Fax:	5515-235-2233
Email:	richard.bergamini@zf.com
Website:	www.zf-marine.com

Chili

Company:	Equipamiento Marino Ltda
Contact:	Christian Rogers Nicklmann
Address:	Rafael Correa 1268 Vitacura
	Santiago, Chili
Phone:	(56-2) 4158737
Fax:	(56-2) 9-9975059
Email:	info@equipamientomarino.cl

China

Company:	Foilborne Engineering, Ltd.
Contact:	Paul Chow
Address:	Unit A 7-9, 13/F Veristrong 34-36 Au Pui Wan Street / FO-Tan Shatin, N.T. Hong Kong, China
Phone:	852-2687-2988
Fax:	852-2687-1996
Email:	paulchow@foilborne.biz.com.hk

Company:	Renford Marine Equipment (<u>China</u>) Ltd.
Contact:	Anthony Yuen
Address:	501 Laws Commercial Plaza 788 Cheung Sha Wan Road Hong Kong, China
Phone:	852-27427111
Fax:	852-27427171
Email:	anthony.yuen@renford.com

Company:	Renford Marine Equipment (<u>Shanghai</u>) Ltd.
Contact:	Anthony Yuen
Address:	811 Jiaxing Building 877 Dong Fang Road, Pudong Shanghai, China 200122
Phone:	8621-50589000
Fax:	8621-505880007
Email:	anthony.yuen@renford.com

Company:	ZF Shanghai Rep. Office
Contact:	Tang Zhou Qing, Gong Lan
Address:	Room 2504, Jiangnan Building No. 600 Luban Road Shanghai, 200023, PR China
Phone:	0086-21-6301-4338
Fax:	0086-21-6301-6449
Email:	qiwei.yao@zf.com
Website:	www.zf-marine.com

Denmark

Company:	ZF Danmark APS
Contact:	Michael Johansson, Frank Kiessling
Address:	Taastrupgaardsvej 8-10 Taastrup, DK-2630, Denmark
Phone:	45-7022-6243
Fax:	45-7022-2643
Email:	frank.kiessling@zf.com; michael.johansson@zf.com
Website:	www.zf-marine.com

Ecuador

Company:	ZF Marine's Consulting
Contact:	Pedro Aspiazu
Address:	Urdesa Central 1A #13184 Costanera Guaaquil – Guayas, Ecuador
Phone:	(593-4) 238-9306
Fax:	(593-4) 238-4010
Email:	zfmachineconsulting@yahoo.com

Finland

Company:	Atoy Oy
Contact:	Antti Hiidenheim
Address:	PO Box 137 FIN-00101, Helsinki Finland
Phone:	35-8968271
Fax:	35-896827305
Email:	anttihiidenheim@atoy.fi

France

Company:	ZF France
Contact:	Ronald Gamere
Address:	3, rue Henri Poincaré' 92167 ANTONY CEDEX, France
Phone:	+33 (01) 40 96 42 74
Fax:	+33 (01) 40 96 42 74
Email:	Ronald.Gamere@zf.com
Website:	www.zf.com/sso/fr

Germany

Company:	Otto Piening Propeller GMBH
Contact:	Mathias Pien
Address:	AM Altendeich 83
	D25348 Glückstadt
	Germany
Phone:	49-4124-916812
Fax:	49-171-4853376
Email:	pein@piening-propeller.de
Website:	www.piening-propeller.de

Greece

Company:	Amaltheia Marine, Ltd
Contact:	Demetris Kyriazis
Address:	13 Papaflessa Str.
	143 43 N. Halkidona
	Athens, Greece
Phone:	30210-25-88-985
Fax:	30210-25-89-986
Email:	amalmar@otenet.gr

Iceland

Company:	Maras ehf
Address:	Gudmundur Bragasson
	Akralind 2
	201 Kopavogur
	Iceland
Phone:	354-555-6444
Fax:	354-565-7230
Email:	Gummi@maras.is

Ireland

Company:	ZF Services Great Britain, Ltd
Contact:	Adi License
Address:	Abbeyfield Road, Lenton
	Nottingham, United Kingdom
	NG7 2SX, England
Phone:	44-115-986-9211
Fax:	44-115-986-9261
Email:	adi.license@zf.com

Website:	www.zf-marine.com
----------	-------------------

Italy

Company:	Saim SPA
Contact:	Antonio Renzetti, Alessandro Busetto
Address:	Via Donizetti, 9/11
	20090 Assago (MI)
	Italy
Phone:	39-02-488-521
Fax:	39-02-45703070
Email:	alessandro.busetto@saim-group.com; antonio.renzetti@saim-group.com
Website:	www.saim-group.com

Japan

Company:	ZF Marine Japan Co. Ltd
Contact:	Y. Ikeda, Nobora Kasajima
Address:	Fujikoshi Bldg. 1-10-11 Iriya taito-ku
	Tokyo, 110-0013
	Japan
Phone:	81-03-5808-4521
Fax:	81-03-5808-4531
Email:	mikio.sato@zf.com
Website:	www.zf-marine.com

Korea

Company:	SE Jung Engineering Co.
Contact:	M.G. Song
Address:	#35-4 Namhangdong-1KA
	Yeongdogu
	Pusan, Korea
Phone:	82-51-415-0591
Fax:	82-51-412-6361
Email:	sjeng88@kornet.net

Mexico

Company:	Baja Naval, s.a. de c.v.
Contact:	Jaime Hernandez, Alfredo Soqui, Mario Herrera
Address:	Av. de le Marina, 10
	Ensenada,
	Baja California Norte 22800
Phone:	011 52 646 174 0020
Fax:	011 52 646 174 0028
Email:	diego@bajanaival.com

Company:	RAL LINE, S.A. DE C.V.
Contact:	Ing. Ernesto Cadavid
Address:	Av. Gran Via Tropical #8
	Fraccionamiento Las Playas
	Acapulco, Gro. Mexico
Phone:	744-482-6365
Fax:	744-482-6365
Email:	ecadavid@ralline.com.mx

New Zealand

Company:	ZF Services Australia Pty, Ltd
Contact:	Gary Bain, Rodney Lean
Address:	Locked Bag 6305
	Blacktown BC
	NSW, Australia 2148
Shipping:	14 Lidco Street
	Arndell Park, NSW
	Australia 2148
Phone:	61-02-9679-5555
Fax:	61-02-9679-5500
Email:	gary.bain@zf.com.au or oesales@zf.com

Norway

Company:	KGK Norge AS
Contact:	Bjorn Reiersen
Address:	Casper Storms Vei 19
	N-0064 Oslo
	Norway
Phone:	47-22-884-680
Fax:	47-22-720-902
Email:	bjorn.reiersen@zf-group.com

Peru

Company:	PGO International S.A.C
Contact:	Pedro Gonzalez – Orbegoso
Address:	AV. Arequipa 2450 of 1108
	Lima 14, Peru
Phone:	(51-1) 421-6055
Fax:	(51-1) 421-6664
Email:	pgorbegoso@perusat.net.pe

Russia

Company:	ZF Russia
Contact:	Anastassia Selverstova
Address:	71, Marata Street Ste 313
	St Petersburg
	Russia 191119
Phone:	7-812-324-54-72
Fax:	7-812-140-18-15
Email:	anastassia.selverstova@zf.sp.ru

Scotland

Company:	ZF Services Great Britain, Ltd
Contact:	Adi License
Address:	Abbeyfield Road, Lenton
	Nottingham, United Kingdom
	NG7 2SX England
Phone:	44-115-986-9211
Fax:	44-115-986-9261
Email:	adi.license@zf.com
Website:	www.zf-marine.com

Singapore

Company:	Mammoth Enterprises Pte, Ltd
Contact:	Steven Wee
Address:	PO Box 283
	Siglap Post Office
	Singapore 914503
Shipping:	6-A Waringin Park
	Singapore 416320
Phone:	65-6-44-88266
Fax:	65-6-44-89800
Email:	mament@singnet.com.sg

Spain

Company:	ZF Espana S.A.
Contact:	Maria Valladolid
Address:	Avda. Fuentemar, 11
	Coslada (Madrid) 28820
	Spain
Phone:	34 (0) 91485-2695
Fax:	34 (0) 91485-0036
Email:	maria.valladolid@zf.com
Website:	www.zf-marine.com

Sweden

Company:	ZF South East Asia
Contact:	Sharon Ho
Address:	11, Tuas Drive 1
	Singapore
Phone:	6861-0177
Fax:	6861-9173
Email:	sharon.ho@zf-seasia

Company:	KG Knutsson AB
Contact:	Karl-Henry Pragsten
Address:	Tansmissions Divisionen
	Hammarbracken 8
	S-191 81 Sollentuna
	Sweden
Phone:	46-08-923-312
Fax:	46-08-929-599
Email:	zf-marine@kgk.se
Website:	www.kgk.se

South Africa

Company:	ZF South Africa Pty, Ltd
Contact:	Heather Hermann
Address:	PO Box 2098
	Kempton Park, 1620 South
	Africa
Shipping:	C/O Barlows Power Systems
	Cnr Peter Barlow and Kasselss Vlei Rd
Phone:	27-11-453-1818
Fax:	27-11-453-7506
Email:	heather@zfsa.za

Switzerland

Company:	Marine Parts Technic
Contact:	Fabian Kraemer
Address:	Pfaffikerstrasse 6
	CH-8604 Volketswil
	Zurich, Switzerland
Phone:	41-1997-4090
Fax:	41-1997-4094
Email:	info@marineparts.ch; fabian.kraemer@marineparts.ch
Website:	www.marineparts.ch

Taiwan

Company:	Asia Diesel electric Corp
Contact:	Mike Ou
Address:	8F-1, No. 34, Min Chuan 1s. Road Kaohsiung, Taiwan. #80205
Phone:	886-7-3331191
Fax:	886-7-3346808
Email:	ade.taiwan@msa.hinet.net
Website:	www.asiadiesel.com.tw

Thailand

Company:	ZF Thailand Co. Ltd
Contact:	Reungpoj V
Address:	159/33 Soi Vipawasee 64 Vipawasee-Rangsit Road Laksi, Bangkok 10210 Thailand
Phone:	66-2-521-6520
Fax:	66-2-521-6523
Email:	tanapath@bkk.loxinfo.th

The Netherlands (Holland)

Company:	ADS/van Stigt
Contact:	Ton Hekman, Rob van der Linde
Address:	Avelingen – West 30 NL-4202 MS Gorinchem The Netherlands
Phone:	31-0-183-650000
Fax:	31-0-183-650001
Email:	Ton.Hekman@vanstigt.com
Website:	info@vanstigt.com

U.A.E.

Company:	ZF Middle East, LLC
Contact:	M. Narasimhan (Narsi), A.T. Moorthy
Address:	PO Box 26093 Sharjah, U.A.E.
Shipping:	#502 Golden Tower Building Sharjah, U.A.E.
Phone:	971-6-5747074
Fax:	971-6-5747174
Email:	thiru.moorthy@zf-marine.com; narasimhan.manian@zf-marine.com
Website:	www.zf-marine.com

United Kingdom

Company:	Atlantis Marine Power, Ltd
Contact:	Peter Middleton, Paul Lakey
Address:	Western wood Way Language Science Park Plymouth, Devon, PL7 5BG 5BG England
Phone:	44-1752-208810
Fax:	44-1752-208811
Email:	paul.lakey@atlantismarine.co.uk; peter@atlantismarine.com
Website:	www.atlantismarine.co.uk

USA

Company:	ZF Marine – US Headquarters
Contact:	A.J. Halavacs
Address:	15351 SW 29th Street, Ste 300 Miramar, FL 33027
Phone:	954-441-4040
Fax:	954-441-4140
Email:	aj.halavacs@zf.com
Website:	www.zf-marine.com

Company:	ZF Marine, LLC – Gulf Coast
Contact:	Mike Gauthreaux
Address:	161 James Drive West
	Suite 120
	St Rose, LA 70087
Phone:	504-443-0501
Fax:	504-443-0504
Email:	mike.gauthreaux@zf.com
Website:	www.zf-marine.com

Company:	ZF Marine –West Coast
Contact:	Bud Bloom, Kevin Zwicker
Address:	12125 Harbour Reach Drive Ste B
	Mukilteo, WA 98275
Phone:	425-583-1900
Fax:	425-493-1569
Email:	kevin.zwicker@zf.com; bud.bloom@zf.com
Website:	www.zf-marine.com

Venezuela

Company:	Sistemas de Propulsion C.A.
Address:	AV 67a Entre 149By 150
	2 Etapa Zona Industrial
	Maracaibo, Venezuela
Phone:	58-261-736-0747
Fax:	58-261-736-0746
Email:	spd@sistemaspropulsion.com

9000 Series Micro/ClearCommand Servo Throttle - Servo Clutch QFA & DVTP**ENG-127-1: Revision List**

Rev	Date	Description
A	4/15/05	Release authored by Joe Case, approved by Robert Anderson, verified by Jeff Turner.
A.1	02/23/2012	Revised per ELR00158

Qualitative Failure Analysis

The following qualitative failure analysis is provided to show compliance with:

- Subchapter K Small Passenger Vessels, 46 CFR 121.620
- Subchapter L Offshore Supply Vessels, 46 CFR 130.120
- Subchapter T Small Passenger Vessels, 46 CFR 184.620:

Propulsion engine control systems.

- a A vessel must have two independent means of controlling each propulsion engine. Control must be provided for the engine speed, direction of shaft rotation, and engine shutdown.
 1. One of the means may be the ability to readily disconnect the remote engine control linkage to permit local operation.
 2. A multiple engine vessel with independent remote propulsion control for each engine need not have a second means of controlling each engine.
- b In addition to the requirements of paragraph (a) of this section, a vessel must have a reliable means for shutting down a propulsion engine, at the main pilot house control station, which is independent of the engine's speed control.
- c A propulsion engine control system, including pilothouse control, must be designed so that a loss of power to the control system does not result in an increase in shaft speed or propeller pitch.
- d All microprocessor or computer based systems must meet the requirements of part 62 in subchapter F of this chapter.

Propulsion control.

- a Each vessel must have--
 1. A propulsion-control system operable from the pilothouse; and
 2. A means at each propulsion engine of readily disabling the propulsion-control system to permit local operation.
- b Each propulsion-control system operable from the pilothouse must enable--
 1. Control of the speed of each propulsion engine;
 2. Control of the direction of propeller-shaft rotation;
 3. Control of propeller pitch, if a controllable-pitch propeller is fitted; and
 4. Shutdown of each propulsion engine.
- c The propulsion-control system operable from the pilothouse may constitute the remote stopping-system required by Sec. 129.540 of this subchapter.
- d Each propulsion-control system, including one operable from the pilothouse, must be designed so that no one complete or partial failure of an easily replaceable component of the system allows the propulsion engine to over-speed or the pitch of the propeller to increase.

Propulsion engine control systems.

- a A vessel must have two independent means of controlling each propulsion engine. Control must be provided for the engine speed, direction of shaft rotation, and engine shutdown.
 - 1. One of the means may be the ability to readily disconnect the remote engine control linkage to permit local operation.
 - 2. A multiple engine vessel with independent remote propulsion control for each engine need not have a second means of controlling each engine.
- b In addition to the requirements of paragraph (a), a vessel must have a reliable means for shutting down a propulsion engine, at the main pilothouse control station, which is independent of the engine's speed control.
- c A propulsion engine control system, including pilothouse control, must be designed so that a loss of power to the control system does not result in an increase in shaft speed or propeller pitch.

The ZF Marine Electronics MicroCommander/ClearCommand 9000 Series (servo throttle, servo clutch version) marine engine controls offer single lever control of speed and direction. Each enclosure houses an independent Control Processor and requires separate power supplies. The system operates on 12 or 24VDC power and can have up to five remote stations depending on the application. The system sequences the operation of speed and shift in order to prevent an inexperienced operator from mishandling the engine or transmission.

A requirement of the ZF Marine Electronics MicroCommander/ClearCommand system is that there be an engine 'STOP' button at each remote station.

A standard feature is an alarm contact (normally open) to interface with the main alarm system of the vessel. This switch will open and activate the alarm system with a power loss or CPU failure. In addition, ZF Marine Electronics provides audible tones at the Control Head locations to indicate system faults.

ITEM NUMBER	FAILED COMPONENT	ALARM STATUS	INITIAL RESULT	FINAL OUTCOME
1	Zf Marine Electronics Control Head	Audible Tone Will Sound At Control Head	Throttle Resets To Idle	No Increase In Engine Rpm
			Clutch Shifts To Neutral	No Increase In Shaft Speed
2	Loss Of Power Supply	Alarm Circuit Will Open	Throttle Remains At Last Commanded Position	No Increase In Engine Rpm
			Clutch Remains At Last Commanded Position	No Increase In Shaft Speed
3	Zf Marine Electronics Throttle Feedback Potentiometer	Audible Tone Will Sound At Control Head	Throttle Resets To Idle	No Increase In Engine Rpm
			Clutch Remains At Last Commanded Position	No Increase In Shaft Speed
4	Zf Marine Electronics Clutch Feedback Potentiometer	Audible Tone Will Sound At Control Head	Throttle Resets To Idle	No Increase In Engine Rpm
			Clutch Remains At Last Commanded Position	No Increase In Shaft Speed

Design Verification Test Procedure

The MicroCommander/ClearCommand 9000 Series (servo throttle, servo clutch version) Propulsion Control System is compliant to the environmental design standards in 46 CFR 62.25-30.

The following test procedure covers the 4 items included in the Qualitative Failure Analysis; 1) Control Head Potentiometer failure, 2) Loss of power supply, 3) Throttle Feedback Potentiometer failure, and 4) Clutch Feedback Potentiometer failure.

Failure: Control Head Potentiometer failure.

- a **Results:** The Processor will shift to Neutral (if needed) and throttle will go to Idle, (if needed).
- b Test Procedure
 1. Turn power ON to both Port and Starboard Processors. Take command at a Control Head.
 2. Move the Port and Starboard Control Head levers to approximately ½ Ahead.
 3. Locate the green wire coming from the Port Control Head in command, connecting to pin 6 of the respective terminal block on the Processor circuit board. Disconnect it from the Processor circuit board.
 - The Port Processor will shift to Neutral (if needed) and throttle will go to Idle (if needed).
 - The Port Control Head will give an audible tone indicating a faulty potentiometer.
 4. Move the Port and Starboard Control Head levers back to Neutral. Reconnect the green wire.
 5. Take command at the Control Head
 6. Repeat for Starboard side.

Failure: Power failure to MicroCommander/ClearCommand 9000 Series

A power failure to the MicroCommander/ClearCommand 9000 Series circuit board will have the same results as a failed microprocessor

- a Results
 1. Throttle and clutch will remain at last commanded position.
 2. LED at Control Heads will not be lit.
 3. Opposite engine still under power has full control.
- b Test Procedure.
 1. Turn power ON to both Port and Starboard Processors. Take command at a Control Head.
 2. Move the Port and Starboard Control Head levers to approximately ½ Ahead.
 3. Turn power OFF to the Port side only.
 - Port side throttle and clutch will remain at last commanded position.
 - LED on the Port side of the Control Head in command will go OFF.
 - The Port Control Head will no longer have command of the engine and gear.
 - The Starboard Control Head will still have full command of the Starboard engine and gear.
 4. Turn power ON to the Port Processor. Return Control Head lever to Neutral. Take command of the Port side.
 - The Port Control Head will operate as usual-(Non-volatile memory)
 5. Repeat test for Starboard Processor.


Failure: Throttle Feedback Potentiometer failure

- a **Results:** Throttle will go to Idle (if needed).
- b **Test Procedure.**
 1. Turn power ON to both Port and Starboard Processors. Take command at a Control Head.
 2. Move the Port and Starboard Control Head levers to approximately 1/2 Ahead.
 3. On the Port Processor, locate the 3-pin plug above the throttle servo on the Processor's main circuit board. Disconnect the plug from the circuit board.
 - The Port Processor will move the throttle to Idle.
 - The Port Control Heads will give an audible tone indicating a faulty throttle feedback potentiometer.
 4. Move the Port and Starboard Control Head levers back to Neutral.
 5. Replace the 3-pin plug.
 6. Acknowledge the error by pressing the transfer button.
 7. Repeat test for Starboard Processor.

Failure: Clutch Feedback Potentiometer failure

- a **Results:** Clutch will remain at last commanded position. Throttle will go to Idle (if needed).
- b **Test Procedure.**
 1. Turn power ON to both Port and Starboard Processors. Take command at a Control Head.
 2. Move the Port and Starboard Control Head levers to approximately 1/2 Ahead.
 3. On the Port Processor, locate the 3-pin plug above the clutch servo on the Processor's main circuit board. Disconnect the plug from the circuit board.
 - The Port Processor clutch servo will remain at last commanded position. Throttle servo will drive to Idle.
 - The Port Control Heads will give an audible tone indicating a faulty clutch feedback potentiometer.
 4. Move the Port and Starboard Control Head levers back to Neutral.
 5. Replace the 3-pin plug.
 6. Acknowledge the error by pressing the transfer button.
 7. Repeat test for Starboard Processor.

14 Appendix C - System Drawings



SEE SHEET 3 FOR NOTES


REV	BY	DATE	DESCRIPTION
A	R.A.	04/05	SHT 2: REVISED TACH SENSOR; SHT 3: REVISED NOTE 13

ZF MARINE ELECTRONICS, LLC
 12125 HARBOUR REACH DR. WAKILUO WA, 98275
 MICROCOMMANDER—MECHANICAL
 THROTTLE/SHIFT—SYSTEM DRAWING

ENG. T.JONES	DWN. MAMLISON
WFG. R.J.Z.	QA. RBH.
DATE 7-16-03	SHT. 1 OF 3
SCALE: NONE	SIZE: B
PART NO. 91102	DWG. NO. 12271

Drawing 12271 MicroCommander - Mechanical Throttle / Shift

91102 INTERNAL CONNECTIONS



* DENOTES WIRING FOR A TWIN SCREW APPLICATION

SEE SHEET 3 FOR NOTES


REV. A : SEE SHEET 1	
ZF MARINE ELECTRONICS, LLC 12125 HARBOUR REACH DR. MUKLETO WA. 98275	
MICROCOMMANDER-MECHANICAL THROTTLE/SHIFT-SYSTEM DRAWING	
ENG. T. JONES	DWN. WILSON
WFE. R. J.Z.	O.A. R.B.H.
DATE 7-16-03	SHT. 2 OF 3
SCALE: NONE	SIZE: B
PART NO. 91102	DWG. NO. 12271

- NOTES -

- NOTES -



1. DO NOT MOUNT CONTROL SYSTEM COMPONENTS ON ENGINE OR REDUCTION GEAR.
2. DO NOT MOUNT CONTROL COMPONENTS NEAR SOURCES OF HIGH HEAT. (EXHAUST DUCTS, ETC.)
3. DO NOT MOUNT CONTROL COMPONENTS NEAR SOURCES OF STRONG ELECTROMAGNETIC FIELDS. (STARTERS, GENERATORS, ETC.)
4. MOUNT CONTROL COMPONENTS IN A LOCATION ACCESSIBLE FOR CHECKOUT, MONITORING AND MAINTENANCE.
5. ALL ELECTRICAL CABLES ARE TO BE SUITABLE FOR MARINE APPLICATION AND MEET ALL APPLICABLE REGULATORY REQUIREMENTS.
6. INSURE THAT SHIELD ON THE SHIELDED CABLE IS CONNECTED ONLY AT ONE END TO THE CHASSIS AND THAT THE DRAIN WIRE DOES NOT TOUCH ANY OTHER CONDUCTIVE SURFACE.
- 6A. INSURE THAT DRAIN WIRE ON SHIELDED CABLE IS CONNECTED ONLY WHERE INDICATED INSIDE HOUSING AND THAT DRAIN WIRE DOES NOT TOUCH ANY OTHER CONDUCTIVE SURFACE. FOR OPTIMAL SCREENING THE SERIAL WIRE HARNESS SHIELD SHOULD BE CONNECTED TO "EARTH" AT ONE POINT IN THE VESSEL. (NOT INSIDE THE UNIT)
7. START INTERLOCK RELAY WITH NORMALLY OPEN CONTACTS. CONTACTS ARE CLOSED WHEN SYSTEM IS OPERATING AND COMMANDING NEUTRAL. MAXIMUM OF 5 AMP, MAXIMUM OF 30V.
8. THE CONTROL PROCESSOR WILL BE PROVIDED SHIPS SUPPLY OF 12 OR 24 VDC, PROTECTED BY A 10 AMP RATED CIRCUIT BREAKER PROVIDED BY THE SHIPYARD.
9. CONTROL FAILURE ALARM RELAY CONTACTS RATED FOR A MAXIMUM OF 0.5A, MAXIMUM CONTACT DRY RATING OF 100V. DO NOT EXCEED THIS RATING. IT IS THE SHIPYARDS RESPONSIBILITY TO UTILIZE THE ALARM CONNECTION IN AN APPROPRIATE ALARM CIRCUIT.
10. CAUTION:
THIS PART CONTAINS ELECTRONIC COMPONENTS WHICH CAN BE DESTROYED BY STATIC ELECTRICITY. PERSONNEL SHOULD GROUND THEMSELVES TO DISSIPATE ANY STATIC ELECTRICITY PRIOR TO WORKING INSIDE THE PART.
11. PRESSURE SWITCH SETPOINT (N.O. CONTACTS) MUST BE SET AT 150 PSI OR AS RECOMMENDED BY TRANSMISSION MANUFACTURER. WHEN CONTACTS CLOSE THIS INDICATES TO THE CONTROL PROCESSOR WHEN THE CLUTCH IS SUFFICIENTLY ENGAGED TO ALLOW A SPEED COMMAND ABOVE IDLE SPEED. IT IS A SAFETY FEATURE THAT PROTECTS THE CLUTCH AND ITS USE IS RECOMMENDED.
12. THE CONTROL PROCESSOR'S MOUNTING FEET MUST BE CONNECTED TO THE VESSEL'S BONDING SYSTEM.
13. FREQUENCY INPUT FOR ENGINE SYNCHRONIZATION:
(INPUT PULSES EITHER AC TYPE TACH INPUT OR OPEN COLLECTOR TYPE INPUT)
AC COUPLED INPUT (T89-2): MINIMUM FREQUENCY 30Hz - MAXIMUM FREQUENCY 8000Hz.
MINIMUM VOLTAGE 3V - MAXIMUM VOLTAGE 200V, PEAK TO PEAK.
OPEN COLLECTOR INPUT (T89-3): MINIMUM FREQUENCY 5Hz - MAXIMUM FREQUENCY 8000Hz.
MINIMUM SINK CURRENT 2mA, MAX SENSOR OUTPUT SATURATION VOLTAGE 0.8V.
14. REFER TO DRAWING 11488 FOR ADDITIONAL POWER OPTIONS.
15. THIS PROCESSOR COMES EQUIPPED WITH TWO STATIONS PRE-WIRED. THREE ADDITIONAL STATIONS MAY BE ADDED BY EITHER HARD CABLE WIRING INTO THE LOCATIONS SHOWN ON SHEET TWO OF THIS DRAWING OR BY ACQUIRING THE # OF ADDITIONAL DIGITALS AND WIRE HARNESS'S REQUIRED FROM ZF MATHERS.

REV A : SEE SHEET 1	
ZF MARINE ELECTRONICS, LLC	
12125 HARBOUR BEACH DR, MIKILTEO WA, 98275	
MICROCOMMANDER-MECHANICAL	
THROTTLE/SHIFT-SYSTEM DRAWING	
ENG. T.JONES	DWL. M.WILSON
WFG. R.J.Z.	QA. R.B.H.
DATE 7-16-03	SHT. 3 OF 3
SCALE: NONE	SIZE: B
PART NO. 91102	DWGNO. 12271




Drawing 12379 MicroCommander - Mechanical Throttle / Shift

91100 INTERNAL CONNECTIONS



TERMINAL CONNECTIONS



STATION SHIELDING AT FRAME
 * DENOTES WIRING FOR A TWIN SCREW APPLICATION

SEE SHEET 3 FOR NOTES

REV. A : SEE SHEET 1	
ZF MARINE ELECTRONICS, LLC	
12125 HARBOUR REACH DR. MARLBORO VA. 98275	
MICROCOMMANDER-MECHANICAL	
THROTTLE/SHIFT-SYSTEM DRAWING	
ENG. JONES	DWN. WILSON
WFG. R.Z.	QA. R.G.
DATE 11-11-03	SHT. 2 OF 3
SCALE: NONE	SIZE: B
PART NO. 91100	DWG. NO. 12379

– NOTES –

– NOTES –

1. DO NOT MOUNT CONTROL SYSTEM COMPONENTS ON ENGINE OR REDUCTION GEAR.
2. DO NOT MOUNT CONTROL COMPONENTS NEAR SOURCES OF HIGH HEAT: (EXHAUST DUCTS, ETC.)
3. DO NOT MOUNT CONTROL COMPONENTS NEAR SOURCES OF STRONG ELECTROMAGNETIC FIELDS: (STARTERS, GENERATORS, ETC.)
4. MOUNT CONTROL COMPONENTS IN A LOCATION ACCESSIBLE FOR CHECKOUT, MONITORING AND MAINTENANCE.
5. ALL ELECTRICAL CABLES ARE TO BE SUITABLE FOR MARINE APPLICATION AND MEET ALL APPLICABLE REGULATORY REQUIREMENTS.
6. INSURE THAT SHIELD ON THE SHIELDED CABLE IS CONNECTED ONLY AT ONE END TO THE CHASSIS AND THAT THE DRAIN WIRE DOES NOT TOUCH ANY OTHER CONDUCTIVE SURFACE. USE THE P-CLAMP TO CONNECT THE SHIELD TO THE CHASSIS AS SHOWN IN THE STATION SHIELDING AT FRAME DETAIL, ON SHEET 2.
- 6a. INSURE THAT DRAIN WIRE ON SHIELDED CABLE IS CONNECTED ONLY WHERE INDICATED INSIDE HOUSING AND THAT DRAIN WIRE DOES NOT TOUCH ANY OTHER CONDUCTIVE SURFACE. FOR OPTIMAL SCREENING THE SERIAL WIRE HARNESS SHIELD SHOULD BE CONNECTED TO "EARTH" AT ONE POINT IN THE VESSEL. (NOT INSIDE THE UNIT)
7. START INTERLOCK RELAY WITH NORMALLY OPEN CONTACTS. CONTACTS ARE CLOSED WHEN SYSTEM IS OPERATING AND COMMANDING NEUTRAL. MAXIMUM OF 5 AMP, MAXIMUM OF 30V.
8. THE CONTROL PROCESSOR WILL BE PROVIDED SHIPS SUPPLY OF 12 OR 24 VDC, PROTECTED BY A 10 AMP RATED CIRCUIT BREAKER PROVIDED BY THE SHIPYARD.
9. CONTROL FAILURE ALARM RELAY CONTACTS RATED FOR A MAXIMUM OF 0.5A, MAXIMUM CONTACT DRY RATING OF 100V. DO NOT EXCEED THIS RATING. IT IS THE SHIPYARD'S RESPONSIBILITY TO UTILIZE THE ALARM CONNECTION IN AN APPROPRIATE ALARM CIRCUIT.
10. CAUTION:
THIS PART CONTAINS ELECTRONIC COMPONENTS WHICH CAN BE DESTROYED BY STATIC ELECTRICITY. PERSONNEL SHOULD GROUND THEMSELVES TO DISSIPATE ANY STATIC ELECTRICITY PRIOR TO WORKING INSIDE THE PART.
11. PRESSURE SWITCH SETPOINT (N.O. CONTACTS) MUST BE SET AT 150 PSI OR AS RECOMMENDED BY TRANSMISSION MANUFACTURER. WHEN CONTACTS CLOSE THIS INDICATES TO THE CONTROL PROCESSOR WHEN THE CLUTCH IS SUFFICIENTLY ENGAGED TO ALLOW A SPEED COMMAND ABOVE IDLE SPEED. IT IS A SAFETY FEATURE THAT PROTECTS THE CLUTCH AND ITS USE IS RECOMMENDED.
12. THE CONTROL PROCESSOR'S MOUNTING FEET MUST BE CONNECTED TO THE VESSEL'S BONDING SYSTEM.
13. FREQUENCY INPUT FOR ENGINE SYNCHRONIZATION:
(INPUT PULSES EITHER AC TYPE TACH INPUT OR OPEN COLLECTOR TYPE INPUT)
AC COUPLED INPUT (TB9-2): MINIMUM FREQUENCY 30Hz – MAXIMUM FREQUENCY 8000Hz.
MINIMUM VOLTAGE 3v – MAXIMUM VOLTAGE 200V, PEAK TO PEAK.
OPEN COLLECTOR INPUT (TB9-3): MINIMUM FREQUENCY 5Hz – MAXIMUM FREQUENCY 8000Hz.
MINIMUM SINK CURRENT 2mA, MAX SENSOR OUTPUT SATURATION VOLTAGE 0.8V.
14. REFER TO DRAWING 11488 FOR ADDITIONAL POWER OPTIONS.
15. ELECTRICAL CABLING MUST BE 14 AWG OR LARGER.
16. ELECTRICAL CABLING MUST BE 16-20 AWG.
17. ELECTRICAL CABLING MUST BE 14-16 AWG.
18. 8 CONDUCTOR 20 AWG SHIELDED CABLE (PN: 00350) WITH COLOR CODE AS SHOWN.

REV A : SEE SHEET 1	
ZF MARINE ELECTRONICS, LLC	
12125 HARBOUR REACH DR. MILWAUKEE WI. 98275	
MICROCOMMANDER-MECHANICAL	
THROTTLE/SHIFT-SYSTEM DRAWING	
ENG. I.JONES	DRAWN M.WILLSON
WFG. R.Z.	QA. R.G.
DATE 11-11-03	SHEET 3 OF 3
SCALE: NONE	SIZE: B
PART NO. 91100	DWG. NO. 12379

ZF Padova S.r.l.

Via Penghe, 48

I - 35030 Caselle di Selvazzano (PD)

ITALY

Phone

+39 049 8299 311

Fax

+39 049 8299 550

www.zf.com



REFERENCE MANUAL

MM13927 FIELD SERVICE TEST UNIT

MARINE PROPULSION SYSTEMS



Released by After Sales dept.

Data subject to change without notice. We decline all responsibility for the use of non-original components or accessories which have not been tested and submitted for approval.

ZF reserves all rights regarding the shown technical information including the right to file industrial property right applications and the industrial property rights resulting from these in Germany and abroad.

© ZF Friedrichshafen AG, 2014.

Revisions List

Rev	Date	Revision Description
A	11/02	Revised Section 1.0 Table 1
B	2/03	Revised manual to current ZF Marine Electronics manual standards. Revised Section 3.0
C	4/03	Deleted Section 2.1.6
D	10/03	Revising to add 9000 Series and 2-Speed information
E	06/07	Brought Entire Manual up to current ZF Standards. Software revised to SW70203.3 adding Joystick display. ELR 1401: Table 1, 2, 3, and 4 Item #3 changed from 13316-XX to 70422-xx Made CANtrak consistent throughout manual. Renamed Figures without CANtrak
E.1	07/10	Reformatted, updated inserted images

1 Introduction

Refer to Bulletin 02-008 for Service Field Test Unit (Part No. 13927) recommendations. Refer to Figure MM13927-1: .Service Field Test Unit (Break-out Box) for an example of the Test Unit and a Multimeter




Figure MM13927-1: .Service Field Test Unit (Break-out Box)

The Service Field Test Unit, hereafter referred to as the “Break-out Box”, is recommended for use with all CruiseCommand Processors (Part No. 785CE) and with ClearCommand Processors (Part No. 9XXX Series) that have pluggable (Pigtail) Throttle, Clutch or Troll Connections.

The procedures for testing the various outputs of the ClearCommand and CruiseCommand Processors are similar, with the exception of where they connect to the respective Processor. Figure MM13927-2: CruiseCommand Connector Locations indicates the location of the connectors on the CruiseCommand Processor and Figure MM13927-3: Example ofCLEARCommand Pigtail Locations the typical pigtail plugs on a 9000 Series ClearCommand Processor.



NOTE: Not all ClearCommand Processors have all of the pigtails shown in Figure MM13927-3: Example ofCLEARCommand Pigtail Locations. Only the pigtails that are required for a specific application are installed in a ClearCommand Processor.




Figure MM13927-2: CruiseCommand Connector Locations




Figure MM13927-3: Example of CLEARCommand Pigtail Locations

Designation #	Description	Harness Type	Harness Use
1	Black 8 Pin	Throttle Connector/Pigtail	The throttle signal is output from this connector/pigtail. The signal may be in the form of Pulse Width Modulation (PWM), Voltage, Current, or Frequency.
2	Black 12 Pin	Power Connector/Pigtail	This connector/pigtail contains the inputs and outputs for Main Processor Power, Start Interlock, Clutch Oil Pressure Interlock, and External Alarm Circuit.
3	Gray 12 Pin	Clutch Connector/Pigtail	The external connections for Clutch Power, Ahead, Astern, and Neutral Solenoids, Troll On/ Off, and Proportional Solenoids are made at this connector/pigtail.
4	Gray 8 Pin	Control Head Connector	All the required connections for the Remote Control Stations are made at these connectors.
5	Gray 6 Pin	Serial Communication Connector/Pigtail	The Serial Communication connections between multiple Processors in applications with more than one Processor at this connector/pigtail.
6	Gray 4 Pin	Tachometer Sensor Connector/Pigtail	The input signal from a Tachometer or Shaft Speed Sensor connects to this connector/pigtail.

The actual procedures for using the Break-out Box are the same for CruiseCommand and ClearCommand Processors. However, the adjustment within the Processor to obtain the correct output may differ. The appropriate Installation Manual must be referred to when making the adjustments.

2 Procedure

2.1 Throttle Signal Testing

Depending on which Processor is being tested, it may have the capability of sourcing one or all of the following: DC Voltage, Current, PWM (Pulse Width Modulation) or Frequency.



NOTE: The following procedures and drawings pertain to both the CruiseCommand and ClearCommand Processors.

2.1.1 DC Voltage

- A Ensure that power is removed from the Engine Electronics and the Processor.
- B Disconnect the Throttle Harness from the number **1** Processor connector/pigtail.
- C Insert the Break-out Box between the number **1** Processor connector/pigtail and the Throttle Harness as shown in Figure MM13927-4: Throttle Connection (DC Voltage).




Figure MM13927-4: Throttle Connection (DC Voltage)

- D Set up the Multimeter to measure DC Volts and plug the black lead into the Break-out Box black socket labeled “-” and the red lead into the socket labeled “VDC”.
- E Turn power ‘On’ to the Processor and take command at any Remote Station.
- F The appropriate Idle Voltage for the application should be measured at this time.
- G Move the Control Head lever to the Full Throttle position while depressing the Transfer Button (Throttle Only Mode).
- H The appropriate Full Throttle Voltage for the application should be measured at this time.

2.1.2 Current (mA)

- A Ensure power is removed from both the Engine Electronics and the Processor.
- B Disconnect the Throttle Harness from the number **1** Processor connector/pigtail.
- C Insert the Break-out Box between the number **1** Processor connector/pigtail and the Throttle Harness as shown in Figure MM13927-5: Throttle Connection (Current mA).
- D Set up the Multimeter to measure current (mA.) and plug the black lead into the Break-out Box black socket labeled “-” and the red lead into the socket labeled “mA”.
- E Turn power ‘On’ to the Processor and take command at any Remote Station.

- F Depress and hold the Push-button Switch labeled "mA." The appropriate Current (mA.) for the application should be measured.
- G Move the Control Head lever to the Full Throttle position while depressing the Transfer Button (Throttle Only Mode).




Figure MM13927-5: Throttle Connection (Current mA)

- H Depress and hold the "mA." Push-button. The appropriate Full Throttle Current (mA.) for the application should be measured at this time.

2.1.3 PWM (Pulse Width Modulation) with DC Voltmeter

- A Ensure power is removed from both the Engine Electronics and the Processor.
- B Disconnect the Throttle Harness from the number 1 Processor connector/pigtail.
- C Insert the Break-out Box between the number 1 Processor connector/pigtail and the Throttle Harness as shown in Figure MM13927-6: Throttle Connection (PWM with DC Voltmeter) labeled "-" and the red lead into the socket labeled "PWM".




Figure MM13927-6: Throttle Connection (PWM with DC Voltmeter)

- D Turn power 'On' to the Caterpillar ECM (Electronic Control Module) **Only. Do Not** apply power to the Processor at this time.

- E Depending on the type of Caterpillar ECM (PEEC or ADEMS), the measurement should be approximately 5.00 or 12.00 VDC. Record the measurement as shown in Drawing Figure MM13927-6: Throttle Connection (PWM with DC Voltmeter).
- F Set up the Multimeter to DC Volts and plug the black lead into the Break-out Box black socket Turn power 'On' to the Processor and take command at any Remote Station.
- G Record the DC Voltage at this time. The measurement should be 7- 9% of the voltage measured in step F).
- H Move the Control Head lever to the Full Throttle position while depressing the Transfer Button (Throttle Only Mode).
- I The measurement should be 91- 93% of the voltage measured in step F) [e.g. Idle = 8% of 12 VDC reference or 0.96 VDC; Full Throttle = 92% of 12 VDC reference or 11.04 VDC.

2.1.4 PWM (Pulse Width Modulation) with Duty Cycle Meter

- A Ensure power is removed from both the Engine electronics and the Processor.
- B Disconnect the Throttle Harness from the number 1 Processor connector/pigtail.
- C Insert the Break-out Box between the number 1 Processor connector/pigtail and the Throttle Harness as shown in Figure MM13927-7: Throttle connection (PWM with Duty Cycle Meter).





Figure MM13927-7: Throttle connection (PWM with Duty Cycle Meter)

- D Set up the Multimeter to measure Duty Cycle and plug the black lead into the Break-out Box black socket labeled "-" and the red lead into the socket labeled "PWM".
- E Turn power 'On' to the Caterpillar ECM (Electronic Control Module) and to the Processor.
- F The measurement should be approximately 8% duty Cycle.
- G Move the Control Head lever to the Full Throttle position while depressing the Transfer Button (Throttle Only Mode).
- H The measurement will increase from 8% to 91- 93%.

2.1.5 Frequency (Hz.)

- A Ensure power is removed from both the Engine Electronics and the Processor.
- B Disconnect the Throttle Harness from the number 1 Processor connector/pigtail.
- C Insert the Break-out Box between the number 1 Processor connector/pigtail and the Throttle Harness as shown in Figure MM13927-8: Throttle Connection (Frequency Hz).

- D Set up the Multimeter to measure Frequency and plug the black lead into the Break-out Box black socket labeled “-” and the red lead into the socket labeled “FREQ”.



DWG: 11653-A_ART


Figure MM13927-8: Throttle Connection (Frequency Hz)

- E Turn power ‘On’ to the Processor and take command at any Remote Station.
- F The appropriate Idle Frequency for the application should be measured at this time.
- G Move the Control Head lever to the Full Throttle position while depressing the Transfer Button (Throttle Only Mode).
- H The appropriate Full Throttle Frequency for the application should be measured at this time.

2.2 Clutch Testing

2.2.1 Neutral Solenoid Testing

- A Ensure power is removed from both the Processor and the Clutch Power Supply.
- B Disconnect the Clutch Harness from the number 3 Processor connector/pigtail.
- C Insert the Break-out Box between the number 3 Processor connector/pigtail and the Clutch Harness as shown in Figure MM13927-9: Clutch Connections Neutral Solenoid.



DWG: 11653-L_ART

Figure MM13927-9: Clutch Connections Neutral Solenoid

- D Turn power ‘On’ to the Processor and take command at any Remote Station with the Control Head lever in the Neutral/Idle position.
- E The measurement on the Neutral Test Point should be 12 or 24 VDC, depending on the Solenoid’s rating and the LED adjacent to the socket should be illuminated.

- F Move the Control Head lever to the Ahead Detent position. The voltage should drop to 0 VDC in CruiseCommand systems and remain at 12 or 24 VDC in ClearCommand systems. The adjacent LED should go out in CruiseCommand systems and stay on in ClearCommand systems.

2.2.2 Ahead Solenoid Testing

- A Ensure power is removed from both the Processor and the Clutch Power Supply.
- B Disconnect the Clutch Harness from the number 3 Processor connector/pigtail.
- C Insert the Break-out Box between the number 3 Processor connector/pigtail and the Clutch Harness as shown in Figure MM13927-10: Clutch Connections Ahead Solenoid.





Figure MM13927-10: Clutch Connections Ahead Solenoid

- D Set up the Multimeter to measure DC Volts and plug the black lead into the Break-out Box socket labeled “CLUTCH -” and the red lead into the socket labeled “AHEAD”.
- E Turn power ‘On’ to the Processor and take command at any Remote Station with the lever in the Neutral/Idle position.
- F The measurement should be 0 VDC and the adjacent LED should not be lit.
- G Position the Control Head lever into the Ahead detent. The measurement should be 12 or 24 VDC depending on the Ahead Solenoid’s rating. The LED adjacent to the Ahead plug on the Break-out Box should be lit.
- H Return the Control Head lever to the Neutral/Idle position.

2.2.3 Astern Solenoid Testing

- A Ensure power is removed from both the Processor and the Clutch Supply Power.
- B Disconnect the Clutch Harness from the number 3 Processor connector/pigtail.
- C Insert the Break-out Box between the number 3 Processor connector/pigtail and the Clutch Harness as shown in Figure MM13927-11: Clutch Connections Astern Solenoid.
- D Set up the Multimeter to measure DC Volts and plug the black lead into the Break-out Box socket labeled “CLUTCH -” and the red lead into the socket labeled “ASTERN”.
- E Turn power ‘On’ to the Processor and take command at any Remote Station with the Control Head lever in the Neutral/Idle position.

- F The measurement should be 0 VDC and the adjacent LED should not be lit.



DWG: 11653-J_ART


Figure MM13927-11: Clutch Connections Astern Solenoid

- G Position the Control Head lever into the Astern detent. The measurement should be 12 or 24 VDC depending on the Astern Solenoid's rating. The LED adjacent to the Astern plug on the Break-out Box should be lit. Return the Control Head lever to the Neutral/Idle position.

2.3 Troll Testing

2.3.1 Troll On/Off Solenoid

- A Ensure power is removed from both the Processor and the Clutch Power Supply.
- B Disconnect the Clutch Harness from the number 3 Processor connector/pigtail.
- C Insert the Break-out Box between the number 3 Processor connector/pigtail and the Clutch Harness as shown in Figure MM13927-12: Troll Connections Troll On/Off Solenoid.



DWG: 11653-M_ART

Figure MM13927-12: Troll Connections Troll On/Off Solenoid

- D Set up the Multimeter to measure DC Volts and connect the black lead to the socket labeled "CLUTCH -" and the red lead to the socket labeled "TROLL ON/OFF" as shown in Figure MM13927-12: Troll Connections Troll On/Off Solenoid.
- E Turn power 'On' to the Processor and the Clutch Power Supply and take command at a Remote Station with the Control Head lever in the Neutral/Idle position.
- F Depress the Transfer Button again for approximately 2 seconds until the red LED begins blinking at a fast rate (Troll Mode Indication).
- G The measurement should be 0 VDC.

- H Position the Control Head lever to the Ahead detent. The measurement should now be 12 or 24 VDC, depending on the Solenoid's rating.
- I Position the Control Head lever further forward while monitoring the DC Voltmeter. The measurement should go from 12 or 24 VDC to 0 VDC at the same time the red LED on the Control Head becomes lit solid.

2.3.2 Troll Command (Proportional Solenoid) Testing with Amp Meter

- A Ensure power is removed from both the Processor and the Clutch Power Supply.
- B Disconnect the Clutch Harness from the number 3 Processor connector/pigtail.
- C Insert the Break-out Box between the number 3 Processor connector/pigtail and the Clutch Harness as shown in Figure MM13927-13: Troll Connections (Proportional Solenoid).




Figure MM13927-13: Troll Connections (Proportional Solenoid)

- D Set up the Multimeter to measure (mA,) and connect the black lead to black socket and the red lead to the red socket labeled "TROLL COMMAND" as shown in Figure MM13927-13: Troll Connections (Proportional Solenoid).
- E Turn power 'On' to the Processor and the Clutch Power Supply and take command at a Remote Station with the Control Head lever in the Neutral/Idle position.
- F Depress the Transfer Button again for approximately 2 seconds until the red LED on the Control Head begins blinking at a fast rate (Troll Mode Indication).
- G Flip switch away from "Troll Command" to read current through meter.
- H Move the Control Head lever to the Ahead detent. The current measurement should be the correct value for minimum clutch pressure (shaft rotations). This value varies depending on the type of Marine Gear. Refer to the Literature provided with the Trolling Valve and the Processor for specifics.
- I Slowly advance the Control Head lever while monitoring the current. The current should increase or decrease, depending on the Gear type, in proportion with the Control Head lever movement. Once again, refer to the Literature provided with the Trolling Valve and the Processor for specific values.
- J Continue to move the Control Head lever forward until the red LED stops blinking (lit steady). The current should drop to 0 mA.

2.4 2-Speed Testing

2.4.1 2nd Gear Disengaged

- A Ensure power is removed from the Processor.
- B Disconnect the Clutch/2-Speed Harness from the number 3 Processor connector/pigtail.

- C Insert the Break-out Box between the number 3 Processor connector/pigtail and the Clutch/2-Speed Harness as shown in Figure MM13927-14: 2-Speed Connections.1653




Figure MM13927-14: 2-Speed Connections

- D Set up the Multimeter to measure DC Volts and connect the black lead to the socket labeled “CLUTCH - ” and the red lead to the socket labeled “TROLL ON/OFF” as shown in Figure MM13927-14: 2-Speed Connections.
- E Turn power ‘On’ to the Processor and take command at any Remote Station.
- F The voltage measurement should be approximate 0 VDC.

2.4.2 2nd Gear Engaged

- A Leave the Break-out Box and Multimeter in the same position as left in 2nd Gear Disengaged.
- B Start the engine(s).
- C Depress the Transfer Button while moving the lever(s) into the Ahead detent (red LED should be blinking, indicating Warm-up Mode).
- D Continue to move both Control Head lever(s) forward until the RPM programmed for Function Code **U1** has been reached.
- E The voltage measurement at the Multimeter should now be 12 or 24 VDC, depending on the Solenoid’s rating.
- F Return the Control Head levers to the Neutral/Idle position and shut down the engines.
- G Turn power Off to the Processor(s).
- H Unplug the Break-out Box from the Pigtail and Harness plugs and reconnect the Harness to the Pigtail.

2.5 Parts List

ZF Marine Electronics Part No.	Part Name
13927	Service Field Test unit (Break-out Box)
MM13927	Technical Manual
	Multimeter
14000	Test Control Head - Dual

ZF Padova S.r.l.

Via Penghe, 48

I - 35030 Caselle di Selvazzano (PD)

ITALY

Phone

+39 049 8299 311

Fax

+39 049 8299 550

www.zf.com

